

CANopen Manual

canopen

item Servo Positioning Controller C Series

item Industrietechnik GmbH
Friedenstraße 107-109
42699 Solingen
Germany

Phone: +49-(0)212-6580-0
Fax: +49-(0)212-6580-310
E-mail: info@item24.com

Fehler! Verweisquelle konnte nicht gefunden werden.

Copyrights

© 2016 . All rights reserved.

The information and data in this document have been composed to the best of our knowledge. However, deviations between the document and the product cannot be excluded entirely. For the devices and the corresponding software in the version handed out to the customer, guarantees the contractual use in accordance with the user documentation. In the case of serious deviations from the user documentation, has the right and the obligation to repair, unless it would involve an unreasonable effort. A possible liability does not include deficiencies caused by deviations from the operating conditions intended for the device and described in the user documentation.

does not guarantee that the products meet the buyer's demands and purposes or that they work together with other products selected by the buyer. does not assume any liability for damages resulting from the combined use of its products with other products or resulting from improper handling of machines or systems.

reserves the right to modify, amend, or improve the document or the product without prior notification.

This document may, neither entirely nor in part, be reproduced, translated into any other natural or machine-readable language nor transferred to electronic, mechanical, optical or any other kind of data media, without expressive authorisation by the author.

Trademarks

Any product names in this document may be registered trademarks. The sole purpose of any trademarks in this document is the identification of the corresponding products.

™ is a registered trademark of .

Table of contents

1	General Terms	12
1.1	Documentation.....	12
1.2	CANopen.....	12
2	Safety Notes for electrical drives and controls	14
2.1	Symbols and signs	14
2.2	General notes	15
2.3	Danger resulting from misuse	16
2.4	Safety notes	17
2.4.1	General safety notes.....	17
2.4.2	Safety notes for assembly and maintenance.....	18
2.4.3	Protection against contact with electrical parts.....	19
2.4.4	Protection against electrical shock by means of protective extra-low voltage (PELV)	20
2.4.5	Protection against dangerous movements	21
2.4.6	Protection against contact with hot parts.....	21
2.4.7	Protection during handling and assembly.....	22
3	Cabling and pin assignment.....	24
3.1	Pin assignment.....	24
3.2	Cabling hints	25
4	Activation of CANopen.....	26
4.1	Survey.....	26
5	Access methods.....	28
5.1	Survey.....	28
5.2	Access by SDO	29
5.2.1	SDO sequences to read or write parameters	30
5.2.2	SDO-error messages.....	32
5.2.3	Simulation of SDO accesses via RS232	33
5.3	PDO-Message	35
5.3.1	Description of objects.....	37
5.3.2	Objects for parameterising PDOs	40
5.3.3	Activation of PDOs.....	47
5.4	SYNC-Message	48
5.5	EMERGENCY-Message	48
5.5.1	Survey.....	49
5.5.2	Structure of an EMERGENCY message	49
5.5.3	Description of Objects	52
5.5.3.1	Object 1003; pre_defined_error_field	52
5.6	Network management (NMT service).....	54
5.7	Bootup (Error Control Protocol)	57
5.7.1	Survey.....	57
5.7.2	Structure of the Bootup message.....	57
5.8	Heartbeat (Error Control Protocol)	57
5.8.1	Survey.....	57
5.8.2	Structure of the Heartbeat message	58

5.8.3 Objects.....	58
5.8.3.1 Object 1017 _h : producer_heartbeat_time.....	58
5.9 Nodeguarding (Error Control Protocol).....	60
5.9.1 Survey.....	60
5.9.2 Structure of the Nodeguarding message	60
5.9.3 Description of Objects	61
5.9.3.1 Object 100C _h : guard_time.....	61
5.9.3.2 Objekt 100D _h : life_time_factor.....	61
5.10 Table of identifiers.....	62
6 Adjustment of parameters.....	63
6.1 Load and save set of parameters	63
6.1.1 Survey.....	63
6.1.2 Description of Objects	65
6.1.2.1 Object 1011 _h : restore_default_parameters.....	65
6.1.2.2 Object 1010 _h : store_parameters	66
6.2 Compatibility settings	67
6.2.1 Survey.....	67
6.2.2 Description of Objects	67
6.2.2.1 Objects treated in this chapter.....	67
6.2.2.2 Object 6510 _h _F0 _h : compatibility_control.....	67
6.3 Conversion factors (Factor Group)	70
6.3.1 Survey.....	70
6.3.2 Description of Objects	71
6.3.2.1 Objects treated in this chapter.....	71
6.3.2.2 Object 6093 _h : position_factor	71
6.3.2.3 Object 6094 _h : velocity_encoder_factor	75
6.3.2.4 Object 6097 _h : acceleration_factor	78
6.3.2.5 Object 607E _h : polarity	81
6.4 Power stage parameters	82
6.4.1 Survey.....	82
6.4.2 Description of Objects	82
6.4.2.1 Object 6510 _h _10 _h : enable_logic.....	82
6.4.2.2 Object 6510 _h _30 _h : pwm_frequency	83
6.4.2.3 Object 6510 _h _3A _h : enable_enhanced_modulation.....	84
6.4.2.4 Object 6510 _h _31 _h : power_stage_temperature	85
6.4.2.5 Object 6510 _h _32 _h : max_power_stage_temperature	86
6.4.2.6 Object 6510 _h _33 _h : nominal_dc_link_circuit_voltage	86
6.4.2.7 Object 6510 _h _34 _h : actual_dc_link_circuit_voltage	88
6.4.2.8 Object 6510 _h _35 _h : max_dc_link_circuit_voltage	88
6.4.2.9 Object 6510 _h _36 _h : min_dc_link_circuit_voltage	89
6.4.2.10 Object 6510 _h _37 _h : enable_dc_link_undervoltage_error	89
6.4.2.11 Object 6510 _h _40 _h : nominal_current	91
6.4.2.12 Object 6510 _h _41 _h : peak_current	92
6.5 Current control and motor adaptation.....	93
6.5.1 Survey.....	93
6.5.2 Description of Objects	94
6.5.2.1 Object 6075 _h : motor_rated_current	94
6.5.2.2 Object 6073 _h : max_current	95
6.5.2.3 Object 604D _h : pole_number	95
6.5.2.4 Object 6410 _h _03 _h : iit_time_motor	97
6.5.2.5 Object 6410 _h _04 _h : iit_ratio_motor	97
6.5.2.6 Object 6510 _h _38 _h : iit_error_enable	98

6.5.2.7 Object 6410 _h _10 _h : phase_order.....	98
6.5.2.8 Object 6410 _h _11 _h : encoder_offset_angle.....	99
6.5.2.9 Object 6410 _h _14 _h : motor_temperature_sensor_polarity.....	101
6.5.2.10Object 6510 _h _2E _h : motor_temperature.....	101
6.5.2.11Object 6510 _h _2F _h : max_motor_temperature	102
6.5.2.12Object 60F6 _h : torque_control_parameters.....	103
6.6 Velocity controller.....	104
6.6.1 Survey.....	104
6.6.2 Description of Objects	104
6.6.2.1 Object 60F9 _h : velocity_control_parameters.....	104
6.6.2.2 Objekt 2073 _h : velocity_display_filter_time.....	106
6.7 Position Control Function	107
6.7.1 Survey.....	107
6.7.2 Description of Objects	110
6.7.2.1 Objects treated in this chapter.....	110
6.7.2.2 Affected objects from other chapters.....	111
6.7.2.3 Object 60FB _h : position_control_parameter_set	111
6.7.2.4 Object 6062 _h : position_demand_value	114
6.7.2.5 Object 202D _h : position_demand_sync_value	114
6.7.2.6 Object 6064 _h : position_actual_value.....	116
6.7.2.7 Object 6065 _h : following_error_window.....	116
6.7.2.8 Object 6066 _h : following_error_time_out	118
6.7.2.9 Object 60FA _h : control_effort	118
6.7.2.10Object 6067 _h : position_window.....	119
6.7.2.11Object 6068 _h : position_window_time	119
6.7.2.12Object 6510 _h _22 _h : position_error_switch_off_limit.....	120
6.7.2.13Object 607B _h : position_range_limit	121
6.7.2.14Object 6510 _h _20 _h : position_range_limit_enable	122
6.7.2.15Object 2030 _h : set_position_absolute	123
6.8 Setpoint limitation.....	123
6.8.1 Description of objects.....	123
6.8.1.1 Objects treated in this chapter.....	123
6.8.1.2 Object 2415 _h : current_limitation.....	123
6.8.1.3 Object 2416 _h : speed_limitation	125
6.9 Encoder settings.....	126
6.9.1 Survey.....	126
6.9.2 Description of Objects	127
6.9.2.1 Objects treated in this chapter.....	127
6.9.2.2 Object 2024 _h : encoder_x2a_data_field.....	127
6.9.2.3 Object 2026 _h : encoder_x2b_data_field.....	129
6.9.2.4 Object 2025 _h : encoder_x10_data_field.....	131
6.10 Incremental encoder emulation.....	134
6.10.1 Survey	134
6.10.2 Description of Objects	134
6.10.2.1Objects treated in this chapter.....	134
6.10.2.2Object 2028 _h : encoder_emulation_resolution	134
6.10.2.3Object 2028 _h : encoder_emulation_resolution	135
6.11 Sources for demand / actual value	137
6.11.1 Survey	137
6.11.2 Description of Objects	137
6.11.2.1Objects treated in this chapter.....	137
6.11.2.2Object 201F _h : commutation_encoder_select	137

6.11.2.3Object 2021 _h : position_encoder_selection.....	139
6.11.2.4Object 2022 _h : synchronisation_encoder_selection.....	140
6.11.2.5Object 202F _h : synchronisation_selector_data	141
6.11.2.6Object 2023 _h : synchronisation_filter_time.....	142
6.12 Analogue inputs	143
6.12.1 Survey	143
6.12.2 Description of Objects.....	143
6.12.2.12400 _h : analog_input_voltage	143
6.12.2.20Object 2401 _h : analog_input_offset (Offset Analogeingänge).....	144
6.13 Digital inputs and outputs.....	146
6.13.1 Survey	146
6.13.2 Description of Objects.....	146
6.13.2.1Objects treated in this chapter.....	146
6.13.2.2Object 60FD _h : digital_inputs.....	147
6.13.2.3Object 60FE _h : digital_outputs.....	148
6.13.2.4Object 2420 _h : digital_output_state_mapping.....	149
6.14 Homing switches (Limit / Reference switch).....	152
6.14.1 Survey	152
6.14.2 Description of Objects.....	152
6.14.2.1Object 6510 _h _11 _h : limit_switch_polarity	152
6.14.2.2Object 6510 _h _12 _h : limit_switch_selector	153
6.14.2.3Object 6510 _h _14 _h : homing_switch_polarity.....	153
6.14.2.4Object 6510 _h _13 _h : homing_switch_selector	155
6.14.2.5Object 6510 _h _15 _h : limit_switch_deceleration	155
6.15 Sampling positions.....	156
6.15.1 Survey	156
6.15.2 Description of Objects.....	156
6.15.2.1Objects treated in this chapter.....	156
6.15.2.2Object 204A _h : sample_data.....	157
6.16 Brake control.....	162
6.16.1 Survey	162
6.16.2 Description of Objects.....	163
6.16.2.1Object 6510 _h _18 _h : brake_delay_time.....	163
6.17 Device informations	164
6.17.1 Description of Objects	164
6.17.1.1Object 1018 _h : identity_object	164
6.17.1.2Object 6510 _h _A0 _h : drive_serial_number	166
6.17.1.3Object 6510 _h _A1 _h : drive_type.....	166
6.17.1.4Object 6510 _h _A9 _h : firmware_main_version.....	167
6.17.1.5Object 6510 _h _AA _h : firmware_custom_version	167
6.17.1.6Object 6510 _h _AD _h : km_release.....	167
6.17.1.7Object 6510 _h _AC _h : firmware_type	169
6.17.1.8Object 6510 _h _B0 _h : cycletime_current_controller.....	169
6.17.1.9Object 6510 _h _B1 _h : cycletime_velocity_controller.....	170
6.17.1.10 Object 6510 _h _B2 _h : cycletime_position_controller.....	170
6.17.1.11 Object 6510 _h _B3 _h : cycletime_trajectory_generator	170
6.17.1.12 Object 6510 _h _C0 _h : commissioning_state	172
6.18 Error management	173
6.18.1 Survey	173
6.18.2 Description of Objects	174
6.18.2.1Objects treated in this chapter.....	174
6.18.2.2Object 2100 _h : error_management	174

6.18.2.30	Objekt 200F _h : last_warning_code	176
7	Device Control	177
7.1	State diagram (State machine)	177
7.1.1	Survey.....	177
7.1.2	The state diagram of the servo controller	178
7.1.2.1	State diagram: States	180
7.1.2.2	State diagram: State transitions	180
7.1.3	controlword.....	183
7.1.3.1	Object 6040 _h : controlword	183
7.1.4	Reading the status of the servo controller	187
7.1.5	statusword.....	188
7.1.5.1	Object 6041 _h : statusword	188
7.1.5.2	Object 2000 _h : manufacturer_statuswords	193
7.1.5.3	Objekt 2005 _h : manufacturer_status_masks	196
7.1.5.4	Objekt 200A _h : manufacturer_status_invert	197
7.1.6	Description of Objects	198
7.1.6.1	Objects treated in this chapter	198
7.1.6.2	Object 605B _h : shutdown_option_code	198
7.1.6.3	Object 605C _h : disable_operation_option_code	199
7.1.6.4	Object 605A _h : quick_stop_option_code	199
7.1.6.5	Object 605E _h : fault_reaction_option_code	200
8	Operating Modes	201
8.1	Adjustment of the Operating Mode	201
8.1.1	Survey.....	201
8.1.2	Description of Objects	201
8.1.2.1	Objects treated in this chapter	201
8.1.2.2	Object 6060 _h : modes_of_operation	202
8.1.2.3	Object 6061 _h : modes_of_operation_display	203
8.2	Operating Mode »Homing mode«	205
8.2.1	Survey.....	205
8.2.2	Description of Objects	206
8.2.2.1	Objects treated in this chapter	206
8.2.2.2	Affected objects from other chapters	206
8.2.2.3	Object 607C _h : home_offset	206
8.2.2.4	Object 6098 _h : homing_method	207
8.2.2.5	Object 6099 _h : homing_speeds	208
8.2.2.6	Object 609A _h : homing_acceleration	210
8.2.2.7	Object 2045 _h : homing_timeout	210
8.2.3	Homing sequences	211
8.2.3.1	Method 1: Negative limit switch using zero impulse evaluation	211
8.2.3.2	Method 2: Positive limit switch using zero impulse evaluation	211
8.2.3.3	Methods 7 and 11: Reference switch and zero impulse evaluation	212
8.2.3.4	Method 17: Homing operation to the negative limit switch	213
8.2.3.5	Method 18: Homing operation to the positive limit switch	213
8.2.3.6	Methods 23 and 27: Homing operation to the reference switch	214
8.2.3.7	Method -1: Negative stop evaluating the zero impulse	215
8.2.3.8	Method -2: Positive stop evaluating the zero impulse	215
8.2.3.9	Method -17: Homing operation to the negative stop	216
8.2.3.10	Method -18: Homing operation to the positive stop	216
8.2.3.11	Methods 32 and 33: Homing operation to the zero impulse	216
8.2.3.12	Method 34: Homing operation to the current position	217

8.2.4 Control of the homing operation.....	217
8.3 Operating Mode »Profile Position Mode«.....	218
8.3.1 Survey.....	218
8.3.2 Description of Objects	219
8.3.2.1 Objects treated in this chapter.....	219
8.3.2.2 Affected objects from other chapters.....	219
8.3.2.3 Object 607Ah: target_position.....	219
8.3.2.4 Object 6081h: profile_velocity.....	221
8.3.2.5 Object 6082h: end_velocity.....	221
8.3.2.6 Object 6083h: profile_acceleration.....	222
8.3.2.7 Object 6084h: profile_deceleration	222
8.3.2.8 Object 6085h: quick_stop_deceleration.....	223
8.3.2.9 Object 6086h: motion_profile_type.....	223
8.3.3 Functional Description	224
8.4 Interpolated Position Mode.....	227
8.4.1 Survey.....	227
8.4.2 Description of Objects	228
8.4.2.1 Objects treated in this chapter.....	228
8.4.2.2 Affected objects of other chapters	228
8.4.2.3 Object 60C0h: interpolation_submode_select.....	228
8.4.2.4 Object 60C1h: interpolation_data_record.....	229
8.4.2.5 Object 60C2h: interpolation_time_period	231
8.4.2.6 Object 60C3h: interpolation_sync_definition.....	232
8.4.2.7 Object 60C4h: interpolation_data_configuration	234
8.4.3 Functional Description	237
8.4.3.1 Preliminary parameterisation.....	237
8.4.3.2 Activation of the Interpolated Position Mode and first synchronisation.....	237
8.4.3.3 Interruption of interpolation in case of an error	240
8.5 Profile Velocity Mode.....	241
8.5.1 Survey.....	241
8.5.2 Description of Objects	243
8.5.2.1 Objects treated in this chapter.....	243
8.5.2.2 Affected objects from other chapters	244
8.5.2.3 Object 6069h: velocity_sensor_actual_value	244
8.5.2.4 Object 606Ah: sensor_selection_code.....	245
8.5.2.5 Object 606Bh: velocity_demand_value	245
8.5.2.6 Object 202Eh: velocity_demand_sync_value	246
8.5.2.7 Object 606Ch: velocity_actual_value	246
8.5.2.8 Objekt 2074h: velocity_actual_value_filtered.....	247
8.5.2.9 Object 606Dh: velocity_window	248
8.5.2.10 Object 606Eh: velocity_window_time	248
8.5.2.11 Object 606Fh: velocity_threshold	249
8.5.2.12 Object 6070h: velocity_threshold_time	249
8.5.2.13 Object 6080h: max_motor_speed	250
8.5.2.14 Object 60FFh: target_velocity	250
8.6 Speed ramps	250
8.7 Profile Torque Mode	253
8.7.1 Survey.....	253
8.7.2 Description of Objects	254
8.7.2.1 Objects treated in this chapter	254
8.7.2.2 Affected objects from other chapters	254
8.7.2.3 Object 6071h: target_torque	255

8.7.2.4 Object 6072 _h : max_torque.....	255
8.7.2.5 Object 6074 _h : torque_demand_value.....	256
8.7.2.6 Object 6076 _h : motor_rated_torque.....	256
8.7.2.7 Object 6077 _h : torque_actual_value.....	257
8.7.2.8 Object 6078 _h : current_actual_value.....	257
8.7.2.9 Object 6079 _h : dc_link_circuit_voltage	258
8.7.2.10 Object 6087 _h : torque_slope.....	258
8.7.2.11 Object 6088 _h : torque_profile_type.....	259
9 Appendix	260
9.1 Characteristics of the CAN interface.....	260
9.2 Header File	260
10 Keyword index	270

Table of Figures

Figure 3.1:	CAN connector for	24
Figure 3.2:	Cabling (schematically)	25
Figure 5.3:	Access methods	28
Figure 5.4:	NMT-State machine	55
Figure 6.5:	Survey: Factor Group	72
Figure 6.6:	Trailing error (Following Error) – Function Survey	107
Figure 6.7:	Trailing error (following error)	108
Figure 6.8:	Position Reached – Function Survey	108
Figure 6.9:	Position reached	109
Figure 6.10:	Function of brake delay (in Operating Mode Profile Velocity Mode and Operating Mode »Profile Position Mode«)	162
Figure 7.11:	State diagram of the servo controller	178
Figure 7.12:	Most important state transitions	179
Figure 8.1:	Homing Mode	205
Figure 8.2:	Home Offset	206
Figure 8.3:	Homing operation to the negative limit switch including evaluation of the zero impulse	211
Figure 8.4:	Homing operation to the positive limit switch including evaluation of the zero impulse	211
Figure 8.5:	Homing operation to the reference switch evaluating the zero impulse for a positive start motion	212
Figure 8.6:	Homing operation to the reference switch evaluating the zero impulse for a negative start motion	212
Figure 8.7:	Homing operation to the negative limit switch	213
Figure 8.8:	Homing operation to the positive limit switch	213
Figure 8.9:	Homing operation to the reference switch for a positive start motion	214
Figure 8.10:	Homing operation to the reference switch for a negative start motion	214
Figure 8.11:	Homing operation to the negative stop evaluating the zero impulse	215
Figure 8.12:	Homing operation to the positive stop evaluating the zero impulse	215
Figure 8.13:	Homing operation to the negative stop	216
Figure 8.14:	Homing operation to the positive stop	216
Figure 8.15:	Homing operation only referring to the zero impulse	217
Figure 8.16:	Trajectory generator and position controller	218
Figure 8.17:	Positioning job transfer from a host	224
Figure 8.18:	Simple positioning job	225
Figure 8.19:	Gapless sequence of positioning jobs	226
Figure 8.20:	Linear interpolation between two positions	227
Figure 8.21:	First synchronisation und data processing	239
Figure 8.22:	Structure of the Profile Velocity Mode	242

Figure 8.23: Evaluation of velocity_actual_value and velocity_actual_value_filtered	247
Figure 8.24: Speed ramps	251
Figure 8.25: Structure of the Profile Torque Mode	253

1 General Terms

1.1 Documentation

This manual describes how to parametrize and control the using the standardised protocol CANopen. The adjustment of the physical parameters, the activation of the CANopen protocol, the embedding into a CAN network and the communication with the controller will be explained. It is intended for persons who are already well versed with the servo positioning controller series.

It contains safety notes that have to be noticed.

For more information, please refer to the following manuals of the :

- **Software Manual “item Servo Positioning Controller C Series”:** Description of the device functionality and the software functions of the firmware including RS232 communication. Description of the parameterisation program™ with instructions on the commissioning of the .
- **Product Manual “item Servo Positioning Controller C 1-Series”:** Description of the technical specifications and the device functionality as well as notes on the installation and the operation of the .
- **Product manual "item Servo Positioning Controller C 3-Series":** Description of the technical data and the device functionality plus notes concerning the installation and operation of the .
- **CANopen Manual “item Servo Positioning Controller C 3-Series“:** Description of the implemented CANopen protocol as per DSP402.
- **PROFIBUS Manual “item Servo Positioning Controller C 3-Series”:** Description of the implemented PROFIBUS-DP protocol.

1.2 CANopen

CANopen is a standard established by the association “CAN in Automation”. A great number of device manufacturers are organised in this association. This standard has replaced most of all manufacturer-specific CAN protocols. So a manufacturer independent communication interface is available for the user:

CiA Draft Standard 201...207: In these standards the general network administration and the transfer of objects are determined. This book is rather comprehensive. The relevant aspects are treated in the CANopen manual in hand so that it is not necessary in general to acquire the DS201..207.

CiA Draft Standard 301: In this standard the basic structure of the object dictionary of a CANopen device and the access to this directory are described. Besides this the statements made in the DS201..207 are described in detail. The elements needed for the of the object directory and the access methods which belong to them are described in the present manual. It is advisable to acquire the DS301 but not necessary.

CiA Draft Standard 402: This standard describes the concrete implementation of CANopen in servo controllers. Though all implemented objects are also briefly documented and described in this CANopen manual the user should own this book.

Order address

CAN in Automation (CiA) International Headquarter
Am Wechselgarten 26
D-91058 Erlangen
Tel. +49-09131-601091
Fax: +49-09131-601092
www.can-cia.de

The underlying standards are used by the implementation of the CANopen:

- | | | | |
|--------------------------------------|---------------|-------------|------|
| [1] CiA Draft Standard 301, | Version 4.02, | 13. Februar | 2002 |
| [2] CiA Draft Standard Proposal 402, | Version 2.0, | 26. Juli | 2002 |

2 Safety Notes for electrical drives and controls

2.1 Symbols and signs



Information

Important informations and notes.



Caution!

The nonobservance can result in high property damage.



DANGER!

The nonobservance can result in property damages and in **injuries to persons**.



Caution! High voltage.

The note on safety contains a reference to a possibly occurring life dangerous voltage.



The parts of this document marked with this sign should give examples to make it easier to understand the use of single objects and parameters.

2.2 General notes

In case of damage resulting from non-compliance with the safety notes in this manual, will not assume any liability.



Prior to the initial use you must read the chapters Safety Notes for electrical drives and controls *starting on page 14*

If the documentation in the language at hand is not understood accurately, please contact and inform your supplier.

Sound and safe operation of the servo drive controller requires proper and professional transportation, storage, assembly and installation as well as proper operation and maintenance. Only trained and qualified personnel may handle electrical devices:

TRAINED AND QUALIFIED PERSONNEL

in the sense of this product manual or the safety notes on the product itself are persons who are sufficiently familiar with the setup, assembly, commissioning and operation of the product as well as all warnings and precautions as per the instructions in this manual and who are sufficiently qualified in their field of expertise:

- Education and instruction or authorisation to switch devices/systems on and off and to ground them as per the standards of safety engineering and to efficiently label them as per the job demands.
- Education and instruction as per the standards of safety engineering regarding the maintenance and use of adequate safety equipment.
- First aid training.

The following notes must be read prior to the initial operation of the system to prevent personal injuries and/or property damages:



These safety notes must be complied with at all times.



Do not try to install or commission the servo drive controller before carefully reading all safety notes for electrical drives and controllers contained in this document. These safety instructions and all other user notes must be read prior to any work with the servo drive controller.



In case you do not have any user notes for the servo positioning controller, please contact your sales representative. Immediately demand these documents to be sent to the person responsible for the safe operation of the servo drive controller.



If you sell, rent and/or otherwise make this device available to others, these safety notes must also be included.



The user must not open the servo drive controller for safety and warranty reasons.



Professional control process design is a prerequisite for sound functioning of the servo drive controller!

**DANGER!**

Inappropriate handling of the servo drive controller and non-compliance of the warnings as well as inappropriate intervention in the safety features may result in property damage, personal injuries, electric shock or in extreme cases even death.

2.3 Danger resulting from misuse

**DANGER!**

High electrical voltages and high load currents!

Danger to life or serious personal injury from electrical shock!

**DANGER!**

High electrical voltage caused by wrong connections!

Danger to life or serious personal injury from electrical shock!

**DANGER!**

Surfaces of device housing may be hot!

Risk of injury! Risk of burning!

**DANGER!**

Dangerous movements!

Danger to life, serious personal injury or property damage due to unintentional movements of the motors!

2.4 Safety notes

2.4.1 General safety notes



The servo drive controller corresponds to IP20 class of protection as well as pollution level 1. Make sure that the environment corresponds to this class of protection and pollution level.



Only use replacements parts and accessories approved by the manufacturer.



The devices must be connected to the mains supply as per EN regulations, so that they can be cut off the mains supply by means of corresponding separation devices (e.g. main switch, contactor, power switch).



The servo drive controller may be protected using an AC/DC sensitive 300mA fault current protection switch (RCD = Residual Current protective Device).



Gold contacts or contacts with a high contact pressure should be used to switch the control contacts.



Preventive interference rejection measures should be taken for control panels, such as connecting contactors and relays using RC elements or diodes.



The safety rules and regulations of the country in which the device will be operated must be complied with.



The environment conditions defined in the product documentation must be kept. Safety-critical applications are not allowed, unless specifically approved by the manufacturer.



For notes on installation corresponding to EMC, please refer to Product Manual . The compliance with the limits required by national regulations is the responsibility of the manufacturer of the machine or system.



The technical data and the connection and installation conditions for the servo drive controller are to be found in this product manual and must be met.



DANGER!

The general setup and safety regulations for work on power installations (e.g. DIN, VDE, EN, IEC or other national and international regulations) must be complied with.

Non-compliance may result in death, personal injury or serious property damages.



Without claiming completeness, the following regulations and others apply:

VDE 0100 Regulations for the installation of high voltage (up to 1000 V) devices

EN 60204 Electrical equipment of machines

EN 50178 Electronic equipment for use in power installations

2.4.2 Safety notes for assembly and maintenance

The appropriate DIN, VDE, EN and IEC regulations as well as all national and local safety regulations and rules for the prevention of accidents apply for the assembly and maintenance of the system. The plant engineer or the operator is responsible for compliance with these regulations:



The servo drive controller must only be operated, maintained and/or repaired by personnel trained and qualified for working on or with electrical devices.



Prevention of accidents, injuries and/or damages:
Additionally secure vertical axes against falling down or lowering after the motor has been switched off, e.g. by means of:

- Mechanical locking of the vertical axle,
- External braking, catching or clamping devices or
- Sufficient balancing of the axle.



The motor holding brake supplied by default or an external motor holding brake driven by the drive controller alone is not suitable for personal protection!



Render the electrical equipment voltage-free using the main switch and protect it from being switched on again until the DC bus circuit is discharged, in the case of:

- Maintenance and repair work
- Cleaning
- long machine shutdowns



Prior to carrying out maintenance work make sure that the power supply has been turned off, locked and the DC bus circuit is discharged.



The external or internal brake resistor carries dangerous DC bus voltages during operation of the servo drive controller and up to 5 minutes thereafter. Contact may result in death or serious personal injury.



Be careful during the assembly. During the assembly and also later during operation of the drive, make sure to prevent drill chips, metal dust or assembly parts (screws, nuts, cable sections) from falling into the device.



Also make sure that the external power supply of the controller (24V) is switched off.



The DC bus circuit or the mains supply must always be switched off prior to switching off the 24V controller supply.



Carry out work in the machine area only, if AC and/or DC supplies are switched off. Switched off output stages or controller enabling are no suitable means of locking. In the case of a malfunction the drive may accidentally be put into action.



Initial operation must be carried out with idle motors, to prevent mechanical damages e.g. due to the wrong direction of rotation.



Electronic devices are never fail-safe. It is the user's responsibility, in the case an electrical device fails, to make sure the system is transferred into a secure state.



The servo drive controller and in particular the brake resistor, externally or internally, can assume high temperatures, which may cause serious burns.

2.4.3 Protection against contact with electrical parts

This section only concerns devices and drive components carrying voltages exceeding 50 V. Contact with parts carrying voltages of more than 50 V can be dangerous for people and may cause electrical shock. During operation of electrical devices some parts of these devices will inevitably carry dangerous voltages.



DANGER!

High electrical voltage!

Danger to life, danger due to electrical shock or serious personal injury!

The appropriate DIN, VDE, EN and IEC regulations as well as all national and local safety regulations and rules for the prevention of accidents apply for the assembly and maintenance of the system. The plant engineer or the operator is responsible for compliance with these regulations:



Before switching on the device, install the appropriate covers and protections against accidental contact. Rack-mounted devices must be protected against accidental contact by means of a housing, e.g. a switch cabinet. The regulations VBG 4 must be complied with!



Always connect the ground conductor of the electrical equipment and devices securely to the mains supply.
Due to the integrated line filter the leakage current exceeds 3.5 mA!



Comply with the minimum copper cross-section for the ground conductor over its entire length as per EN60617!



Prior to the initial operation, even for short measuring or testing purposes, always connect the ground conductor of all electrical devices as per the terminal diagram or connect it to the ground wire. Otherwise the housing may carry high voltages which can cause electrical shock.



Do not touch electrical connections of the components when switched on.



Prior to accessing electrical parts carrying voltages exceeding 50 Volts, disconnect the device from the mains or power supply. Protect it from being switched on again.



For the installation the amount of DC bus voltage must be considered, particularly regarding insulation and protective measures. Ensure proper grounding, wire dimensioning and corresponding short-circuit protection.



The device comprises a rapid discharge circuit for the DC bus as per EN60204 section 6.2.4. In certain device constellations, however, mostly in the case of parallel connection of several servo drive controllers in the DC bus or in the case of an unconnected brake resistor, this rapid discharge may be rendered ineffective. The servo drive controllers can carry voltage until up to 5 minutes after being switched off (residual capacitor charge).

2.4.4 Protection against electrical shock by means of protective extra-low voltage (PELV)

All connections and terminals with voltages between 5 and 50 Volts at the servo drive controller are protective extra-low voltage, which are designed safe from contact in correspondence with the following standards:

International: IEC 60364-4-41

European countries within the EU: EN 50178/1998, section 5.2.8.1.



DANGER!

High electrical voltages due to wrong connections!

Danger to life, risk of injury due to electrical shock!

Only devices and electrical components and wires with a protective extra low voltage (PELV) may be connected to connectors and terminals with voltages between 0 to 50 Volts.

Only connect voltages and circuits with protection against dangerous voltages. Such protection may be achieved by means of isolation transformers, safe optocouplers or battery operation.

2.4.5 Protection against dangerous movements

Dangerous movements can be caused by faulty control of connected motors, for different reasons:

- Improper or faulty wiring or cabling
- Error in handling of components
- Error in sensor or transducer
- Defective or non-EMC-compliant components
- Error in software in superordinated control system

These errors can occur directly after switching on the device or after an indeterminate time of operation.

The monitors in the drive components for the most part rule out malfunctions in the connected drives. In view of personal protection, particularly the danger of personal injury and/or property damage, this may not be relied on exclusively. Until the built-in monitors come into effect, faulty drive movements must be taken into account; their magnitude depends on the type of control and on the operating state.



DANGER!

Dangerous movements!

Danger to life, risk of injury, serious personal injuries or property damage!

For the reasons mentioned above, personal protection must be ensured by means of monitoring or superordinated measures on the device. These are installed in accordance with the specific data of the system and a danger and error analysis by the manufacturer. The safety regulations applying to the system are also taken into consideration. Random movements or other malfunctions may be caused by switching the safety installations off, by bypassing them or by not activating them.

2.4.6 Protection against contact with hot parts



DANGER!

Housing surfaces may be hot!

Risk of injury! Risk of burning!



Do not touch housing surfaces in the vicinity of heat sources! Danger of burning!



Before accessing devices let them cool down for 10 minutes after switching them off.



Touching hot parts of the equipment such as the housing, which contain heat sinks and resistors, may cause burns!

2.4.7 Protection during handling and assembly

Handling and assembly of certain parts and components in an unsuitable manner may under adverse conditions cause injuries.



DANGER!

Risk of injury due to improper handling!

Personal injury due to pinching, shearing, cutting, crushing!

The following general safety notes apply:



Comply with the general setup and safety regulations on handling and assembly.



Use suitable assembly and transportation devices.



Prevent incarcerations and contusions by means of suitable protective measures.



Use suitable tools only. If specified, use special tools.



Use lifting devices and tools appropriately.



If necessary, use suitable protective equipment (e.g. goggles, protective footwear, protective gloves).



Do not stand underneath hanging loads.



Remove leaking liquids on the floor immediately to prevent slipping.

3 Cabling and pin assignment

3.1 Pin assignment

At the the CAN interface is already integrated in the device and therefore always available.

According to the CANopen specification a 9-pin DSUB-plug (male) is integrated in the device.




Figure 3.1: CAN connector for

CAN bus cabling

 Please respect carefully the following information and notes for the cabling of the controller to get a stable and undisturbed communication system. A non professional cabling can cause malfunctions of the CAN bus which hence the controller to shutdown with an error.



120Ω Termination resistor

No termination resistor is integrated in the item servo positioning controller C 1-Series

3.2 Cabling hints

The CAN bus offers an easy and safe way to connect all parts of a plant. As condition all following instructions have to be respected carefully.




Figure 3.2: Cabling (schematically)

- All nodes of a network are principally connected in series, so that the CAN cable is looped through all controllers (see **Figure 3.2**).
- The two ends of the CAN cable have to be terminated by a resistor of $120\Omega \pm 5\%$. Please note that such a resistor is often already installed in CAN cards or the PLC.
- For cabling **shielded** cable with exactly two **twisted** pairs have to be used.

- One twisted pair is used for CAN-H and CAN-L.
- One twisted pair is used commonly for CAN-GND.
- The shield of the cable is connected to CAN-SHIELD at all nodes.

A table with technical data of suitable cables can be found at the end of this chapter. Recommended cables can be found in the product manual.


- We dissuade from using connectors in between the CAN bus line. If it is still necessary to use connectors, assure that the connection of the shield is done by using metallic cases.
- For less noise injection principally
 - Never place motorcables parallel to signalcables.
 - Use only motorcables specified by .
 - Shield and earth motorcables correctly.
- For further informations refer to the Controller Area Network protocol specification, Ver. 2.0, Robert Bosch GmbH, 1991.
- Technical data CAN bus cable:

2 twisted pairs, $d \geq 0,22 \text{ mm}^2$	loop resistance $< 0,2 \Omega/\text{m}$
shielded	char. impedance $100-120 \Omega$

4 Activation of CANopen

4.1 Survey

The activation of CANopen is done one-time using the serial interface of the servo controller. The CAN protocoll can be activated in the window “CANopen” of the TM.



There have to be set three different parameters:

- **Basic Node Number**

For unmistakable identification each user within the network has to have an unique node number. The node number is used to address the device.

As an option it is possible to calculate the node number dependent of the plug-in location of the device. Therefore once after reset the combination of digital inputs (DINO...DIN3) or analogue inputs AIN1 and AIN2 is added to the basic node number. AIN1 will be added with a valence of 32 and AIN2 with a valence of 64, if the particular input is connected to

$V_{ref} = 10V$.

- **Baudrate**

This parameter determines the used baudrate in kBaud. Please note that high baudrates can only be achieved with short cable length.

- **Options**

All CANopen nodes send a bootup message containing their own node number. If the servo positioning controller receives such a message containing its own node number, the error 12-0 will be raised.

Finally the CANopen protocoll can be activated. Please take into account that the parameters mentioned above can only be changed when the protocoll is deactivated.



Please note that the activation of CANopen will only be available after a reset if the parameter set has been saved.

5 Access methods

5.1 Survey

CANopen offers an easy and standardised way to access all parameters of the servo controller (e.g. the maximum current). To achieve a clear arrangement a unique index and subindex is assigned to every parameter (CAN object). The parameters altogether form the so called object dictionary.

The object dictionary can be accessed via CAN bus in primarily two ways: A confirmed access with so called SDOs and a unconfirmed access using so called PDOs with no hand-shake.





Figure 5.3: Access methods

As a rule the servo controller will be configured and controlled by SDOs. Additional types of messages (so called Communication Objects, COB) are defined for special applications. They will be sent either by the superimposed control or the servo controller:

SDO	Service Data Object	Used for normal parametrization of the servo controller
PDO	Process Data Object	Fast exchange of process data (e.g. velocity actual value) possible.
SYNC	Synchronization Message	Synchronisation of several CAN nodes.

EMCY	Emergency Message	Used to transmit error messages of the servo controller.
NMT	Network Management	Used for network services. For example the user can act on all controllers at the same time via this object type.
HEARTBEAT	Error Control Protocol	Used for observing all nodes by cyclic messages.

Every message sent via CAN bus contains an address to identify the node the message is meant for. This address is called Identifier. The lower the identifier, the higher the priority. Each communication object mentioned above has a specific identifier. The following figure shows the schematic structure of a CANopen message:



5.2 Access by SDO

The object dictionary can be accessed with **Service Data Objects** (SDO). This access is particularly easy and clear. Therefore it is recommended to base the application on SDOs first and later adapt some accesses to the certainly faster but more complicated **Process Data Objects** (PDOs).

SDO accesses always start from the superimposed control (host). The host sends a write request to change a parameter or a read request to get a parameter from the servo controller. Every request will be answered by the servo controller either sending the requested parameter or confirming the write request. Every command has to be sent with a definite identifier so that the servo controller knows what command is intended for it.

This identifier is composed of the base 600_h + node number of the corresponding servo controller. The servo controller answers with identifier 580_h + node number.


The structure of the writing and reading sequences depends on the data type as 1, 2 or 4 data bytes have to be sent or received. The following data types will be supported:

UINT8	8 bit value, unsigned	0 ... 255
INT8	8 bit value, signed	-128 ... 127
UINT16	16 bit value, unsigned	0 ... 65535

INT16	16 bit value, signed	-32768 ... 32767
UINT32	32 bit value, unsigned	0 ... (2^{32} -1)
INT32	32 bit value, signed	(- 2^{31}) ... (2^{31} -1)

5.2.1 SDO sequences to read or write parameters

Following sequences have to be used to read or write can objects of mentioned type. Commands to write a value into the servo controller start with a different token depending on the parameters data type, whereas the first token of the answer is always the same. For commands to read parameters it is vice versa: They always start with the same token, whereas the answer of the servo controller starts with a token depending on the parameters data type. For all numerical values the hexadecimal notation is used.



EXAMPLE

<p>UINT8 / INT8</p> <p>Reading of Obj. 6061_00_h</p> <p>Returning data: 01_h</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%;">Command:</td> <td style="width: 90%; text-align: center;">40_h 61_h 60_h 00_h</td> </tr> <tr> <td>Answer:</td> <td style="text-align: center;">4F_h 61_h 60_h 00_h 01_h</td> </tr> </table>	Command:	40_h 61_h 60_h 00_h	Answer:	4F_h 61_h 60_h 00_h 01_h	<p>Writing of Obj. 1401_02_h</p> <p>Data: EF_h</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%;">Command:</td> <td style="width: 90%; text-align: center;">2F_h 01_h 14_h 02_h EF_h</td> </tr> <tr> <td>Answer:</td> <td style="text-align: center;">60_h 01_h 14_h 02_h</td> </tr> </table>	Command:	2F_h 01_h 14_h 02_h EF_h	Answer:	60_h 01_h 14_h 02_h
Command:	40_h 61_h 60_h 00_h								
Answer:	4F_h 61_h 60_h 00_h 01_h								
Command:	2F_h 01_h 14_h 02_h EF_h								
Answer:	60_h 01_h 14_h 02_h								
<p>UINT16 / INT16</p> <p>Reading of Obj. 6041_00_h</p> <p>Returning data: 1234_h</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%;">Command:</td> <td style="width: 90%; text-align: center;">40_h 41_h 60_h 00_h</td> </tr> <tr> <td>Answer:</td> <td style="text-align: center;">2B_h 40_h 60_h 00_h E8_h 03_h</td> </tr> </table>	Command:	40_h 41_h 60_h 00_h	Answer:	2B_h 40_h 60_h 00_h E8_h 03_h	<p>Writing of Obj. 6040_00_h</p> <p>Data: 03E8_h</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%;">Command:</td> <td style="width: 90%; text-align: center;">2B_h 40_h 60_h 00_h E8_h 03_h</td> </tr> <tr> <td>Answer:</td> <td style="text-align: center;">60_h 01_h 14_h 02_h</td> </tr> </table>	Command:	2B_h 40_h 60_h 00_h E8_h 03_h	Answer:	60_h 01_h 14_h 02_h
Command:	40_h 41_h 60_h 00_h								
Answer:	2B_h 40_h 60_h 00_h E8_h 03_h								
Command:	2B_h 40_h 60_h 00_h E8_h 03_h								
Answer:	60_h 01_h 14_h 02_h								



Answer:	4B _h 41 _h 60 _h 00 _h 34 _h 12 _h	60 _h 40 _h 60 _h 00 _h
UINT32 / INT32	Reading of Obj. 6093_01 _h Returning data: 12345678 _h	Writing of Obj. 6093_01 _h Data: 12345678 _h
Command:	40 _h 93 _h 60 _h 01 _h	23 _h 93 _h 60 _h 01 _h 78 _h 56 _h 34 _h 12 _h
Answer:	43 _h 93 _h 60 _h 01 _h 78 _h 56 _h 34 _h 12 _h	60 _h 93 _h 60 _h 01 _h




Always wait for the acknowledge of the controller!

Only if a request has been acknowledged by the controller it is allowed to send the next request.

5.2.2 SDO-error messages

If an error occurs while reading or writing an object (e.g. because the value is out of range) the servo controller answers with an error message instead of the normal answer:



Error code	Description
F3 F2 F1 F0	
05 03 00 00 _h	Toggle bit not alternated
05 04 00 01 _h	Client / server command specifier not valid or unknown
06 01 00 00 _h	Unsupported access to an object
06 01 00 01 _h	Attempt to read a write only object
06 01 00 02 _h	Attempt to write a read only object
06 02 00 00 _h	Object does not exist in the object dictionary
06 04 00 41 _h	Object cannot be mapped to the PDO
06 04 00 42 _h	The number and length of the objects to be mapped would exceed PDO length
06 04 00 47 _h	General internal incompatibility in the device
06 07 00 10 _h	Data type does not match, length of service parameter does not match
06 07 00 12 _h	Data type does not match, length of service parameter too high
06 07 00 13 _h	Data type does not match, length of service parameter too low
06 09 00 11 _h	Sub-index does not exist
06 04 00 43 _h	General parameter incompatibility
06 06 00 00 _h	Access failed due to an hardware error ^{*1)}
06 09 00 30 _h	Value range of parameter exceeded
06 09 00 31 _h	Value of parameter written too high
06 09 00 32 _h	Value of parameter written too low
06 09 00 36 _h	Maximum value is less than minimum value
08 00 00 20 _h	Data cannot be transferred or stored to the application ^{*1)}
08 00 00 21 _h	Data cannot be transferred or stored to the application because of local control
08 00 00 22 _h	Data cannot be transferred or stored to the application because of the present device state ^{*3)}

Error code	Description
F3 F2 F1 F0	
08 00 00 23h	No Object Dictionary is present ^{*2)}

^{*1)} According to DS301 used on invalid access to store_parameters / restore_parameters


^{*2)} This abort codes signals that another fieldbus controls the servo or the access to the parameter is not allowed.


^{*3)} “Device State” is used generally: This can be a wrong mode of operation as well as a missing technology module.

5.2.3 Simulation of SDO accesses via RS232

The firmware of the servo controller offers the option to simulate SDO accesses via the serial port. Consequently it is possible to check objects written to the controller via CAN bus by using the serial port. Particularly using the transfer window of TM (see **File | Transfer**) will simplify the building of applications.


The following syntax has to be used:





¹⁾ The answer is build similarly for each 3 commands (8, 16, 32 Bit).

Please note that the commands are composed out of chars without spaces.



5.3 PDO-Message

Process Data Objects (PDOs) are suitable to transmit data event-controlled, whereas the PDO contains one or more predefined parameters. In contrast to SDOs no hand-shake is used. So the receiver has to be able to handle an arriving PDO at any time. In most cases this requires a great deal of software in the host computer. This disadvantage is in contrast to the advantage that the host computer does not need cyclically inquiry of the objects embedded in a PDO, which means a strong reduction of bus load.

EXAMPLE



The host computer wants to know when the servo controller has reached the target position from A to B.

If SDOs are used the host constantly has to poll the object **statusword**, e.g. every millisecond, thus loading the bus capacity more or less depending on the request cycle time.

If PDOs are used the servo controller is configured at the start of an application in such a way that a PDO including the **statusword** is sent on each modification of the **statusword**.

So the host computer does not need to poll the statusword all the time. Instead a message is send to the host automatically if the specified event occurs.

Following types of PDOs can be differenced:


Transmit-PDO (T-PDO) Servo → Host Servo controller sends PDO if a certain event occurs

Receive-PDO (R-PDO) Host → Servo Servo controller evaluates PDO if a certain event occurs

The servo controller disposes of four Transmit- and four Receive-PDOs.

Almost all parameters can be embedded (mapped) into a PDO, i.e. the PDO is for example composed of the velocity actual value, the position actual value or the like.

Before a PDO can be used the servo controller has to know, what data shall be transmitted, because a PDO only contains useful data and no information about the kind of parameter. In the following example the PDO contains the position actual value in the data byte D0...D3 and the velocity actual value in the data bytes D4...D7.



Almost any desired data frame can be built this way. The following chapter shows how to parametrize the servo controller for that purpose:

5.3.1 Description of objects

Identifier of PDOs

COB_ID_used_by_PDO

In the object **COB_ID_used_by_PDO** the desired identifier has to be entered. The PDO will be sent with this identifier. If bit 31 is set the associated PDO will be deactivated. This is the default setting.

It is prohibited to change the COB-ID if the PDO is not deactivated (= bit 31 set). Therefore a different identifier as the current one may only be written, if bit 31 is set.

A set bit 30 at reading the identifier indicates that it is not possible to request a PDO by a remote frame. This bit will be ignored at writing and is always set at reading.

Number of objects to be transmitted

number_of_mapped_objects

The object determines how many objects are mapped into the specific PDO. Following restrictions has to be respected:

- A maximum of 4 objects can be mapped into a PDO.
- The total length of a PDO must not exceed 64 bit.


Objects to be transmitted

first_mapped_object ... fourth_mapped_object

The host has to parametrize the index, the subindex and the length of each object that should be transmitted by the PDO. The length has to match with the length stored in the Object Dictionary.

Parts of an object cannot be mapped.

The following format has to be used:



To simplify the mapping the following sequence has to be used:

- 1.) The **number_of_mapped_objects** is set to 0.
- 2.) The parameter **first_mapped_object...fourth_mapped_object** can be parameterised (The length of all objects will not be considered at this time).
- 3.) The **number_of_mapped_objects** is set to a value between 1...4: The

length of all mapped objects may not exceed 64 bit now.

Transmission type

transmission_type und inhibit_time

For each PDO it can be configured which event results in sending (Transmit-PDO) resp. evaluating (Receive-PDO) the PDO:

Value	Description	Allowed with
01 _h - F0 _h	SYNC message The value determines how many SYNC messages have to be received before the PDO will be - sent (T-PDO) resp. - evaluated (R-PDO).	TPDOS RPDOS
FE _h	Cyclic A Transfer-PDO will be updated and sent cyclic. The period is determined by the object inhibit_time . Receive-PDOs will be evaluated immediately after receipt.	TPDOS (RPDOS)
FF _h	On change The Transfer-PDO will be sent, if at least one bit of the PDO data has changed. Therefore the object inhibit_time determines the minimal period between two PDOs in multiples of 100µs.	TPDOS

The use of any other value for this parameter is inhibited.

Mask

transmit_mask_high and transmit_mask_low

Using the **transmission_type** "On change" the PDO will always be sent if at least one bit has changed. Sometimes it is useful to send the PDO only if a defined bit has changed. Therefore it is possible to mask the PDO. Thereby only PDO bits with an "1" in the corresponding bit of the mask will take effect to determine if the PDO has changed. This function is manufacturer specific and deactivated by default, i.e. all bits of the mask are set by default.

EXAMPLE



Following objects should be transmitted in a PDO:

Name of the object	Index_subindex	Meaning
statusword	6041h_00h	Device Control
modes_of_operation_display	6061h_00h	Operating mode
digital_inputs	60FDh_00h	Digital inputs

The 1st Transmit-PDO (TPDO 1) should be used and should always be sent if a digital input changes but with a minimum repetition time of 10 ms. The PDO should use identifier 187h.

1.) Deactivate a PDO

If the PDO is active, it must be deactivated at first.

Write identifier with set bit 31 (PDO will be deactivated) $\Rightarrow \text{cob_id_used_by_pdo} = \text{C}0000187\text{h}$

2.) Set number of mapped objects to 0

To enable the mapping, the number of mapped objects has to be zero.

$\Rightarrow \text{number_of_mapped_objects} = 0$

3.) Parametrize objects to be mapped:

The above mentioned objects have to be assembled to a 32 bit value:

Index = 6041h	Subin. = 00h	Length = 10h	$\Rightarrow \text{first_mapped_object} = 60410010h$
Index = 6061h	Subin. = 00h	Length = 08h	$\Rightarrow \text{second_mapped_object} = 60610008h$
Index = 60FDh	Subin. = 00h	Length = 20h	$\Rightarrow \text{third_mapped_object} = 60FD0020h$

4.) Set number of mapped objects:

The PDO contains 3 objects $\Rightarrow \text{number_of_mapped_objects} = 3h$

5.) Parametrize transmission type

The PDO should be sent if a digital input changes. $\Rightarrow \text{transmission_type} = FFh$

The PDO have to be masked in order to restrict the condition for a transmission of the PDO to a change of the digital inputs. $\Rightarrow \text{transmit_mask_high} = 00FFFF00h$

$\Rightarrow \text{transmit_mask_low} = 00000000h$

The PDO should be sent at most every 10 ms (100×100µs). $\Rightarrow \text{inhibit_time} = 64h$

6.) Parametrize the identifier

The PDO should be transmitted with the identifier 187h.

Writing the new identifier and activating the PDO by resetting bit 31: $\Rightarrow \text{cob_id_used_by_pdo} = 40000187h$



Please note that it is only allowed to change the settings of the PDOs if the Network state (NMT) is not **operational**. See also chapter 5.6.

5.3.2 Objects for parameterising PDOs

The servo positioning controller of the contain 4 Transmit- and 4 Receive-PDOs. The objects for parameterising these PDOs are equal for each 4 TPDOs and each 4 RPDOs. Therefore only the description for the first TPDO is stated below. It can be taken analogous for all the other PDOs, listed in a table thereafter.

Index	1800_h
Name	transmit_pdo_parameter_tpdo1
Object Code	RECORD
No. of Elements	3

Sub-Index	01_h
Description	cob_id_used_by_pdo_tpdo1
Data Type	UINT32
Access	rW
PDO Mapping	no
Units	-
Value Range	181 _h ...1FF _h , Bit 31 may be set
Default Value	C0000181 _h

Sub-Index	02_h
Description	transmission_type_tpdo1
Data Type	UINT8
Access	rW
PDO Mapping	no
Units	-
Value Range	0...8C _h , FE _h , FF _h
Default Value	FF _h

Sub-Index	03_h
Description	inhibit_time_tpdo1
Data Type	UINT16
Access	rW
PDO Mapping	no
Units	100µs (i.e. 10 = 1ms)
Value Range	-

Default Value	0
---------------	---

Index	1A00_h
Name	transmit_pdo_mapping_tpdo1
Object Code	RECORD
No. of Elements	2

Sub-Index	00_h
Description	number_of_mapped_objects_tpdo1
Data Type	UINT8
Access	rw
PDO Mapping	no
Units	-
Value Range	0...4
Default Value	0

Sub-Index	01_h
Description	first_mapped_object_tpdo1
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	-
Value Range	-
Default Value	see Table

Sub-Index	02_h
Description	second_mapped_object_tpdo1
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	-
Value Range	-
Default Value	see Table

Sub-Index	03_h
Description	third_mapped_object_tpdo1
Data Type	UINT32
Access	rw
PDO Mapping	no

Units	-
Value Range	-
Default Value	see Table

Sub-Index	04 _h
Description	fourth_mapped_object_tpdo1
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	-
Value Range	-
Default Value	see Table



Please note that the object records `transmit_pdo_parameter_xxx` and `transmit_pdo_mapping_xxx` can only be written, if the PDO is deactivated (Bit 31 in `cob_id_used_by_pdo_xxx` is set)

1. Transmit-PDO

Index	Comment	Type	Acc.	Default Value
1800 _h _00 _h	number of entries	UINT8	ro	03 _h
1800 _h _01 _h	COB-ID used by PDO	UINT32	rw	C0000181 _h
1800 _h _02 _h	transmission type	UINT8	rw	FF _h
1800 _h _03 _h	inhibit time (100 µs)	UINT16	rw	0000 _h
1A00 _h _00 _h	number of mapped objects	UINT8	rw	01 _h
1A00 _h _01 _h	first mapped object	UINT32	rw	60410010 _h
1A00 _h _02 _h	second mapped object	UINT32	rw	00000000 _h
1A00 _h _03 _h	third mapped object	UINT32	rw	00000000 _h
1A00 _h _04 _h	fourth mapped object	UINT32	rw	00000000 _h

2. Transmit-PDO

Index	Comment	Type	Acc.	Default Value
1801 _h _00 _h	number of entries	UINT8	ro	03 _h
1801 _h _01 _h	COB-ID used by PDO	UINT32	rw	C0000281 _h
1801 _h _02 _h	transmission type	UINT8	rw	FF _h
1801 _h _03 _h	inhibit time (100 µs)	UINT16	rw	0000 _h
1A01 _h _00 _h	number of mapped objects	UINT8	rw	02 _h
1A01 _h _01 _h	first mapped object	UINT32	rw	60410010 _h
1A01 _h _02 _h	second mapped object	UINT32	rw	60610008 _h
1A01 _h _03 _h	third mapped object	UINT32	rw	00000000 _h

1A01_h_04_h	fourth mapped object	UINT32	rw	00000000_h
-------------	----------------------	--------	----	------------

3. Transmit-PDO

Index	Comment	Type	Acc.	Default Value
1802_h_00_h	number of entries	UINT8	ro	03_h
1802_h_01_h	COB-ID used by PDO	UINT32	rw	C0000381_h
1802_h_02_h	transmission type	UINT8	rw	FF_h
1802_h_03_h	inhibit time (100 µs)	UINT16	rw	0000_h
1A02_h_00_h	number of mapped objects	UINT8	rw	02_h
1A02_h_01_h	first mapped object	UINT32	rw	60410010_h
1A02_h_02_h	second mapped object	UINT32	rw	60640020_h
1A02_h_03_h	third mapped object	UINT32	rw	00000000_h
1A02_h_04_h	fourth mapped object	UINT32	rw	00000000_h

4. Transmit-PDO

Index	Comment	Type	Acc.	Default Value
1803_h_00_h	number of entries	UINT8	ro	03_h
1803_h_01_h	COB-ID used by PDO	UINT32	rw	C0000481_h
1803_h_02_h	transmission type	UINT8	rw	FF_h
1803_h_03_h	inhibit time (100 µs)	UINT16	rw	0000_h
1A03_h_00_h	number of mapped objects	UINT8	rw	02_h
1A03_h_01_h	first mapped object	UINT32	rw	60410010_h
1A03_h_02_h	second mapped object	UINT32	rw	606C0020_h
1A03_h_03_h	third mapped object	UINT32	rw	00000000_h
1A03_h_04_h	fourth mapped object	UINT32	rw	00000000_h

tpdo_1_transmit_mask

Index	Comment	Type	Acc.	Default Value
2014_h_00_h	number of entries	UINT8	ro	02_h
2014_h_01_h	tpdo_1_transmit_mask_low	UINT32	rw	FFFFFFFF_h
2014_h_02_h	tpdo_1_transmit_mask_high	UINT32	rw	FFFFFFFF_h

tpdo_2_transmit_mask

Index	Comment	Type	Acc.	Default Value
2015_h_00_h	number of entries	UINT8	ro	02_h
2015_h_01_h	tpdo_2_transmit_mask_low	UINT32	rw	FFFFFFFF_h
2015_h_02_h	tpdo_2_transmit_mask_high	UINT32	rw	FFFFFFFF_h

tpdo_3_transmit_mask

Index	Comment	Type	Acc.	Default Value
2016h_00h	number of entries	UINT8	ro	02h
2016h_01h	tpdo_3_transmit_mask_low	UINT32	rw	FFFFFFFh
2016h_02h	tpdo_3_transmit_mask_high	UINT32	rw	FFFFFFFh

tpdo_4_transmit_mask

Index	Comment	Type	Acc.	Default Value
2017h_00h	number of entries	UINT8	ro	02h
2017h_01h	tpdo_4_transmit_mask_low	UINT32	rw	FFFFFFFh
2017h_02h	tpdo_4_transmit_mask_high	UINT32	rw	FFFFFFFh

1. Receive PDO

Index	Comment	Type	Acc.	Default Value
1400 _h _00 _h	number of entries	UINT8	ro	02 _h
1400 _h _01 _h	COB-ID used by PDO	UINT32	rw	C0000201 _h
1400 _h _02 _h	transmission type	UINT8	rw	FF _h
1600 _h _00 _h	number of mapped objects	UINT8	rw	01 _h
1600 _h _01 _h	first mapped object	UINT32	rw	60400010 _h
1600 _h _02 _h	second mapped object	UINT32	rw	00000000 _h
1600 _h _03 _h	third mapped object	UINT32	rw	00000000 _h
1600 _h _04 _h	fourth mapped object	UINT32	rw	00000000 _h

2. Receive PDO

Index	Comment	Type	Acc.	Default Value
1401 _h _00 _h	number of entries	UINT8	ro	02 _h
1401 _h _01 _h	COB-ID used by PDO	UINT32	rw	C0000301 _h
1401 _h _02 _h	transmission type	UINT8	rw	FF _h
1601 _h _00 _h	number of mapped objects	UINT8	rw	02 _h
1601 _h _01 _h	first mapped object	UINT32	rw	60400010 _h
1601 _h _02 _h	second mapped object	UINT32	rw	60600008 _h
1601 _h _03 _h	third mapped object	UINT32	rw	00000000 _h
1601 _h _04 _h	fourth mapped object	UINT32	rw	00000000 _h

3. Receive PDO

Index	Comment	Type	Acc.	Default Value
1402 _h _00 _h	number of entries	UINT8	ro	02 _h
1402 _h _01 _h	COB-ID used by PDO	UINT32	rw	C0000401 _h
1402 _h _02 _h	transmission type	UINT8	rw	FF _h
1602 _h _00 _h	number of mapped objects	UINT8	rw	02 _h
1602 _h _01 _h	first mapped object	UINT32	rw	60400010 _h
1602 _h _02 _h	second mapped object	UINT32	rw	607A0020 _h
1602 _h _03 _h	third mapped object	UINT32	rw	00000000 _h
1602 _h _04 _h	fourth mapped object	UINT32	rw	00000000 _h

4. Receive PDO

Index	Comment	Type	Acc.	Default Value
1403 _h _00 _h	number of entries	UINT8	ro	02 _h
1403 _h _01 _h	COB-ID used by PDO	UINT32	rw	C0000501 _h
1403 _h _02 _h	transmission type	UINT8	rw	FF _h
1603 _h _00 _h	number of mapped objects	UINT8	rw	02 _h
1603 _h _01 _h	first mapped object	UINT32	rw	60400010 _h

1603 _h _02 _h	second mapped object	UINT32	rw	60FF0020 _h
1603 _h _03 _h	third mapped object	UINT32	rw	00000000 _h
1603 _h _04 _h	fourth mapped object	UINT32	rw	00000000 _h

5.3.3 Activation of PDOs

The following points have to be fulfilled for the activation of a PDO:


- The object **number_of_mapped_objects** has to be different from zero
- The bit 32 has to be deleted in the object **cob_id_used_for_pdos**
- The communication status of the servo has to be **operational** (see chapter 5.6, Network management)

The following points have to be fulfilled to parametrize a PDO

- The communication status of the servo must not be **operational**

5.4 SYNC-Message

Several devices of a plant can be synchronised with each other. To that purpose one of the devices (in most cases the superimposed control) periodically sends synchronisation messages. All connected servo controllers receive these messages and use them for the treatment of the PDOs (see chapter 5.3).



The identifier on which the servo controller receives SYNC messages is fixed to 080_h . The identifier can be read via the object `cob_id_sync`.

Index	1005_h
Name	<code>cob_id_sync</code>
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	no
Units	-
Value Range	80000080_h , 00000080_h
Default Value	00000080_h


5.5 EMERGENCY-Message

The servo controller monitors the functions of its essential units. The power supply, the power stage, the angle encoder input, and the technology module belong to these units. Besides this the motor (temperature, angle encoder) and the limit switches are constantly controlled. Bad parameters could also result in error messages (division by zero etc.).

If an error occurs, the error number is displayed by the servo controller. If several error messages occur at the same time the message which has the highest priority (the least number) is displayed.

5.5.1 Survey

If an error occurs or an error-reset has been carried out the servo controller sends an EMERGENCY message. The identifier of this message is 80_h plus node number.




After Reset the state of the servo controller will be *Error free* (if there is an error right from the start, it immediately moves to *Error occurred*). The following state transitions are possible:

No.	Cause	Meaning
0	Initialisation completed	
1	Error occurs	No error was present and a new error occurs: An EMERGENCY- Telegram with the error code of the newly occurred error will be sent.
2	Error-reset	An error-reset (see Chap. 7.1.3.1) will be executed, but not all error reasons are removed.
3	Error occurs	An error was still present and yet another error occurs: An EMERGENCY- Telegram with the error code of the newly occurred error will be sent.
4	Error-reset	An error-reset will be executed and all error reasons are removed. An EMERGENCY- Telegram with the error code 0000 will be sent.

5.5.2 Structure of an EMERGENCY message

The EMERGENCY message consists of eight data bytes with the **error code** in the first two bytes. These **error_codes** are described in the following table. There is a further error code (object 1001_h) in the third byte. The other five bytes contain zeros.



The following **error_codes** can occur

error_code (hex)	Anzeige	Bedeutung
0000	-	Error free
6180	E 01 0	Stack overflow
3220	E 02 0	Undervoltage of DC-bus
4310	E 03 x	Overtemperature motor
4210	E 04 0	Overtemperature of the power stage
4280	E 04 1	Overtemperature in the DC-bus
5114	E 05 0	Internal undervoltage supply 1
5115	E 05 1	Internal undervoltage supply 2
5116	E 05 2	Driver voltage fault
5410	E 05 3	Undervoltage dig. I/O
5410	E 05 4	Overcurrent dig. I/O
2320	E 06 x	Short circuit in the power stage
3210	E 07 0	Oversupply
7380	E 08 0	Angle encoder error resolver
7382	E 08 2	Error of track signals Z0 incremental encoder
7383	E 08 3	Error of track signals Z1 incremental encoder
7384	E 08 4	Error of track signals of digital incremental encoder
7385	E 08 5	Error of Hall signals of incremental encoder
7386	E 08 6	Communication error angle encoder
7387	E 08 7	Signal amplitude: erroneous incremental track
7388	E 08 8	Internal angle encoder error
7389	E 08 9	Angle encoder on X2B is not supported
73A1	E 09 0	Angle encoder parameter set: type item C Series
73A2	E 09 1	Angle encoder parameter set cannot be decoded
73A3	E 09 2	Angle encoder parameter set: unknown version
73A4	E 09 3	Angle encoder parameter set: a damaged data structure
73A5	E 09 7	EEPROM angle encoder is read-only
73A6	E 09 9	EEPROM angle encoder is too small
8A80	E 11 0	Error at start of homing run
8A81	E 11 1	Error during homing run
8A82	E 11 2	Homing: Erroneous index pulse
8A83	E 11 3	Homing: timeout
8A84	E 11 4	Homing: wrong / invalid limit switch
8A85	E 11 5	Homing: I^2t / following error
8A86	E 11 6	Homing: end of the homing distance
8180	E 12 0	CAN bus: Duplicate node number
8120	E 12 1	CAN bus: Communication error: BUS OFF
8181	E 12 2	CAN bus: Communication error: Transmit error
8182	E 12 3	CAN bus: Communication error: Receive error
6185	E 15 0	Division by 0
6186	E 15 1	Range overflow
6181	E 16 0	Erroneous program execution
6182	E 16 1	Illegal interrupt
6187	E 16 2	Initialisation error
6183	E 16 3	Unexpected state
8611	E 17 x	Max. following error exceeded
5280	E 21 1	Error 1 current measurement U
5281	E 21 1	Error 1 current measurement V
5282	E 21 2	Error 2 current measurement U
5283	E 21 3	Error 2 current measurement V
6080	E 25 0	Invalid device type
6081	E 25 1	Device type is not supported
6082	E 25 2	HW revision is not supported
6083	E 25 3	Limited device function

error_code (hex)	Anzeige	Bedeutung
5580	E 26 0	Missing user parameter set
5581	E 26 1	Checksum error
5582	E 26 2	Flash: Error during write operation
5583	E 26 3	Flash: Error during read operation
5584	E 26 4	Flash: Error in internal flash
5585	E 26 5	Missing calibration data
5586	E 26 6	Missing user parameter sets
8611	E 27 0	Following error warning level
FF01	E 28 0	Counter hours of operation is missing
FF02	E 28 1	Counter hours of operation: write error
FF03	E 28 2	Counter hours of operation corrected
FF04	E 28 3	Counter hours of operation converted
6380	E 30 0	Internal conversion error
2312	E 31 0	I ² T – motor
2311	E 31 1	I ² T – servo controller
2313	E 31 2	I ² T – PFC
2314	E 31 3	I ² T – brake chopper
3280	E 32 0	Loading period DC-bus exceeded
3281	E 32 1	Undervoltage for active PFC
3282	E 32 5	Brake chopper overload
3283	E 32 6	Discharging period DC-bus exceeded
3284	E 32 7	Missing power supply for controller enable
3285	E 32 8	Power supply failure at controller enable
3286	E 32 9	Phase failure
8A87	E 33 0	Following error encoder emulation
8780	E 34 0	No synchronization via fieldbus
8781	E 34 1	Synchronization error fieldbus
8480	E 35 0	Overspeed protection linear motor
6320	E 36 x	Parameter has been limited
8612	E 40 x	SW limit switch
8680	E 42 0	Positioning: Drive stopped. Missing following position.
8681	E 42 1	Positioning: Drive stopped. Inversion of the direction is not allowed.
8682	E 42 2	Positioning: Inversion of the direction is not allowed after "Halt"
8081	E 43 0	Limit switch: Negative set point inhibited
8082	E 43 1	Limit switch: Positive set point inhibited
8083	E 43 2	Limit switch: Positioning suppressed
8084	E 45 0	Drivers supply cannot be switched off.
8085	E 45 1	Drivers supply cannot be activated.
8086	E 45 2	Drivers supply has been activated.
7580	E 60 0	Ethernet I
7581	E 61 0	Ethernet II
F080	E 80 0	Overflow current controller - IRQ
F081	E 80 1	Overflow speed controller - IRQ
F082	E 80 2	Overflow positioning controller - IRQ
F083	E 80 3	Overflow interpolator- IRQ
F084	E 81 4	Overflow low-level - IRQ
F085	E 81 5	Overflow MDC-IRQ
5080	E 90 x	Hardware error
6000	E 91 0	Internal initialisation error

5.5.3 Description of Objects

5.5.3.1 Object 1003_h: pre_defined_error_field

The **error_codes** of the error messages are recorded in a four-stage error memory. This memory is structured like a shift register so that always the last error is stored in the object 1003_h_01_h (**standard_error_field_0**). By a read access to the object 1003_h_00_h (**pre_defined_error_field**) you can find out how many error messages are recorded in the error memory at the moment. The error memory is deleted by writing the value 00_h into the object 1003_h_00_h (**pre_defined_error_field**). In addition an **error reset** (see chapter 7.1: state transition 15) has to be executed to reactivate the power stage of the servo controller after an error.

Index	1003_h
Name	pre_defined_error_field
Object Code	ARRAY
No. of Elements	4
Data Type	UINT32

Sub-Index	01_h
Description	standard_error_field_0
Access	ro
PDO Mapping	no
Units	--
Value Range	--
Default Value	--

Sub-Index	02_h
Description	standard_error_field_1
Access	ro
PDO Mapping	no
Units	--
Value Range	--
Default Value	--

Sub-Index	03_h
Description	standard_error_field_2
Access	ro
PDO Mapping	no
Units	--
Value Range	--
Default Value	--


Sub-Index	04_h
Description	standard_error_field_3
Access	ro
PDO Mapping	no
Units	--
Value Range	--
Default Value	--

5.6 Network management (NMT service)


All CANopen devices can be triggered via the network management. A special identifier (000h) is reserved for that.

Commands can be sent to one or all servo controller via this identifier. Each command consists of two bytes. The first byte contains the command code and the second byte the node address of the addressed servo controller. All nodes which are in the network can be addressed via the node address zero simultaneously. So it is possible, for example, to make a reset in all devices at the same time. The servo controller does not quit the NMT-commands. It is only indirectly possible to decide if a reset was successful (e. g. through the Bootup message after a reset).

Structure of the message:



The NMT states of a CANopen device are determined in a state diagram. With the byte **CS** of the NMT message state transitions can be initiated. They are mostly determined by the target state.



13	Reset Application	81 _h	Reset Application * ¹⁾
14	Reset Application	81 _h	Reset Application * ¹⁾

*¹⁾ The final target state is **Pre-Operational** (7F_h), because the transitions 15, 16 and 2 are done automatically by the controller.

Figure 5.4: NMT-State machine

With the following commands the NMT state can be changed:

CS	Meaning	Transition	Target state
01 _h	Start Remote Node	3, 6	Operational (05 _h)
02 _h	Stop Remote Node	5, 8	Stopped (04 _h)
80 _h	Enter Pre-Operational	4, 7	Pre-Operational (7F _h)
81 _h	Reset Application	12, 13, 14	Reset Application * ¹⁾
82 _h	Reset Communication	9, 10, 11	Reset Communication * ¹⁾

All remaining transitions will be executed automatically by the servo controller, e.g. if initialising has been finished.

The parameter **NI** contains the node number of the servo controller or zero, if all nodes within the network will be addressed. Depending on the NMT state several communication objects can not be used. For example it is necessary to set the NMT state to **operational** to enable sending and receiving PDOs.

Name	Meaning	SDO	PDO	NMT
Reset Application	No communication. All CAN objects are set to their reset values (application parameter set).	-	-	-
Reset Communication	No communication. The CAN controller will be re-initialised.	-	-	-
Initialising	State after Hardware Reset. Reset of the CAN node, sending of the Bootup message	-	-	-
Pre-Operational	Communication via SDOs possible. PDOs inactive (No sending / receiving)	X	-	X
Operational	Communication via SDOs possible. PDOs active (sending / receiving)	X	X	X
Stopped	No communication except heartbeat + NMT	-	-	X



NMT telegrams should not be sent in a burst (back-to-back).
The double cycle time of the position controller must be present between two back-to-back NMT messages on the bus (also for several nodes!), so that the controller can correctly process the

NMT messages.



The NMT command „Reset Application“ will be delayed while a save process to the flash (save_all_parameters) is running, as otherwise the save process may be uncompleted leading to a faulty parameter set.

The delay can last several seconds.



The communication status has to be set to **operational** to allow the servo to send and receive PDOs


5.7 Bootup (Error Control Protocol)

5.7.1 Survey

After power-on or after reset, the servo positioning controller reports through a Bootup message that the initialising has been finished. The servo is afterwards in the NMT state **preoperational** (see Chapter 5.6, Network management)

5.7.2 Structure of the Bootup message

The Bootup message is nearly identical with the following Heartbeat message. Only instead of the NMT state zero will be sent.




5.8 Heartbeat (Error Control Protocol)

5.8.1 Survey

To monitor the communication between slave (servo) and master the Heartbeat protocol is implemented. The servo cyclically sends a message to the master. The master can check if it cyclically receives the Heartbeat and initiate appropriate reactions if not. As the Heartbeat telegram as well as the Nodeguarding telegram use identifier **700h + node number** it is not possible to use both simultaneously. If both protocols are active simultaneously only Heartbeat will be available.

5.8.2 Structure of the Heartbeat message

The Heartbeat message will be sent with identifier **700_h** + node number. It is only composed of 1 Byte, containing the NMT state of the servo (see Chapter 5.6, Network management).



N	Description
04 _h	Stopped
05 _h	Operational
7F _h	Pre-Operational

5.8.3 Objects

5.8.3.1 Object 1017_h: producer_heartbeat_time

The time between two Heartbeat messages can be determined by the object **producer_heartbeat_time**.

Index	1017 _h
Name	producer_heartbeat_time
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	no
Units	ms
Value Range	0...65535
Default Value	0

The **producer_heartbeat_time** can be saved in the parameter set. If the servo starts with a **producer_heartbeat_time** unequal zero, the Bootup message is seen as the first heartbeat.

The controller can be used only as so-called Heartbeat Producer. Thus the object 1016_h (`consumer_heartbeat_time`) is implemented only because of compatibility reasons and always returns 0.

5.9 Nodeguarding (Error Control Protocol)

5.9.1 Survey


Nodeguarding can be used as well as the Heartbeat protocol to monitor the communication between Slave (servo controller) and Master. In opposite to the Heartbeat protocol it is possible that master and slave monitors each other:

The master asks the slave cyclically for its NMT state. In each answer of the slave one special bit will be toggled. If the slave doesn't answer or the toggle bit doesn't change, the master can react appropriate. In the same way the slave monitors the master: If no Nodeguarding request arrives within a definite period of time, error 12-4 will be raised.


As the Nodeguarding telegram as well as the Heartbeat telegram use identifier **700_h + node number** it is not possible to use both simultaneously. If both protocols are active simultaneously only Heartbeat will be available. Nodeguarding will be available as of firmware 3.5.x.1.1.

5.9.2 Structure of the Nodeguarding message

The request of the master has to be sent by a Remoteframe with Identifier **700_h + node number**. A Remoteframe is a special CAN telegram where the remote bit is set. Remoteframes in principle have no data bytes.



The response of the slave is similar to the Heartbeat message. It is also composed of just 1 Byte, containing the toggle bit and the NMT state of the servo (see Chapter 5.6, Network management).



The first data byte (T/N) is composed as follows:

Bit	Value	Name	Meaning
7	80 _h	toggle_bit	Changes with every response
0...6	7F _h	nmt_state	04 _h Stopped 05 _h Operational 7F _h Pre- Operational

The guarding time (monitoring time) can be configured. The slave starts monitoring with the first received Remoteframe from the master. From this time all Remoteframes have to arrive before the expiration of the guard time, as otherwise error 12-4 will occur.

The toggle bit will be deleted by the NMT command **Reset Communication**. Therefore it is reset in the first response of the servo controller.

5.9.3 Description of Objects

5.9.3.1 Object 100C_h: guard_time

For activating the Nodeguarding the maximum time between two remote requests of the master will be configured. As this time will be calculated as product of **guard_time** (100C_h) and **life_time_factor** (100D_h), it is recommended to set the **life_time_factor** to 1 and write the **guard_time** directly in milliseconds.

Index	100C _h
Name	guard_time
Object Code	VAR
Data Type	UINT16

As of Firmware 3.5.x.1.1

Access	rw
PDO Mapping	no
Units	ms
Value Range	0...65535
Default Value	0

5.9.3.2 Objekt 100D_h: life_time_factor

The **life_time_factor** should be set to 1 to write the **guard_time** directly in milliseconds.

Index	100D_h
Name	life_time_factor
Object Code	VAR
Data Type	UINT8

As of Firmware 3.5.x.1.1

Access	rw
PDO Mapping	no
Units	-
Value Range	0, 1
Default Value	0

5.10 Table of identifiers

The following table gives a survey of the used identifiers.

Object-Type	Identifier (hexadecimal)	Remark
SDO (Host to Servo)	600 _h +node id	
SDO (Servo to Host)	580 _h + node id	
TPD01	181 _h	Standard values.
TPD02	281 _h	
TPD03	381 _h	Can be changed on demand.
TPD04	481 _h	
RPD01	201 _h	
RPD02	301 _h	
RPD03	401 _h	
RPD04	501 _h	
SYNC	080 _h	
EMCY	080 _h + node number	
HEARTBEAT	700 _h + node number	
NODEGUARDING	700 _h + node number	
BOOTUP	700 _h + node number	
NMT	000 _h	

6 Adjustment of parameters

Before a certain task (e.g. torque or velocity control) can be managed by the servo controller several parameters have to be adjusted according to the used motor and the specific application. Therefore the chronological order suggested by the following chapters should be abided.

After explaining the parameter adjustment the device control and the several modes of operation will be presented.



An "A" will be displayed by the servo controller if it is not properly commissioned yet. If the complete adjustment of parameter should be done via the CAN bus, object **6510_h_C0_h** have to be configured to suppress the "A". (see chapter 6.17.1.12 Object 6510h_C0h: commissioning_state).

Beside the parameters, described in details here, there are more parameters in the controller's object dictionary, which must be implemented according to the CANopen specification. They normally contain no information, which can be meaningful used for configuring an application with the . If necessary the specification of such objects can be found in [1] and [2] (see page 13).

6.1 Load and save set of parameters

6.1.1 Survey

The servo controller has three parameter sets:

- **Current parameter set**

This parameter set is in the transient memory (RAM) of the servo controller. It can be read and written optionally via the parameter set-up program ™ or via the CAN bus. When the servo controller is switched on the **application parameter set** is copied into the **current parameter set**.


- **Default parameter set**

This is the unmodifiable **default parameter set** of the servo controller given by the manufacturer. The **default parameter set** can be copied to the current parameter set through a write process into the CANopen object **1011_h_01_h (restore_all_default_parameters)**. This copy process is only possible while the output power stage is switched off.

- Application parameter set

The **current parameter set** can be saved into the non-transient flash memory. This saving process is enabled by a write access to the CANopen object **1010h_01h** (**save_all_parameters**). When the servo controller is switched on the **application parameter set** is copied to the **current parameter set**.

The following graphic illustrates the coherence between the respective parameter sets.



Two different methods are possible concerning the parameter set administration:

1. The parameter set is made up with the parameter set-up program™ and also transferred to the single servo controller by the parameter set-up program™. With this method only those objects which can be accessed via CANopen exclusively have to be adjusted via the CAN bus.
This method has the disadvantage that the parameter set-up software is needed for every start of a new machine or in case of repair (exchange of servo controller). Therefore this method only makes sense for individual units.
2. This method is based on the fact that most application specific parameter sets only vary in few parameters from the **default parameter set**. Thus it is possible to set up the **current parameter set** after every reset via the CAN bus. To that purpose the **default parameter set** is first loaded by the superimposed control (call of the CANopen object **1011h_01h** (**restore_all_default_parameters**)). Afterwards only those objects are transferred which vary. The complete process only lasts about 0,3 seconds per drive. It is advantageous that this method also works for non-configured servo controllers and the parameter set-up software™ is not necessary for this. It is urgently recommended to use method 2.



Before switching on the power stage for the first time, assure that the servo controller contains the desired parameters.

An incorrect parameter set-up may cause uncontrolled behaviour of the motor and thereby personal or material damage may occur.

6.1.2 Description of Objects

6.1.2.1 Object 1011_h: restore_default_parameters

Index	1011_h
Name	restore_parameters
Object Code	ARRAY
No. of Elements	1
Data Type	UINT32

Sub-Index	01_h
Description	restore_all_default_parameters
Access	rw
PDO Mapping	no
Units	-
Value Range	64616F6C _h („load“)
Default Value	1 (read access)

Through the object **1011_h_01_h** (**restore_all_default_parameters**) it is possible to put the **current parameter set** into a defined state. For that purpose the **default parameter set** is copied to the **current parameter set**. The copy process is enabled by a write access to this object and the string "load" is to be passed as data set in hexadecimal form.

This command is only executed while the output power stage is deactivated. Otherwise the SDO error "The controller is in wrong operation mode for this kind of operation" is generated.

The parameters for the CAN communication (node number, baudrate and mode) and several parameters for configuring the encoder inputs (partly needing a reset for becoming valid) remain unchanged.

6.1.2.2 Object 1010_h: store_parameters

Index	1010 _h
Name	store_parameters
Object Code	ARRAY
No. of Elements	1
Data Type	UINT32

Sub-Index	01 _h
Description	save_all_parameters
Access	rW
PDO Mapping	no
Units	-
Value Range	65766173 _h („save“)
Default Value	1

To store the **default parameter set** as **application parameter set**, the object 1010_h_01_h (**save_all_parameters**) must be used additionally.

The default behaviour for this object being written by an SDO access is an immediate SDO response. So the response does not mirror the end of the “saving parameters” process. This behaviour can be changed by object 6510_h_F0_h (**compatibility_control**).

6.2 Compatibility settings

6.2.1 Survey

In order to be compatible to earlier CANopen implementations (also to other device series for example) on the one hand and to achieve changes and patches compared to the DSP402 and the DS301 on the other hand, the object **compatibility_control** has been introduced. In the default parameter set this object returns 0, i.e. compatibility to earlier versions. For new applications we recommend to set the defined bits, to facilitate as high as possible conformance with the mentioned standards.

6.2.2 Description of Objects

6.2.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
6510 _h _F0 _h	VAR	compatibility_control	UINT16	rw

6.2.2.2 Object 6510_h_F0_h: compatibility_control

Sub-Index	F0 _h
Description	compatibility_control
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	-
Value Range	0...1FF _h , see table
Default Value	0

As of Firmware 3.2.0.1.1

Bit	Value	Name	
0	0001 _h	homing_method_scheme*	
1	0002 _h	reserved	
2	0004 _h	homing_method_scheme	
3	0008 _h	reserved	
4	0010 _h	response_after_save	As of Firmware 3.4.0.1.1
5	0020 _h	reserved	As of Firmware 3.5.0.1.1
6	0040 _h	homing_to_zero	As of Firmware 3.5.0.1.1
7	0080 _h	device_control	As of Firmware 3.5.0.1.1
8	0100 _h	reserved	As of Firmware 3.5.0.1.1

Bit 0 homing_method_scheme*

This bit is compatible with bit 2. If this bit will be set, bit 2 will be set as well and vice versa.

Bit 1 reserved

This bit is reserved. It must not be set.

Bit 2 homing_method_scheme

If this bit is set the numeration of the homing methods 32...35 corresponds to the DSP 402. If it is reset the numeration is compatible to previous implementations.
(See also Chap. 8.2.3)

If this bit will be set, bit 0 will be set as well and vice versa.

Bit 3 reserved

This bit is reserved. It must not be set.

Bit 4 response_after_save

If this bit is set, the sdo response to **save_all_parameters** will not be sent before the saving has been completed, which can take several seconds. This may lead to a timeout of the master.

If this bit is reset, the response will be sent immediately, without waiting for the end of the saving process.

Bit 5 reserved

This bit is reserved. It must not be set.

Bit 6 homing_to_zero

A CANopen homing operation consists of two phases (Search for switch an Search for zero) until now: The drive does not move to the zero position (which can be different to the found reference position due to the **homing_offset** for example).

If this bit is set, this behaviour will be changed and the servo controller always moves to the zero position.

Bit 7 device_control

If this bit is set, bit 4 of the **statusword** (**voltage_enabled**) complies to DSP 402 v2.0

Furthermore the state **FAULTREACTION_ACTIVE** is distinguishable from the state **FAULT**. See also Chapter 7

Bit 8 reserved


This bit is reserved. It must not be set.

6.3 Conversion factors (Factor Group)

6.3.1 Survey

Servo controllers will be used in a huge number of applications: As direct drive, with gear or for linear drives. To allow an easy parametrization for all kinds of applications, the servo controller can be configured in such a way that all values like the demand velocity refer to the driven side of the plant. The necessary calculation is done by the servo controller.

Consequently it is possible to enter values directly in e.g. millimetre per second if a linear drive is used. The conversion is done by the servo controller using the Factor Group. For each physical value (position, velocity and acceleration) exists a specific conversion factor to adapt the unit to the own application. In general the user specific units defined by the Factor Group are called `position_units`, `speed_units` and `acceleration_units`. The following Figure shows the function of the Factor Group:



Principally all parameters will be stored in its internal units and converted while reading or writing a parameter.

Therefore the Factor Group should be adjusted once before commissioning the servo controller and not to be changed during parametrization.

The default setting of the Factor Group is as follows:

Value	Name	Unit	Remark
Length	position_units	Increments	65536 Increments per revolution
Velocity	speed_units	min ⁻¹	Revolution per minute (RPM)
Acceleration	acceleration_units	min ⁻¹ /s	Increase of velocity per second (RPM / s)

6.3.2 Description of Objects

6.3.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
6093 _h	ARRAY	position_factor	UINT32	rw
6094 _h	ARRAY	velocity_encoder_factor	UINT32	rw
6097 _h	ARRAY	acceleration_factor	UINT32	rw
607E _h	VAR	polarity	UINT8	rw

6.3.2.2 Object 6093_h: position_factor

The object **position_factor** converts all values of length of the application from **position_units** into the internal unit **increments** (65536 Increments equals 1 Revolution). It consists of numerator and divisor:




Figure 6.5: Survey: Factor Group

Index	6093 _h
Name	position_factor
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01 _h
Description	numerator
Access	rw
PDO Mapping	yes
Units	-
Value Range	-
Default Value	1

Sub-Index	02 _h
Description	divisor
Access	rw
PDO Mapping	yes
Units	-
Value Range	-
Default Value	1

To calculate the **position_factor** the following values are necessary:

gear_ratio	Ratio between revolutions on the driving side (R_{IN}) and revolutions on the driven side (R_{OUT}).
feed_constant	Ratio between revolutions on the driven side (R_{OUT}) and equivalent motion in position_units (e.g. 1 rev = 360°)

The calculation of the **position_factor** is done with the following equation:

$$\text{position_factor} = \frac{\text{numerator}}{\text{divisor}} = \frac{\text{gear_ratio} \cdot 65536}{\text{feed_constant}}$$

Numerator and divisor of the **position_factor** has to be entered separately. Therefore it may be necessary to extend the fraction to generate integers.



The **position_factor** must not exceed 2^{24} .

EXAMPLE



At first the desired unit (column 1) and the number of decimals (dec) must be specified, as well as the gear ratio and if necessary the feed constant of the application must be determined. This feed constant will be then represented in the desired position units (column 2).

Finally all the values can be inserted in the formula and the fraction can be calculated.

Degree, 1 Dec. 1/10 Degree (°/10)	$1 R_{\text{OUT}} = 3600 \frac{\text{°}}{10}$	1/1	$\frac{1R}{1R} \cdot \frac{65536 \text{ Inc}}{R} = \frac{65536 \text{ Inc}}{3600 \frac{\text{°}}{10}}$	num: 4096 div: 225
--	---	-----	--	-----------------------

1. Desired unit on the driven side (*position_units*)
2. *feed_constant*: How many *position_units* are 1 Revolution (R_{OUT})
3. *Gear_ratio*: R_{IN} per R_{OUT}
4. Calculate equation

1.	2.	3.	4.	RESULT Shortened
Increments, 0 Dec. Inc	$1 R_{\text{OUT}} = 65536 \text{ Inc}$	1/1	$\frac{1R}{1R} \cdot \frac{65536 \text{ Inc}}{R} = \frac{1 \text{ Inc}}{65536 \text{ Inc}}$	num: 1 div: 1
Degree, 1 Dec. 1/10 Degree (°/10)	$1 R_{\text{OUT}} = 3600 \frac{\text{°}}{10}$	1/1	$\frac{1R}{1R} \cdot \frac{65536 \text{ Inc}}{R} = \frac{65536 \text{ Inc}}{3600 \frac{\text{°}}{10}}$	num: 4096 div: 225
Revolutions, 2 Dec. 1/100 R (R/100)	$1 R_{\text{OUT}} = 100 \frac{R}{100}$	1/1	$\frac{1R}{1R} \cdot \frac{65536 \text{ Inc}}{R} = \frac{65536 \text{ Inc}}{100 \frac{R}{100}}$	num: 16384 div: 25
mm, 1 Dec. 1/10 mm (mm/10)	$63.15 \frac{\text{mm}}{R} \Rightarrow 1 R_{\text{OUT}} = 631.5 \frac{\text{mm}}{10}$	4/5	$\frac{4R}{5R} \cdot \frac{65536 \text{ Inc}}{R} = \frac{2621440 \text{ Inc}}{631.5 \frac{\text{mm}}{10}}$	num: 524288 div: 6315

6.3.2.3 Object 6094_h: velocity_encoder_factor

The object **velocity_encoder_factor** converts all speed values of the application from **speed_units** into the internal unit **revolutions per 4096 minutes**. It consists of numerator and divisor:

Index	6094 _h
Name	velocity_encoder_factor
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01 _h
Description	numerator
Access	rw
PDO Mapping	yes
Units	-
Value Range	-
Default Value	1000 _h

Sub-Index	02 _h
Description	divisor
Access	rw
PDO Mapping	yes
Units	-
Value Range	-
Default Value	1

In principle the calculation of the **velocity_encoder_factor** is composed of two parts: A conversion factor from internal units of length into **position_units** and a conversion factor from internal time units into user defined time units (e.g. from seconds to minutes). The first part equals the calculation of the **position_factor**. For the second part another factor is necessary for the calculation:

- | | |
|---------------|--|
| time_factor_v | Ratio between internal and user defined time units.
(z.B. 1 min = $\frac{1}{4096} \text{ 4096 min}$) |
| gear_ratio | Ratio between revolutions on the driving side (R_{IN}) and revolutions on the driven side (R_{OUT}). |
| feed_constant | Ratio between revolutions on the driven side (R_{OUT}) and equivalent |

motion in position_units (e.g. 1 R = 360°)

The calculation of the `velocity_encoder_factor` is done with the following equation:

$$\text{velocity_encoder_factor} = \frac{\text{numerator}}{\text{divisor}} = \frac{\text{gear_ratio} \cdot \text{time_factor_v}}{\text{feed_constant}}$$

Numerator and divisor of the `velocity_encoder_factor` has to be entered separately. Therefore it may be necessary to extend the fraction to generate integers:

EXAMPLE



At first the desired unit (column 1) and the number of decimals (dec) must be specified, as well as the gear ratio and if necessary the feed constant of the application must be determined. This feed constant will be then represented in the desired position units (column 2). Subsequently the desired time unit has to be converted into the servo's time unit (column 3).

Finally all the values can be inserted in the formula and the fraction can be calculated.

mm/s 1 Dec	$63.15 \text{ mm/R} \Rightarrow$	$1 \frac{1}{10} = \frac{63.15}{10}$	$\frac{4R}{5R} \cdot \frac{60 \cdot 4096 \frac{1}{4096\text{min}}}{631.5 \frac{\text{mm}}{10}} = \frac{1966080 \text{ R}}{6315 \frac{\text{mm}}{10\text{s}}} = \frac{1966080}{6315} \text{ R/s}$	num: 131072 div: 421
------------------------	----------------------------------	-------------------------------------	--	-------------------------

1. Desired unit on the driven side (*position_units*)
2. *feed_constant*: How many *position_units* are 1 Revolution (R_{OUT})
3. *time_factor_v*: Convert time_unit to internal unit
4. Gear_ratio: R_{IN} per R_{OUT}
5. Calculate equation

1.	2.	3.	4.	5.	RESULT Shortened
R/min 0 Dec.	$1 R_{OUT} =$ $1 R_{OUT}$	$1 \frac{1}{10} = \frac{11}{10}$ $4096 \frac{1}{4096\text{min}}$	1/1	$\frac{1R}{1R} \cdot \frac{4096 \frac{1}{4096\text{min}}}{1 \frac{1}{10}} = \frac{4096}{10} \text{ R/min}$	num: 4096 div: 1
R/min 2 Dec.	$1 R_{OUT} =$ $100 \frac{R}{100}$ $(\frac{R}{100\text{min}})$	$1 \frac{1}{10} = \frac{11}{10}$ $4096 \frac{1}{4096\text{min}}$	2/3	$\frac{2R}{3R} \cdot \frac{4096 \frac{1}{4096\text{min}}}{1 \frac{1}{10}} = \frac{8192}{300} \frac{R}{100\text{min}}$	num: 2048 div: 75
$^{\circ}/\text{s}$ 1 Dec.	$1 R_{OUT} =$ $3600 \frac{^{\circ}}{10}$	$1 \frac{1}{10} = \frac{11}{10}$	1/1	$\frac{1R}{1R} \cdot \frac{60 \cdot 4096 \frac{1}{4096\text{min}}}{1 \frac{1}{10}} = \frac{245760}{3600} \frac{R}{4096\text{min}}$	num: 1024



EXAMPLE

At first the desired unit (column 1) and the number of decimals (dec) must be specified, as well as the gear ratio and if necessary the feed constant of the application must be determined. This feed constant will be then represented in the desired position units (column 2). Subsequently the desired time unit has to be converted into the servo's time unit (column 3).

Finally all the values can be inserted in the formula and the fraction can be calculated.

mm/s 1 Dec $1/10 \frac{\text{mm}}{\text{s}}$ ($\frac{\text{mm}}{\text{10s}}$)	$63.15 \frac{\text{mm}}{\text{R}} \Rightarrow$ $631.5 \frac{\text{mm}}{10}$	$1 \frac{1}{s} =$ $60 \frac{1}{\text{min}} =$ $4096 \cdot 60 \frac{1}{4096 \text{ min}}$	$4/5$	$\frac{4R}{5R} \cdot \frac{60 \cdot 4096 \frac{1}{4096 \text{ min}}}{631.5 \frac{\text{mm}}{10}} = \frac{1966080 \frac{\text{R}}{4096 \text{ min}}}{6315 \frac{\text{mm}}{10 \text{ s}}}$	num: 131072 div: 421
---	--	--	-------	---	-------------------------

1. Desired unit on the driven side (*position_units*)
2. *feed_constant*: How many *position_units* are 1 Revolution (R_{OUT})
3. *time_factor_v*: Convert *time_unit* to internal unit
4. *Gear_ratio*: R_{IN} per R_{OUT}
5. Calculate equation

1.	2.	3.	4.	5.	RESULT Shortened
$1/10 \frac{\text{°}}{\text{s}}$ ($\frac{\text{°}}{\text{10s}}$)		$60 \frac{1}{\text{min}} = 60 \cdot 4096 \frac{1}{4096 \text{ min}}$			div: 15
mm/s 1 Dec. $1/10 \frac{\text{mm}}{\text{s}}$ ($\frac{\text{mm}}{\text{10s}}$)	$63.15 \frac{\text{mm}}{\text{R}} \Rightarrow$ $1 R_{\text{OUT}} = 631.5 \frac{\text{mm}}{10}$	$1 \frac{1}{s} =$ $60 \frac{1}{\text{min}} = 60 \cdot 4096 \frac{1}{4096 \text{ min}}$	$4/5$	$\frac{4R}{5R} \cdot \frac{60 \cdot 4096 \frac{1}{4096 \text{ min}}}{631.5 \frac{\text{mm}}{10}} = \frac{1966080 \frac{\text{R}}{4096 \text{ min}}}{6315 \frac{\text{mm}}{10 \text{ s}}}$	num: 131072 div: 421

6.3.2.4 Object 6097_h: acceleration_factor

The object **acceleration_factor** converts all acceleration values of the application from **acceleration_units** into the internal unit **RPM per 256 minutes**. It consists of numerator and divisor:

Index	6097 _h
Name	acceleration_factor
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01 _h
Description	numerator
Access	rw
PDO Mapping	yes
Units	-
Value Range	-
Default Value	100 _h

Sub-Index	02 _h
Description	divisor
Access	rw
PDO Mapping	yes
Units	-
Value Range	-
Default Value	1

The calculation of the **acceleration_factor** is also composed of two parts: A conversion factor from internal units of length into **position_units** and a conversion factor from internal time units squared into user defined time units squared (e.g. from seconds² to minutes²). The first part equals the calculation of the **position_factor**. For the second part another factor is necessary for the calculation:

time_factor_a Ratio between internal time units squared and user defined time units squared

$$(z.B. 1 \text{ min}^2 = 1 \text{ min} \cdot 1 \text{ min} = 60 \text{ s} \cdot 1 \text{ min} = \frac{60}{256} \text{ 256 min} \cdot \text{s})$$

gear_ratio Ratio between revolutions on the driving side (R_{IN}) and revolutions on the driven side (R_{OUT}).

feed_constant Ratio between revolutions on the driven side (R_{OUT}) and equivalent

motion in position_units (e.g. 1 R = 360°)

The calculation of the **acceleration_factor** is done with the following equation:

$$\text{acceleration_factor} = \frac{\text{numerator}}{\text{divisor}} = \frac{\text{gear_ratio} \cdot \text{time_factor_a}}{\text{feed_constant}}$$

Numerator and divisor of the **acceleration_factor** has to be entered separately. Therefore it may be necessary to extend the fraction to generate integers.

EXAMPLE



At first the desired unit (column 1) and the number of decimals (dec) must be specified, as well as the gear ratio and if necessary the feed constant of the application must be determined. This feed constant will be then represented in the desired position units (column 2). Subsequently the desired time unit squared has to be converted into the servo's time unit squared (column 3).

Finally all the values can be inserted in the formula and the fraction can be calculated.

mm/s^2 1 Dec $1/10 \text{ mm}/\text{s}^2$ ($\text{mm}/10\text{s}^2$)	$63.15 \text{ mm}/\text{R} \Rightarrow$ $631.5 \text{ mm}/10$	$1 \frac{1}{s^2} =$ $60 \frac{1}{\text{min} \cdot \text{s}} =$ $60 \cdot 256 \frac{1}{\text{min}^2}$ $256 \cdot \text{s}$	$4/5$	$4R \cdot 256 \cdot 60 \frac{1}{256 \text{ min} \cdot \text{s}}$ $5R \cdot 1 \frac{1}{s^2}$ $631.5 \frac{\text{mm}}{10}$ $1R$	$\frac{122880 \frac{\text{R}}{\text{min}}}{6315 \frac{\text{mm}}{10 \text{ s}^2}}$	num: 8192 div: 421
---	--	--	-------	--	--	-----------------------

1. Desired unit on the driven side (*acceleration_units*)
2. *feed_constant*: How many *position_units* are 1 Revolution (R_{OUT})
3. *time_factor_v*: Convert (*time_unit*)² to internal unit²
4. Gear_ratio: R_{IN} per R_{OUT}
5. Calculate equation

1.	2.	3.	4.	5.	RESULT Shortened
$R/\text{min}/\text{s}$ 0 Dec. $R/\text{min}/\text{s}$	$1 R_{\text{OUT}} =$ $1 R_{\text{OUT}}$	$1 \frac{1}{\text{min} \cdot \text{s}} =$ $256 \frac{1}{\text{min}^2}$ $256 \cdot \text{s}$	1/1	$\frac{1R \cdot 256 \frac{1}{256 \text{ min} \cdot \text{s}}}{1R \cdot 1 \frac{1}{\text{min} \cdot \text{s}}} = \frac{256 \frac{\text{R}}{\text{min}}}{1 \frac{\text{R}}{\text{min}}}$	num: 256 div: 1
$^{\circ}/\text{s}^2$ 1 Dec. $1/10 ^{\circ}/\text{s}^2$ ($^{\circ}/10\text{s}^2$)	$1 R_{\text{OUT}} =$ $3600 ^{\circ}/10$	$1 \frac{1}{\text{s}^2} =$ $60 \frac{1}{\text{min} \cdot \text{s}} =$ $60 \cdot 256 \frac{1}{\text{min}^2}$ $256 \cdot \text{s}$	1/1	$\frac{1R \cdot 60 \cdot 256 \frac{1}{256 \text{ min} \cdot \text{s}}}{1R \cdot 1 \frac{1}{\text{s}^2}} = \frac{15360 \frac{\text{R}}{\text{min}}}{3600 \frac{^{\circ}}{10 \text{ s}^2}}$	num: 64 div: 15
R/min^2 2 Dec. $1/100 R/\text{min}^2$ ($R/100 \text{ min}^2$)	$1 R_{\text{OUT}} =$ $100 R/100$	$1 \frac{1}{\text{min}^2} =$ $\frac{1}{60} \frac{1}{\text{min}} =$ $\frac{256}{60} \frac{1}{\text{min}}$ $256 \cdot \text{s}$	2/3	$\frac{2R \cdot 256 \frac{1}{256 \text{ min} \cdot \text{s}}}{3R \cdot 60 \frac{1}{\text{min}^2}} = \frac{512 \frac{\text{R}}{\text{min}}}{100 \frac{R}{100 \text{ min}^2}}$	num: 32 div: 1125
mm/s^2 1 Dec. $1/10 \text{ mm}/\text{s}^2$ ($\text{mm}/10\text{s}^2$)	$63.15 \text{ mm}/\text{R} \Rightarrow$ $631.5 \text{ mm}/10$	$1 \frac{1}{\text{s}^2} =$ $60 \frac{1}{\text{min} \cdot \text{s}} =$ $60 \cdot 256 \frac{1}{\text{min}^2}$ $256 \cdot \text{s}$	4/5	$\frac{4R \cdot 256 \cdot 60 \frac{1}{256 \text{ min} \cdot \text{s}}}{5R \cdot 1 \frac{1}{\text{s}^2}} = \frac{122880 \frac{\text{R}}{\text{min}}}{631.5 \frac{\text{mm}}{10 \text{ s}^2}}$	num: 8192 div: 421

6.3.2.5 Object 607E_h: polarity

The signs of the position and velocity values of the servo controller can be adjusted via the corresponding polarity flag. This flag can be used to invert the direction of rotation of the motor keeping the same desired values. In most applications it makes sense to set the **position_polarity_flag** and the **velocity_polarity_flag** to the same value. The conversion factors will be used when reading or writing a position or velocity value. Stored parameters will not be affected.

Index	607E _h
Name	polarity
Object Code	VAR
Data Type	UINT8

Access	rw
PDO Mapping	yes
Units	-
Value Range	40 _h , 80 _h , C0 _h
Default Value	0

Bit	Value	Name	Description	
6	40 _h	velocity_polarity_flag	0:	multiply by 1 (default)
			1:	multiply by -1 (invers)
7	80 _h	position_polarity_flag	0:	multiply by 1 (default)
			1:	multiply by -1 (invers)

6.4 Power stage parameters

6.4.1 Survey

The intermediate circuit is charged by the main supply voltage using a precharge control. Thereby the current is limited and the loading process is controlled. The precharge control will be bridged if the intermediate circuit is loaded completely. Before this it is not possible to enable the controller.

The rectified supply voltage is smoothed by the capacitors of the intermediate circuit. The motor is fed from the intermediate circuit via the IGBTs. The power stage contains a number of security functions which can be configured in part:

- Controller enable logic (software and hardware enabling)
- Overcurrent control
- Over- and undervoltage control of the intermediate circuit
- Power stage control

6.4.2 Description of Objects

Index	Object	Name	Typ	Attr.
6510 _h	VAR	drive_data		

6.4.2.1 Object 6510_h_10_h: enable_logic

The digital inputs **enable power stage** and **enable controller** have to be set so that the power stage of the servo controller can be activated. The input **enable power stage** directly acts on the trigger signals of the power transistors and would also be able to interrupt them in case of a defective microprocessor. Therefore the clearing of the signal **enable power stage** during the motor is rotating causes the effect that the motor coasts down without being braked or is only stopped by a possibly existing holding brake. The signal of the input **enable controller** is processed by the microcontroller of the servo controller. Depending on the mode of operation the servo controller reacts differently after clearing this signal:

- **Profile Position Mode and Profile Velocity Mode**

The motor is decelerated using the defined brake ramp after clearing the signal. The power stage is switched off if the motor speed is below 10 rpm and a possibly existing holding brake is locked.

- **Torque Mode**

The power stage is switched off immediately after the signal has been cleared. At the same time a possibly existing holding brake is locked. Therefore the motor coasts down without being braked or is only stopped by a stop brake which might exists.

**CAUTION!**

Both signals do not ensure that the motor is de-energised, although the power stage has been switched off.

If the servo controller is operated via the CAN bus, it is possible to connect the digital inputs **enable power stage** and **enable controller** together at 24 V and to control the enabling via the CAN bus. To that object **6510_h_10_h** (**enable_logic**) has to be set to 2. For safety reasons this is done automatically after activation of CANopen (also after a reset).

Index	6510_h
Name	drive_data
Object Code	RECORD
No. of Elements	51

Sub-Index	10_h
Description	enable_logic
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	-
Value Range	0...2
Default Value	2

Value	Description
0	Digital inputs enable power stage + enable controller.
1	Digital inputs enable power stage + enable controller + RS232
2	Digital inputs enable power stage + enable controller + CAN

6.4.2.2 Object 6510_h_30_h: pwm_frequency

The switching losses of the power stage are proportional to the switching frequency of the power transistors. A little more power can be taken from some devices of the by dividing the PWM frequency by two. The disadvantage is an increasing current ripple. Switch over is only possible while the power stage is switched off.

Sub-Index	30h
Description	pwm_frequency
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	-
Value Range	0, 1
Default Value	0

Value	Description
0	Nominal PWM frequency
1	Half of nominal PWM frequency

6.4.2.3 Object 6510h_3Ah: enable_enhanced_modulation

With the object **enable_enhanced_modulation** the enhanced modulation can be activated. The DC bus voltage will be used more effective thereby increasing the possible velocity by up to 14%. In contrast the control behaviour and the smooth running properties at low speed diminish a little. This object can only be written if the power stage is switched off.

Sub-Index	3Ah
Description	enable_enhanced_modulation
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	-
Value Range	0, 1
Default Value	0

Value	Description
0	Enhanced sinus modulation switched OFF
1	Enhanced sinus modulation switched ON



The Activation of the enhanced modulation will need a Reset to become valid. Therefore the parameter set must be saved (**save_all_parameters**) and after it a Reset must be performed.

6.4.2.4 Object 6510_h_31_h: power_stage_temperature

The temperature of the power stage can be read via the object **power_stage_temperature**. If the temperature specified in the object **6510_h_32_h** (**max_power_stage_temperature**) is exceeded the power stage is switched off and an error message is sent.

Sub-Index	31 _h
Description	power_stage_temperature
Data Type	INT16
Access	ro
PDO Mapping	yes
Units	°C
Value Range	-
Default Value	-

6.4.2.5 Object 6510_h_32_h: max_power_stage_temperature

The temperature of the power stage can be read via the object 6510_h_31_h (power_stage_temperature). If the temperature specified in the object max_power_stage_temperature is exceeded the power stage is switched off and an error message is sent.

Sub-Index	32 _h
Description	max_power_stage_temperature
Data Type	INT16
Access	ro
PDO Mapping	no
Units	°C
Value Range	-
Default Value	Device specific

Device Type	Value
C 1-02	100°C
C 1-05	80°C
C 3-05	80°C
C 3-10	80°C

6.4.2.6 Object 6510_h_33_h: nominal_dc_link_circuit_voltage

The nominal device voltage in mV can be read via the object nominal_dc_link_circuit_voltage.

Sub-Index	33 _h
Description	nominal_dc_link_circuit_voltage
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	mV
Value Range	-
Default Value	Device specific

Device Type	Value
C 1-02	360000

C 1-05	360000
C 3-05	560000
C 3-10	560000

6.4.2.7 Object 6510_h_34_h: actual_dc_link_circuit_voltage

The current voltage in mV of the intermediate circuit can be read via the object `actual_dc_link_circuit_voltage`.

Sub-Index	34 _h
Description	<code>actual_dc_link_circuit_voltage</code>
Data Type	UINT32
Access	ro
PDO Mapping	yes
Units	mV
Value Range	–
Default Value	–

6.4.2.8 Object 6510_h_35_h: max_dc_link_circuit_voltage

The `max_dc_link_circuit_voltage` indicates above which voltage in the intermediate circuit the power stage is immediately switched off for reasons of safety. An error message is sent, too.

Sub-Index	35 _h
Description	<code>max_dc_link_circuit_voltage</code>
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	mV
Value Range	–
Default Value	Device specific

Device Type	Value
C 1-02	460000
C 1-05	460000
C 3-05	800000
C 3-10	800000

6.4.2.9 Object 6510_h_36_h: min_dc_link_circuit_voltage

The servo controller has an undervoltage control. This control can be activated via the object 6510_h_37_h (enable_dc_link_undervoltage_error). The object 6510_h_36_h (min_dc_link_circuit_voltage) determines the lower voltage range. Below this voltage the servo controller decelerates and switches off the power stage afterwards. Furthermore the error E 02 0, "Undervoltage in DC bus" will be activated.

Sub-Index	36 _h
Description	min_dc_link_circuit_voltage
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	mV
Value Range	0...1000000
Default Value	0

6.4.2.10 Object 6510_h_37_h: enable_dc_link_undervoltage_error

The undervoltage control can be activated via the object enable_dc_link_undervoltage_error. The voltage of the intermediate circuit above which the servo should work correctly has to be placed in the object 6510_h_36_h (min_dc_link_circuit_voltage).

Sub-Index	37 _h
Description	enable_dc_link_undervoltage_error
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	-
Value Range	0, 1
Default Value	0

Value	Description
0	Undervoltage error switched OFF (Reaction: Warning)
1	Undervoltage error switched ON (Reaction: Disable servo controller)

The enabling of the error 02-0 is done by changing the error reaction. Reactions leading to a stop of the motor will be returned as ON, all the rest as OFF. On writing a 0 the reaction „Warning“ will be set, on writing a 1 the reaction „Disable servo controller“. See also chapter 6.18 (Error management).

6.4.2.11 Object 6510_h_40_h: nominal_current

The nominal current of the device can be read via this object. It is also the upper limit for the object 6075_h (motor_rated_current).

Sub-Index	40 _h
Description	nominal_current
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	mA
Value Range	–
Default Value	Device specific

Device type	Value
C 1-02	2500
C 1-05	5000
C 3-05	2500
C 3-10	5000



Depending on the controller's cycle time and the frequency of the power stage different values could be shown due to power derating.

6.4.2.12 Object 6510_h_41_h: peak_current

The devices peak current can be read via this object. It is also the upper limit for the object 6073_h (max_current).

Sub-Index	41 _h
Description	peak_current
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	mA
Value Range	–
Default Value	Device specific

Device type	Value
C 1-02	5000
C 1-05	10000
C 3-05	7500
C 3-10	15000



Depending on the controller's cycle time and the frequency of the power stage different values could be shown due to power derating.

6.5 Current control and motor adaptation



Caution!

Incorrect setting of current control parameters and the current limits may possibly destroy the **motor** and even the **servo controller** immediately!

6.5.1 Survey

The parameter set of the servo controller has to be adapted to the connected motor and the used cable set. The following parameters are concerned:

- Nominal current Depending on motor
- Overload Depending on motor
- Pairs of poles Depending on motor
- Current controller Depending on motor
- Direction of rotation Depending on motor and the phase sequence in the motor cable and the resolver cable
- Offset angle Depending on motor and the phase sequence in the motor cable and the resolver cable

These data have to be determined by the program™ when a motor type is used for the first time. You may obtain elaborate parameter sets for a number of motors from your dealer. Please remember that direction of rotation and offset angle also depend on the used cable set. Therefore the parameter sets only work correctly if wiring is identical.



Permuted phase order in the motor or the resolver cable may result in a positive feedback so the velocity in the motor cannot be controlled. The motor will rotate uncontrolled!

6.5.2 Description of Objects

Index	Object	Name	Type	Attr.
6075 _h	VAR	motor_rated_current	UINT32	rw
6073 _h	VAR	max_current	UINT16	rw
604D _h	VAR	pole_number	UINT8	rw
6410 _h	RECORD	motor_data		rw
60F6 _h	RECORD	torque_control_parameters		rw

6.5.2.1 Object 6075_h: motor_rated_current

This value can be read on the motor plate and is specified in mA (effective value, RMS). The upper limit is determined by the object 6510_h_40_h: nominal_current.

Index	6075 _h
Name	motor_rated_current
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	mA
Value Range	0...nominal_current
Default Value	296



If a new value is written into the object 6075_h (motor_rated_current) also object 6073_h (max_current) has to be rewritten.

6.5.2.2 Object 6073_h: max_current

Servo motors may be overloaded for a certain period of time. The maximum permissible motor current is set via this object. It refers to the nominal motor current (object 6075_h: motor_rated_current) and is set in thousandths. The upper limit for this object is determined by the object 6510_h_41_h (peak_current). Many motors may be overloaded by the factor 2 for a short while. In this case the value 2000 has to be written into this object.



Before writing object 6073_h (max_current) the object 6075_h (motor_rated_current) must have a valid value.

Index	6073 _h
Name	max_current
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	per thousands of rated current
Value Range	-
Default Value	2023

6.5.2.3 Object 604D_h: pole_number

The number of poles of the motor can be read in the datasheet of the motor or the parameter set-up program TM. The number of poles is always an integer value. Often the number of pole pairs is specified instead of the number of poles. In this case the number of poles equals the number of pole pairs multiplied with two.

This parameter will not be changed by `restore_default_parameters`.

Index	604D _h
Name	pole_number
Object Code	VAR
Data Type	UINT8

Access	rw
PDO Mapping	yes
Units	-
Value Range	2... 254
Default Value	4 (after /N/T/)

6.5.2.4 Object 6410_h_03_h: iit_time_motor

Servo motors may be overloaded for a certain period of time. This object indicates how long the motor may receive a current specified in the object 6073_h (max_current). After the expiry of the I²t-time the current is automatically limited to the value specified in the object 6075_h (motor_rated_current) in order to protect the motor. The default adjustment is 2 seconds and can be used for most motors.

Index	6410 _h
Name	motor_data
Object Code	RECORD
No. of Elements	5

Sub-Index	03 _h
Description	iit_time_motor
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	ms
Value Range	0...10000
Default Value	2000

6.5.2.5 Object 6410_h_04_h: iit_ratio_motor

The actual value of iit can be read via the object iit_ratio_motor.

Sub-Index	04 _h
Description	iit_ratio_motor
Data Type	UINT16
Access	ro
PDO Mapping	no
Units	per mille
Value Range	-
Default Value	-

6.5.2.6 Object 6510_h_38_h: iit_error_enable

The object **iit_error_enable** determines the behaviour when reaching the iit limit: Either this will only be displayed in the **statusword** or Error 31 0 will be generated

Index	6510 _h
Name	drive_data
Object Code	RECORD
No. of Elements	51

Sub-Index	38 _h
Description	iit_error_enable
Data Type	UINT16
Access	rW
PDO Mapping	no
Units	-
Value Range	0, 1
Default Value	0

Value	Description	
0	lit-error switched OFF	(Reaction: Warning)
1	lit-error switched On	(Reaction: Disable servo controller)

The enabling of the error 31-0 is done by changing the error reaction. Reactions leading to a stop of the motor will be returned as ON, all the rest as OFF. On writing a 0 the reaction „Warning“ will be set, on writing a 1 the reaction „Disable servo controller“. See also chapter 6.18 (Error management).

6.5.2.7 Object 6410_h_10_h: phase_order

With the object **phase_order** it is possible to consider permutations of motor- or resolver cable. This value can be taken from TM. A zero means “right”, a one means “left”.

Sub-Index	10_h
Description	phase_order
Data Type	INT16
Access	rw
PDO Mapping	yes
Units	-
Value Range	0, 1
Default Value	0

Value	Description
0	Right
1	Left

6.5.2.8 Object 6410_h_11_h: encoder_offset_angle

In case of the used servo motors permanent magnets are on the rotor. These magnets generate a magnetic field whose orientation to the stator depends on the rotor position. For the electronic commutation the controller always has to position the electromagnetic field of the stator in the correct angle towards this permanent magnetic field. For that purpose it permanently determines the rotor position with an angle encoder (resolver etc.).

The orientation of the angle encoder to the magnetic field has to be written to the object **resolver_offset_angle**. This angle can be determined by the parameter set-up program TM. The angle determined by the parameter set-up program TM is in the range of +/-180°. It has to be converted as follows to be written into the object **resolver_offset_angle**:

$$\text{encoder_offset_angle} = \text{„Offset of encoder“} \times \frac{32767}{180^\circ}$$

This parameter will not be changed by **restore_default_parameters**.

Index	6410_h
Name	motor_data
Object Code	RECORD
No. of Elements	5

Sub-Index	11_h
Description	encoder_offset_angle
Data Type	INT16
Access	rW
PDO Mapping	yes
Units	-
Value Range	-32767...32767
Default Value	E000 _h (-45°) (after /N/T)

6.5.2.9 Object 6410_h_14_h: motor_temperature_sensor_polarity

The polarity of the motor temperature sensor can be configured by this object. For B-contacts (normally closed) zero has to be entered, for A-contacts (normally opened) one.

Sub-Index	14 _h
Description	motor_temperatur_sensor_polarity
Data Type	INT16
Access	rw
PDO Mapping	yes
Units	-
Value Range	0, 1
Default Value	0

As of Firmware 3.2.0.1.1

Value	Meaning
0	B-contact (normally closed)
1	A-contact (normally opened)

6.5.2.10 Objekt 6510_h_2E_h: motor_temperature

The current motor temperature can be read by this object if a suitable (analogue) motor temperature sensor is connected to the servo. Otherwise the object is undefined.

Index	6510 _h
Name	drive_data
Object Code	RECORD
No. of Elements	51

Sub-Index	2E _h
Description	motor_temperature
Data Type	INT16
Access	ro
PDO Mapping	yes
Units	°C
Value Range	-
Default Value	-

As of Firmware 3.5.x.1.1

6.5.2.11 Objekt 6510_h_2F_h: max_motor_temperature

With this object the maximum motor temperature can be set: If the motor_temperature exceeds this value, a reaction according to the error management (Error 3-0, Overtemperature motor analog) will be initiated. If this reaction stops the movement („Error“) an emergency telegram will be sent. See Chapter 6.18 (error management) for more details.

Sub-Index	2F_h
Description	max_motor_temperature
Data Type	INT16
Access	rw
PDO Mapping	no
Units	°C
Value Range	20...300
Default Value	100

As of Firmware 3.5.x.1.1

6.5.2.12 Object 60F6_h: torque_control_parameters

The data of the current controller has to be taken from the parameter set-up program TM. The following conversions have to be noticed:

The gain of the current controller has to be multiplied by 256. In case of a gain of 1.5 in the parameter set-up program TM the value 384 = 180_h has to be written into the object **torque_control_gain**.

The time constant of the current controller is specified in milliseconds in the parameter set-up program TM. This time constant has to be converted to microseconds before it can be transferred into the object **torque_control_time**. In case of a specified time of 0.6 milliseconds a value of 600 has to be entered into the object **torque_control_time**.

Index	60F6 _h
Name	torque_control_parameters
Object Code	RECORD
No. of Elements	2

Sub-Index	01 _h
Description	torque_control_gain
Data Type	UINT16
Access	rW
PDO Mapping	no
Units	256 = „1“
Value Range	0...32*256
Default Value	3*256 (768)

Sub-Index	02 _h
Description	torque_control_time
Data Type	UINT16
Access	rW
PDO Mapping	no
Units	μs
Value Range	104... 64401
Default Value	1020

6.6 Velocity controller

6.6.1 Survey

The parameter set of the servo controller has to be adapted to the specific application. In particular the gain strongly depends on the masses coupled to the motor. So the data have to be determined by means of the program TM when the plant is set into operation.



Incorrect setting of the velocity control parameters may lead to strong vibrations and destroy parts of the plant!

6.6.2 Description of Objects

Index	Object	Name	Type	Attr.
60F9 _h	RECORD	velocity_control_parameters		rw
2073 _h	VAR	velocity_display_filter_time	UINT32	rw

6.6.2.1 Object 60F9_h: velocity_control_parameters

The data of the velocity controller can be taken from the parameter set-up program TM. Note the following conversions:

The gain of the velocity controller has to be multiplied by 256. In case of a gain of 1.5 in TM the value 384 has to be written into the object **velocity_control_gain**.

The time constant of the velocity controller is specified in milliseconds in TM. This time constant has to be converted to microseconds before it can be transferred into the object **velocity_control_time**. In case of a specified time of 2.0 milliseconds a value of 2000 has to be written into the object **velocity_control_time**.

Index	60F9 _h
Name	velocity_control_parameter_set
Object Code	RECORD
No. of Elements	3

Sub-Index	01 _h
Description	velocity_control_gain
Data Type	UINT16
Access	rW
PDO Mapping	no
Units	256 = Gain 1
Value Range	20...64*256 (16384)
Default Value	256

Sub-Index	02 _h
Description	velocity_control_time
Data Type	UINT16
Access	rW
PDO Mapping	no
Units	μs
Value Range	1...32000
Default Value	2000

Sub-Index	04 _h
Description	velocity_control_filter_time
Data Type	UINT16
Access	rW
PDO Mapping	no
Units	μs
Value Range	1...32000
Default Value	400

6.6.2.2 Objekt 2073_h: velocity_display_filter_time

The filter time of the filter for the actual display velocity (`velocity_actual_value_filtered`) can be configured by this object. This velocity value should only be used for display purposes.

Index	2073 _h
Name	<code>velocity_display_filter_time</code>
Object Code	VAR
Data Type	UINT32

As of Firmware 3.5.x.1.1

Access	rw
PDO Mapping	no
Units	µs
Value Range	1000..50000
Default Value	20000



The `velocity_actual_value_filtered` will be used for overspeed protection. If the `velocity_display_filter_time` is set to a great value, an overspeed error will be detected delayed.

6.7 Position Control Function

6.7.1 Survey

This chapter describes all parameters which are required for the position controller. The desired position value (**position_demand_value**) of the trajectory generator is the input of the position controller. Besides this the actual position value (**position_actual_value**) is supplied by the angle encoder (resolver, incremental encoder, etc.). The behaviour of the position controller can be influenced by parameters. It is possible to limit the output quantity (**control_effort**) in order to keep the position control system stable. The output quantity is supplied to the speed controller as desired speed value. In the **Factor Group** all input and output quantities are converted from the application-specific units to the respective internal units of the controller.

The following subfunctions are defined in this chapter:

1. Trailing error (Following Error)

The deviation of the actual position value (**position_actual_value**) from the desired position value (**position_demand_value**) is named trailing error. If for a certain period of time this trailing error is bigger than specified in the trailing error window (**following_error_window**) bit 13 (**following_error**) of the object **statusword** will be set. The permissible time can be defined via the object **following_error_time_out**.




Figure 6.6: Trailing error (Following Error) – Function Survey

Figure 6.7 shows how the window function is defined for the message "following error". The range between $x_i - x_0$ and $x_i + x_0$ is defined symmetrically around the desired position (**position_demand_value**) x_i . For example the positions x_{t2} and x_{t3} are outside this window (**following_error_window**). If the drive leaves this window and does not return to the window within the time defined in the object **following_error_time_out** then bit 13 (**following_error**) in the **statusword** will be set.




Figure 6.7: Trailing error (following error)

2. Position Reached

This function offers the chance to define a position window around the target position (**target_position**). If the actual position of the drive is within this range for a certain period of time – the **position_window_time** – bit 10 (**target_reached**) will be set in the **statusword**.




Figure 6.8: Position Reached – Function Survey

Figure 6.9 shows how the window function is defined for the message "position reached". The position range between $x_i - x_0$ and $x_i + x_0$ is defined symmetrically around the target position (**target_position**) x_i . For example the positions x_{t0} and x_{t1} are inside this position window (**position_window**). If the drive is within this window a timer is started. If this timer reaches the time defined in the object **position_window_time** and the drive uninterruptedly was within the valid range between $x_i - x_0$ and $x_i + x_0$, bit 10 (**target_reached**) will be set in the **statusword**. As far as the drive leaves the permissible range, bit 10 is cleared and the timer is set to zero.




Figure 6.9: Position reached

6.7.2 Description of Objects

6.7.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
202D _h	VAR	position_demand_sync_value	INT32	ro
6062 _h	VAR	position_demand_value	INT32	ro
6063 _h	VAR	position_actual_value*	INT32	ro
6064 _h	VAR	position_actual_value	INT32	ro
6065 _h	VAR	following_error_window	UINT32	rw
6066 _h	VAR	following_error_time_out	UINT16	rw
6067 _h	VAR	position_window	UINT32	rw
6068 _h	VAR	position_window_time	UINT16	rw
607B _h	ARRAY	position_range_limit	INT32	rw
60FA _h	VAR	control_effort	INT32	ro
60FB _h	RECORD	position_control_parameter_set		rw
60FC _h	VAR	position_demand_value*	INT32	ro
6510 _h _20 _h	VAR	position_range_limit_enable	UINT16	rw
6510 _h _22 _h	VAR	position_error_switch_off_limit	UINT32	rw

6.7.2.2 Affected objects from other chapters

Index	Object	Name	Type	Chapter
607A _h	VAR	target_position	INT32	8.3 Operating Mode »Profile Position Mode«
607C _h	VAR	home_offset	INT32	8.2 Operating Mode »Homing mode«
607D _h	VAR	software_position_limit	INT32	8.3 Operating Mode »Profile Position Mode«
607E _h	VAR	polarity	UINT8	6.3 Conversion factors (Factor Group)
6093 _h	VAR	position_factor	UINT32	6.3 Conversion factors (Factor Group)
6094 _h	ARRAY	velocity_encoder_factor	UINT32	6.3 Conversion factors (Factor Group)
6096 _h	ARRAY	acceleration_factor	UINT32	6.3 Conversion factors (Factor Group)
6040 _h	VAR	controlword	INT16	7 Device Control
6041 _h	VAR	statusword	UINT16	7 Device Control

6.7.2.3 Object 60FB_h: position_control_parameter_set

All parameters of the servo controller have to be adapted to the specific application. Therefore the position control parameters have to be determined optimal by means of the parameter set-up program™.



Incorrect setting of the position control parameters may lead to strong vibrations and so destroy parts of the plant!

The position controller compares the desired position with the actual position and forms a correction speed (Object 60FA_h: control_effort). This correction speed is supplied to the speed controller. The position controller is relatively slow compared to the current controller and speed controller. Therefore the controller internally works with feed forward so that the correction work for the position controller is minimised reaching a fast settling time.

Usually a proportional control unit is sufficient as position controller. The gain of the position controller has to be multiplied by 256. In case of a gain of 1.5 in the menu **Position controller** of the parameter set-up program™ the value 384 = 180_h has to be written into the object **position_control_gain**.

Normally the position controller can work without an integrator. In this case 0 has to be written into the object **position_control_time**. Otherwise the time constant of the position controller has to be converted to microseconds. So the value 4000 has to be written into the object **position_control_time** in case of a time of 4.0 milliseconds.

As the position controller even transforms smallest deviations into a considerable correction speed, very high correction speeds may occur in case of a short disturbance (e. g. short blocking). This can be avoided if the output of the position controller is adequately limited (e.g. 500 rpm) via the object **position_control_v_max**.

The object **position_error_tolerance_window** determines the maximum control deviation without reaction of the position controller. Therewith it is possible to even out backlash within the plant.

Index	60FB _h
Name	position_control_parameter_set
Object Code	RECORD
No. of Elements	4

Sub-Index	01 _h
Description	position_control_gain
Data Type	UINT16
Access	rW
PDO Mapping	no
Units	256 = „1“
Value Range	0...64*256 (16384)
Default Value	102

Sub-Index	02 _h
Description	position_control_time
Data Type	UINT16
Access	rW
PDO Mapping	no
Units	µs
Value Range	0
Default Value	0

Sub-Index	04 _h
Description	position_control_v_max
Data Type	UINT32
Access	rW
PDO Mapping	no
Units	speed units
Value Range	0...131072 min ⁻¹
Default Value	500 min ⁻¹

Sub-Index	05 _h
Description	position_error_tolerance_window
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	position units
Value Range	1...65536 (1 R)
Default Value	2 (1 / 32768 R)

6.7.2.4 Object 6062_h: position_demand_value

The current position demand value can be read by this object. This position is fed into the position controller by the trajectory generator.

Index	6062 _h
Name	position_demand_value
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	position units
Value Range	-
Default Value	-

6.7.2.5 Object 202D_h: position_demand_sync_value

The position setpoint of the synchronization encoder can be read by this object. This position is defined by the object 2022_h synchronization_encoder_select (chap.6.11). This object is specified in user-defined units.

Index	202D _h
Name	position_demand_sync_value
Object Code	VAR
Data Type	INT32

As of Firmware 3.2.0.1.1

Access	ro
PDO Mapping	no
Units	position units
Value Range	-
Default Value	-

6.7.2.6 Object 6064_h: position_actual_value

The actual position can be read by this object. This value is given to the position controller by the angle encoder. This object is specified in user-defined units.

Index	6064 _h
Name	position_actual_value
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	position units
Value Range	-
Default Value	-

6.7.2.7 Object 6065_h: following_error_window

The object **following_error_window** (trailing error window) defines a symmetrical range around the desired position value (**position_demand_value**). If the actual position (**position_actual_value**) is outside the trailing error window (**following_error_window**) a trailing error occurs and bit 13 in the object **statusword** will be set.

The following reasons may cause a trailing error:

- A drive is locked
- The positioning speed is too high
- The accelerations are too high
- The object **following_error_window** configured too small
- The position controller is not configured correctly.

Index	6065 _h
Name	following_error_window
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	position units
Value Range	0...7FFFFFFF _h
Default Value	9101 (9101 / 65536 R = 50°)

6.7.2.8 Object 6066_h: following_error_time_out

If a trailing error occurs longer than defined in this object bit 13 (**following_error**) will be set in the statusword.

Index	6066 _h
Name	following_error_time_out
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	ms
Value Range	0...27314
Default Value	0

6.7.2.9 Object 60FA_h: control_effort

The output quantity of the position controller can be read via this object. This value is supplied internally to the speed controller as desired value.

Index	60FA _h
Name	control_effort
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	speed units
Value Range	--
Default Value	--

6.7.2.10 Object 6067_h: position_window

A symmetrical range around the target position (**target_position**) is defined by the object **position_window**. If the actual position value (**position_actual_value**) is within this range the target position (**target_position**) is regarded as reached.

Index	6067 _h
Name	position_window
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	position units
Value Range	-
Default Value	1820 (1820 / 65536 R = 10°)

6.7.2.11 Object 6068_h: position_window_time

If the actual position of the drive is within the positioning window (**position_window**) as long as defined in this object bit 10 (**target_reached**) will be set in the **statusword**.

Index	6068 _h
Name	position_window_time
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	ms
Value Range	0...65536
Default Value	0

6.7.2.12 Object 6510_h_22_h: position_error_switch_off_limit

In the object **position_error_switch_off_limit** the maximum acceptable deviation between the position setpoint and the position actual value can be entered. In contrast to the following error message mentioned above the power stage will be immediately disabled, whenever the deviation is exceeded, and an error will occur. The motor rotates non-braked, except if a holding brake is available.

Index	6510 _h
Name	drive_data
Object Code	RECORD
No. of Elements	51

Sub-Index	22 _h
Description	position_error_switch_off_limit
Data Type	UINT32
Access	rW
PDO Mapping	no
Units	position units
Value Range	0...2 ³²⁻¹
Default Value	0

As of Firmware 3.2.0.1.1

Value	Meaning
0	Limit value following error OFF (Reaction: NONE)
> 0	Limit value following error ON (Reaction: DISABLE POWER STAGE IMMEDIATELY)

The enabling of the error 17-0 is done by changing the error reaction. The reaction DISABLE POWER STAGE IMMEDIATELY is returned as **ON** and all others are returned as **OFF**. If the value is set to 0, the error reaction will be set to NONE. If a value greater as 0 is set the error reaction will be set to DISABLE POWER STAGE IMMEDIATELY. See also chapter 6.18 (Error management).

6.7.2.13 Object 607B_h: position_range_limit

The object group **position_range_limit** contains two subparameters, which limit the range of the position values. If one of these limits is exceeded, the position value automatically jumps to the respectively other limit. This allows the parameterisation of so-called circular axes. For this purpose the limits must be specified, which should equal the same position (e.g. 0° and 360°).

So that the limits take effect, a circular axis mode must be selected via the object 6510_h_20_h (**position_range_limit_enable**).

Index	607B _h	As of Firmware 3.3.x.1.1
Name	position_range_limit	
Object Code	ARRAY	
No. of Elements	2	
Data Type	INT32	
Sub-Index	01 _h	As of Firmware 3.3.x.1.1
Description	min_position_range_limit	
Access	rW	
PDO Mapping	yes	
Units	position units	
Value Range	-	
Default Value	-	
Sub-Index	02 _h	As of Firmware 3.3.x.1.1
Description	max_position_range_limit	
Access	rW	
PDO Mapping	yes	
Units	position units	
Value Range	-	
Default Value	-	

6.7.2.14 Object 6510_h_20_h: position_range_limit_enable

The range limits, defined by the object 607B_h, can be activated via the object **position_range_limit_enable**. Diverse modes are possible.

If the mode “shortest way” is selected, the positioning jobs are always executed using the physical shortest distance to the target. The drive adjusts the sign of the running speed. In the both modes “fixed rotating direction” the positioning job occurs basically in the direction, specified by the appropriate mode.

Index	6510_h
Name	drive_data
Object Code	RECORD
No. of Elements	51

Sub-Index	20_h
Description	position_range_limit_enable
Data Type	UINT16
Access	rW
PDO Mapping	no
Units	–
Value Range	0...5
Default Value	0

As of Firmware 3.3.x.1.1

Value	Description
0	Off
1	Shortest way (because of compatibility reasons)
2	Shortest way
3	Reserved
4	Fixed rotating direction „positive“
5	Fixed rotating direction „negative“

6.7.2.15 Object 2030_h: set_position_absolute

All readable actual position values can be set to a defined position without changing the physical position. No movement will be executed. If an absolute encoder system is connected, the position offset will be written into the encoder if possible. So in this case this position offset will remain after a Reset. The saving process runs in background independantly from this object. All further parameters which are assigned to the encoder memory are also saved with their current value.

Index	2030 _h
Name	set_position_absolute
Object Code	VAR
Data Type	INT32

As of Firmware 3.5.x.1.1

Access	w0
PDO Mapping	no
Units	position units
Value Range	--
Default Value	--

6.8 Setpoint limitation

6.8.1 Description of objects

6.8.1.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
2415 _h	RECORD	current_limitation		rw
2416 _h	RECORD	speed_limitation		rw

6.8.1.2 Object 2415_h: current_limitation

The record **current_limitation** allows a limitation of the maximum current in the operating modes profile_position_mode, interpolated_position_mode, homing_mode and velocity_mode, whereby a

torque limited speed control mode is possible. With the object **limit_current_input_channel** the source of the limit torque can be chosen. Possible sources are “fixed value” or an analogue input. Depending on the chosen source, the object **limit_current** determines the limit torque (source = fixed value) or the scaling factor for the analogue input (source = analogue input). In the first case the limit current in mA can be entered directly, in the latter case the current in mA, corresponding to an input value of 10V, has to be entered.

Index	2415_h
Name	current_limitation
Object Code	RECORD
No. of Elements	2

Sub-Index	01_h
Description	limit_current_input_channel
Data Type	UINT8
Access	rw
PDO Mapping	no
Units	-
Value Range	0...4
Default Value	0

Sub-Index	02_h
Description	limit_current
Data Type	INT32
Access	rw
PDO Mapping	no
Units	mA
Value Range	-
Default Value	0

Value	Description
0	No limitation
1	AIN0
2	AIN1
3	AIN2
4	Field bus (Field bus selector 2)

6.8.1.3 Object 2416_h: speed_limitation

The record **speed_limitation** allows a limitation of the maximum motor speed in the operating mode **profile_torque_mode**, whereby a speed limited torque control is possible. With the object **limit_speed_input_channel** the source of the limit speed can be chosen. Possible sources are “fixed value” or an analogue input. Depending on the chosen source the object **limit_speed** determines either the limit speed (source = fixed value) or the scaling factor for the analogue input (source = analogue input). In the first case the limit speed can be entered directly, in the latter case the speed, corresponding to an input value of 10V, has to be entered.

Index	2416 _h
Name	speed_limitation
Object Code	RECORD
No. of Elements	2

As of Firmware 3.3.0.1.1

Sub-Index	01 _h
Description	limit_speed_input_channel
Data Type	UINT8
Access	rw
PDO Mapping	no
Units	-
Value Range	0...4
Default Value	0

As of Firmware 3.3.0.1.1

Sub-Index	02 _h
Description	limit_speed
Data Type	INT32
Access	rw
PDO Mapping	no
Units	speed units
Value Range	-
Default Value	0

As of Firmware 3.3.0.1.1

Value	Description
0	No limitation

1	AIN0
2	AIN1
3	AIN2
4	Field bus (Field bus selector 2)

6.9 Encoder settings

6.9.1 Survey

This chapter describes the configuration of the angle encoders X2A, X2B and the incremental input X10.



Caution!

Wrong angle encoder settings may lead to uncontrolled behaviour of the drive and maybe destroy parts of the system.

6.9.2 Description of Objects

6.9.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
2024 _h	RECORD	encoder_x2a_data_field		ro
2024 _{h_01_h}	VAR	encoder_x2a_resolution	UINT32	ro
2024 _{h_02_h}	VAR	encoder_x2a_numerator	INT16	rw
2024 _{h_03_h}	VAR	encoder_x2a_divisor	INT16	rw
2025 _h	RECORD	encoder_x10_data_field		ro
2025 _{h_01_h}	VAR	encoder_x10_resolution	UINT32	rw
2025 _{h_02_h}	VAR	encoder_x10_numerator	INT16	rw
2025 _{h_03_h}	VAR	encoder_x10_divisor	INT16	rw
2025 _{h_04_h}	VAR	encoder_x10_counter	UINT32	ro
2026 _h	RECORD	encoder_x2b_data_field		ro
2026 _{h_01_h}	VAR	encoder_x2b_resolution	UINT32	rw
2026 _{h_04_h}	VAR	encoder_x2b_counter	UINT32	ro

6.9.2.2 Object 2024_h: encoder_x2a_data_field

The record **encoder_x2a_data_field** summarises the parameters, which are necessary for the operation of the angle encoder connected on X2A.

Because numerous angle encoder settings are activated only after a reset, the selection and the settings of the encoders should be made with the TM.

The following settings can be read resp. changed via CANopen.

The object **encoder_x2a_resolution** specifies how many increments per revolution or per unit length an encoder produces. The value 65536 is returned always by this object, because only resolvers evaluated with 16 bit can be connected on the input X2A.

The objects **encoder_x2a_numerator** and **encoder_X2a_divisor** specify the gear (signed or unsigned) between the motor shaft and the encoder.

Index	2024h
Name	encoder_x2a_data_field
Object Code	RECORD
No. of Elements	3

As of Firmware 3.2.0.1.1

Sub-Index	01h
Description	encoder_x2a_resolution
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	increments (4 * line count)
Value Range	-
Default Value	65536

As of Firmware 3.2.0.1.1

Sub-Index	02h
Description	encoder_x2a_numerator
Data Type	INT16
Access	rw
PDO Mapping	no
Units	-
Value Range	-32768 ... 32767 (except 0)
Default Value	1

As of Firmware 3.2.0.1.1

Sub-Index	03h
Description	encoder_x2a_divisor
Data Type	INT16
Access	rw
PDO Mapping	no
Units	-
Value Range	1 ... 32767
Default Value	1

As of Firmware 3.2.0.1.1

6.9.2.3 Object 2026_h: encoder_x2b_data_field

The record **encoder_x2b_data_field** summarises the parameters, which are necessary for the operation of the angle encoder connected on X2B.

The object **encoder_x2b_resolution** specifies how many increments per revolution an encoder produces (for incremental encoders the resolution equals the fourfold line count resp. periods per revolution). The object **encoder_x2b_counter** returns the actual counted number of increments. It returns values between 0 and the number of increments – 1.

An own gear cannot be specified for X2B. The objects **encoder_x2a_numerator** and **encoder_x2a_divisor** can be used instead to set the gear for X2B. The objects **encoder_x2a_numerator** and **encoder_X2a_divisor** specify the gear (signed or unsigned) **between** the motor shaft and the encoder connected to X2b.

Index	2026_h
Name	encoder_x2b_data_field
Object Code	RECORD
No. of Elements	4

As of Firmware 3.2.0.1.1

Sub-Index	01_h
Description	encoder_x2b_resolution
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	increments (4 * line count)
Value Range	depends on the used encoder
Default Value	depends on the used encoder

As of Firmware 3.2.0.1.1

Sub-Index	02_h
Description	encoder_x2b_numerator
Data Type	INT16
Access	rw
PDO Mapping	no
Units	–
Value Range	-32768 ... 32767
Default Value	1

As of Firmware 3.3.0.1.1

Sub-Index	03h
Description	encoder_x2b_divisor
Data Type	INT16
Access	rw
PDO Mapping	no
Units	-
Value Range	1 ... 32767
Default Value	1

As of Firmware 3.3.0.1.1

Sub-Index	04h
Description	encoder_x2b_counter
Data Type	UINT32
Access	ro
PDO Mapping	yes
Units	incremente (4 * line count)
Value Range	0 ... (encoder_x2b_resolution - 1)
Default Value	-

As of Firmware 3.2.0.1.1

6.9.2.4 Object 2025_h: encoder_x10_data_field

The record **encoder_x10_data_field** summarises the parameters, which are necessary for the operation of the incremental input X10. A digital incremental encoder or emulated incremental signals of another can be connected to the incremental input. The input signals via X10 can be used as setpoint or as actual value. You can find more details in chapter 6.11.

The object **encoder_x10_resolution** specifies how many increments per revolution an encoder produces (this equals the fourfold line count). The object **encoder_x10_counter** returns the actual counted number of increments (between 0 and the adjusted number of increments – 1). The objects **encoder_x10_numerator** and **encoder_x10_divisor** specify the gear ratio (signed or unsigned).

When using the X10 signals as an actual value, the gear represents the gear between the motor and actual value encoder connected to X10, which is mounted on the output. When using the X10 signals as a setpoint, a gear ratio between the master and the slave can be realised.

Index	2025_h
Name	encoder_x10_data_field
Object Code	RECORD
No. of Elements	4

As of Firmware 3.2.0.1.1

Sub-Index	01_h
Description	encoder_x10_resolution
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	increments (4 * line count)
Value Range	depends on the used encoder
Default Value	depends on the used encoder

As of Firmware 3.2.0.1.1

Sub-Index	02_h
Description	encoder_x10_numerator
Data Type	INT16
Access	rw
PDO Mapping	no
Units	-
Value Range	-32768 ... 32767 (except 0)
Default Value	1

As of Firmware 3.2.0.1.1

Sub-Index	03_h
Description	encoder_x10_divisor
Data Type	INT16
Access	rw
PDO Mapping	no
Units	-
Value Range	1 ... 32767
Default Value	1

As of Firmware 3.2.0.1.1

Sub-Index	04h
Description	encoder_x10_counter
Data Type	UINT32
Access	ro
PDO Mapping	yes
Units	increments (4 * line count)
Value Range	0 ... (encoder_x10_resolution - 1)
Default Value	-

As of Firmware 3.2.0.1.1

6.10 Incremental encoder emulation

6.10.1 Survey

This object group makes it possible to adjust the incremental output X11. Thus master-slave application, by which the master's output X11 is connected to the slave's input X10, can be parametrised via CANopen.

6.10.2 Description of Objects

6.10.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
2028 _h	VAR	encoder_emulation_resolution	INT32	rw
201A _h	RECORD	encoder_emulation_data		ro
201A _h _01 _h	VAR	encoder_emulation_resolution	INT32	rw
201A _h _02 _h	VAR	encoder_emulation_offset	INT16	rw

6.10.2.2 Object 2028_h: encoder_emulation_resolution

The object record **encoder_emulation_data** encapsulates all settings for the incremental output X11:

Via the object **encoder_emulation_resolution** the output number of increments (= fourfold line count) can be freely set as a multiple of 4. To achieve a ratio of 1:1 in a master-slave application, this must equal the slave's **encoder_X10_resolution**.

With the object **encoder_emulation_offset** the position of the output zero pulse can be shifted based on the zero position of the actual value encoder.

Index	201A_h
Name	encoder_emulation_data
Object Code	RECORD
No. of Elements	2

As of Firmware 3.2.0.1.1

Sub-Index	01_h
Description	encoder_emulation_resolution
Data Type	INT32
Access	rw
PDO Mapping	no
Units	increments (4 * line count)
Value Range	4 * (1...8192)
Default Value	4096

As of Firmware 3.2.0.1.1

Sub-Index	02_h
Description	encoder_emulation_offset
Data Type	INT16
Access	rw
PDO Mapping	no
Units	32767 = 180°
Value Range	-32768...32767
Default Value	0

As of Firmware 3.2.0.1.1

6.10.2.3 Object 2028_h: encoder_emulation_resolution

The object **encoder_emulation_resolution** is only available because of compatibility reasons. It complies with the object **201A_h_01_h**.

Index	2028h
Name	encoder_emulation_resolution
Object Code	VAR
Data Type	INT32

As of Firmware 3.2.0.1.1

Access	rw
PDO Mapping	no
Units	see 201Ah_01h
Value Range	see 201Ah_01h
Default Value	see 201Ah_01h

6.11 Sources for demand / actual value

6.11.1 Survey

The source for the setpoint and the source for the actual value can be changed with the following objects. As standard the controller uses the input of the motor encoder X2A resp. X2B as an actual value for position control. When using an external position encoder, e.g. behind a gear, the supplied position value via X10 can be selected as an actual value for the position controller. Furthermore it is possible to select the X10 input signals (e.g. of a second controller) as an additional setpoint, whereby synchronous operation modes are possible.

6.11.2 Description of Objects

6.11.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
201F _h	VAR	commutation_encoder_select	INT16	rw
2021 _h	VAR	position_encoder_selection	INT16	rw
2022 _h	VAR	synchronisation_encoder_selection	INT16	rw
2023 _h	VAR	synchronisation_filter_time	UINT32	rw
20F0 _h	RECORD	synchronisation_selector_data		ro
20F0 _h _07 _h	VAR	synchronisation_main	UINT16	rw

6.11.2.2 Object 201F_h: commutation_encoder_select

The object **commutation_encoder_select** specifies the encoder input, which is used as commutating encoder. Because this value will be activated only after a reset, the setting of the commutating encoder should be made with the TM.

Index	201F_h
Name	commutation_encoder_select
Object Code	VAR
Data Type	INT16

As of Firmware 3.2.0.1.1

Access	rw
PDO Mapping	no
Units	-
Value Range	0, 2 (see table)
Default Value	0

Value	Description
0	X2A
2	X2B

6.11.2.3 Object 2021_h: position_encoder_selection

The object **position_encoder_selection** specifies the encoder input, which is used for the determination of the actual position (actual value encoder). This value can be changed in order to switch to position control via an external (connected to the output) encoder. Thereby it can be switched between the X10 and the encoder input (X2A, X2B), selected as commutating encoder input. If one of the encoders X2A / X2B is selected as the actual value encoder, then the one, used as the commutating encoder, should be used. If the respectively other one encoder is selected, then it will be automatically switched to the commutating encoder.

Index	2021 _h
Name	position_encoder_selection
Object Code	VAR
Data Type	INT16

As of Firmware 3.2.0.1.1

Access	rw
PDO Mapping	no
Units	-
Value Range	0...2 (see table)
Default Value	0

Value	Description
0	X2A
1	X2B
2	X10



It can be chosen only between the encoder input X10 and the respective commutating encoder X2A or X2B as the actual value encoder. The configuration X2A as the commutating encoder and X2B as the actual value encoder or otherwise is not possible.

6.11.2.4 Object 2022_h: synchronisation_encoder_selection

The object **synchronisation_encoder_selection** specifies the encoder input, which is used as a synchronisation setpoint. Depending on the operation mode this corresponds to a position setpoint (Profile Position Mode) or to a speed setpoint (Profile Velocity Mode).

Only X10 can be used as a synchronisation input. Thus only X10 or No input can be selected. The input chosen as synchronisation setpoint must not be equal to the position encoder selection.

Index	2022 _h
Name	synchronisation_encoder_selection
Object Code	VAR
Data Type	INT16

As of Firmware 3.2.0.1.1

Access	rw
PDO Mapping	no
Units	-
Value Range	-1, 2 (see table)
Default Value	2

Value	Description
-1	No encoder / undefined
2	X10

6.11.2.5 Object 202F_h: synchronisation_selector_data

By the object **synchronisation_main** the enabling of a synchronisation setpoint can be set. To calculate the synchronous setpoint at all, bit 0 must be set. Bit 1 makes it possible in newer firmware versions to switchg on the synchronous position by starting a positioning. At present only 0 is parametrisable, so that the synchronous position is always switched on. Bit 8 specifies if the homing is made without adding the synchronous position, in order to reference the master and the slave separately.

Index	202F _h
Name	synchronisation_selector_data
Object Code	RECORD
No. of Elements	1

As of Firmware 3.2.0.1.1

Sub-Index	07 _h
Description	synchronisation_main
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	–
Value Range	see table
Default Value	–

As of Firmware 3.2.0.1.1

Bit	Value	Meaning
0	0001 _h	0: synchronisation disabled 1: synchronisation enabled
1	0002 _h	“flying saw” not possible
8	0100 _h	0: synchronous position is added while homing 1: synchronous position is not added while homing

6.11.2.6 Object 2023_h: synchronisation_filter_time

The object **synchronisation_filter_time** specifies the filter time constant of a PT1 filter by which the synchronisation speed will be smoothed. This may be necessary particularly for low line counts, because small changes of the input value here correspond to high speeds. On the other hand the drive may not be able to follow the input signal as fast as necessary due to high filter times.

Index	2023 _h
Name	synchronisation_filter_time
Object Code	VAR
Data Type	UINT32

As of Firmware 3.2.0.1.1

Access	rw
PDO Mapping	no
Units	µs
Value Range	10...50 000
Default Value	600

6.12 Analogue inputs

6.12.1 Survey

The servo controller of the contains three analogue inputs, which can be used to enter a demand value for instance For all of these inputs the following objects allow to read out the current input voltage (`analog_input_voltage`) and to determine an offset (`analog_input_offset`).

6.12.2 Description of Objects

Index	Object	Name	Type	Attr.
2400 _h	ARRAY	analog_input_voltage	INT16	ro
2401 _h	ARRAY	analog_input_offset	INT32	rw

6.12.2.1 2400_h: analog_input_voltage

The object record `analog_input_voltage` returns the current input voltage in millivolt considering the offset voltage.

Index	2400 _h
Name	analog_input_voltage
Object Code	ARRAY
No. of Elements	3
Data Type	INT16

Sub-Index	01 _h
Description	analog_input_voltage_ch_0
Access	ro
PDO Mapping	no
Units	mV
Value Range	-
Default Value	-

Sub-Index	02h
Description	analog_input_voltage_ch_1
Access	ro
PDO Mapping	no
Units	mV
Value Range	--
Default Value	--

Sub-Index	03h
Description	analog_input_voltage_ch_2
Access	ro
PDO Mapping	no
Units	mV
Value Range	--
Default Value	--

6.12.2.2 Object 2401_h: analog_input_offset (Offset Analogeingänge)

The object record **analog_input_offset** can be used to determine an offset voltage in millivolt for the respective analogue input. A positive offset compensates a positive dc offset voltage.

Index	2401h
Name	analog_input_offset
Object Code	ARRAY
No. of Elements	3
Data Type	INT32

Sub-Index	01h
Description	analog_input_offset_ch_0
Access	rw
PDO Mapping	no
Units	mV
Value Range	-10000...10000
Default Value	0

Sub-Index	02 _h
Description	analog_input_offset_ch_1
Access	rW
PDO Mapping	no
Units	mV
Value Range	-10000...10000
Default Value	0

Sub-Index	03 _h
Description	analog_input_offset_ch_2
Access	rW
PDO Mapping	no
Units	mV
Value Range	-10000...10000
Default Value	0

6.13 Digital inputs and outputs

6.13.1 Survey

All digital inputs of the servo controller can be read and almost all digital outputs can be set or reset using the can bus.

6.13.2 Description of Objects

6.13.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
60FD _h	VAR	digital_inputs	UINT32	ro
60FE _h	ARRAY	digital_outputs	UINT32	rw
2420 _h	RECORD	digital_output_state_mapping		ro
2420 _h _01 _h	VAR	dig_out_state_mapp_dout_1	UINT8	rw
2420 _h _02 _h	VAR	dig_out_state_mapp_dout_2	UINT8	rw
2420 _h _03 _h	VAR	dig_out_state_mapp_dout_3	UINT8	rw
2420 _h _11 _h	VAR	dig_out_state_mapp_ea88_0_low	UINT32	rw
2420 _h _12 _h	VAR	dig_out_state_mapp_ea88_0_high	UINT32	rw

6.13.2.2 Object 60FD_h: digital_inputs

Using object 60FD_h the digital inputs can be read out:

Index	60FD _h
Name	digital_inputs
Object Code	VAR
Data Type	UINT32

Access	ro
PDO Mapping	yes
Units	-
Value Range	according table
Default Value	0

Bit	Value	Digital input
0	00000001 _h	Negative limit switch
1	00000002 _h	Positive limit switch
2	00000004 _h	Reference switch
3	00000008 _h	Interlock (either "controller enable" or "power stage enable" is missing)
16...23	00FF0000 _h	Additional inputs of an optional EA88-module (EA88-0)
24...27	0F000000 _h	DIN0...DIN3
28	10000000 _h	DIN8
29	20000000 _h	DIN9

6.13.2.3 Object **60FE_h**: digital_outputs

The digital outputs can be set via the object **60FE_h**. For that purpose it has to be indicated which of the digital outputs are allowed to be set in the object **digital_outputs_mask**. Then the selected outputs can be set optionally via the object **digital_outputs_data**. It has to be kept in mind that a delay of up to 10 ms may occur between sending the command and a real reaction of the. The time the outputs are really set can be seen by rereading the object **60FE_h**.

Index	60FE_h
Name	digital_outputs
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01_h
Description	digital_outputs_data
Access	rW
PDO Mapping	yes
Units	-
Value Range	-
Default Value	depends on the state of the brake

Sub-Index	02_h
Description	digital_outputs_mask
Access	rW
PDO Mapping	yes
Units	-
Value Range	-
Default Value	00000000 _h

Bit	Value	Digital Outputs
0	00000001 _h	1 = Set brake, 0 = Release brake
25...27	0E000000 _h	DOUT1...DOUT3



If the **digital_output_mask** is set accordingly, the brake can be released by clearing bit 0 of **digital_output_data** immediately.

This may cause the dropping of a vertical axis.

6.13.2.4 Object 2420_h: digital_output_state_mapping

By the object group **digital_outputs_state_mapping** different controller's status messages can be output via the digital outputs.

Each of the integrated controller's digital outputs has its own subindex. Each subindex summarises 4 outputs. Thus there is one byte for each output, where the function's number has to be entered.

If a function was assigned to a digital output and the output is then switched on or switched off via the object **digital_outputs** (60FE_h), the object **digital_outputs_state_mapping** is also set to OFF(0) resp. ON(12).

Index	2420h
Name	digital_outputs_state_mapping
Object Code	RECORD
No. of Elements	5

As of Firmware 3.2.0.1.1

Sub-Index	01h
Description	dig_out_state_mapp_dout_1
Data Type	UINT8
Access	rW
PDO Mapping	no
Units	-
Value Range	0 ... 16, see table
Default Value	0

As of Firmware 3.2.0.1.1

Sub-Index	02h
Description	dig_out_state_mapp_dout_2
Data Type	UINT8
Access	rW
PDO Mapping	no
Units	-
Value Range	0 ... 16, see table
Default Value	0

As of Firmware 3.2.0.1.1

Sub-Index	03h
Description	dig_out_state_mapp_dout_3
Data Type	UINT8
Access	rW
PDO Mapping	no
Units	-
Value Range	- ... 16, see table
Default Value	0

As of Firmware 3.2.0.1.1

Value	Description
0	OFF (Output is LOW)
1	Position $X_{SET} = X_{DEST}$
2	Position $X_{ACT} = X_{DEST}$
3	Reserved
4	Remaining distance trigger
5	Homing operation active
6	Target velocity reached
7	I^2t -limit active
8	Following error

Value	Description
9	Undervoltage intermediate circuit
10	Brake released
11	Power stage released
12	No function (ON)
13	Reserved
14	Reserved
15	Linear motor identified
16	Homing position valid

6.14 Homing switches (Limit / Reference switch)

6.14.1 Survey

For the definition of the reference (zero) position of the servo controller optional limit switches or reference switches can be used. Further information concerning reference methods can be found in chapter 8.2, Operating Mode »Homing mode«..

6.14.2 Description of Objects

Index	Object	Name	Type	Attr.
6510 _h	RECORD	drive_data		rw

6.14.2.1 Object 6510_h_11_h: limit_switch_polarity

The polarity of the limit switches can be configured by the object 6510_h_11_h (limit_switch_polarity). For B-contacts (normally closed) zero has to be entered, for A-contacts (normally opened) one.

Index	6510 _h
Name	drive_data
Object Code	RECORD
No. of Elements	51

Sub-Index	11 _h
Description	limit_switch_polarity
Data Type	INT16
Access	rw
PDO Mapping	no
Units	-
Value Range	0, 1
Default Value	1

Value	Description
0	B-contact (normally closed)

1	A-contact (normally opened)
---	-----------------------------

6.14.2.2 Object 6510_h_12_h: limit_switch_selector

Using object 6510_h_12_h (**limit_switch_selector**) the assignment of the limit switches (negative, positive) can be swapped, without changing the cabling. To swap the assignment one has to be entered.

Sub-Index	12_h
Description	limit_switch_selector
Data Type	INT16
Access	rw
PDO Mapping	no
Units	-
Value Range	0, 1
Default Value	0

As of Firmware 3.5.x.1.1

Value	Meaning
0	DIN6 = E0 (limit switch negative) DIN7 = E1 (limit switch positive)
1	DIN6 = E1 (limit switch positive) DIN7 = E0 (limit switch negative)

6.14.2.3 Object 6510_h_14_h: homing_switch_polarity

The polarity of the homing switch can be configured by the object 6510_h_14_h (**homing_switch_polarity**). For B-contacts (normally closed) zero has to be entered, for A-contacts (normally opened) one.

Sub-Index	14h
Description	homing_switch_polarity
Data Type	INT16
Access	rw
PDO Mapping	no
Units	--
Value Range	0, 1
Default Value	1

Value	Description
0	B-contact (normally closed)
1	A-contact (normally opened)

6.14.2.4 Object 6510_h_13_h: homing_switch_selector

The object 6510_h_13_h (homing_switch_selector) determines whether DIN8 or DIN9 should be used as reference switch.

Sub-Index	13_h
Description	homing_switch_selector
Data Type	INT16
Access	rw
PDO Mapping	no
Units	-
Value Range	0,1
Default Value	1

Value	Description
0	DIN9
1	DIN8

6.14.2.5 Object 6510_h_15_h: limit_switch_deceleration

The object limit_switch_deceleration determines the deceleration used to stop the motor if a limit switch will be reached during normal operation (limit switch emergency stop).

Sub-Index	15_h
Description	limit_switch_deceleration
Data Type	INT32
Access	rw
PDO Mapping	no
Units	acceleration units
Value Range	0...3000000 min ⁻¹ /s
Default Value	2000000 min ⁻¹ /s

6.15 Sampling positions

6.15.1 Survey

The offer the possibility to store the actual position value at the rising or at the falling edge of a digital input. This position value can be later read and used for different purposes, e.g. for calculations within a control system.

All necessary objects are summarised in the record **sample_data**. The object **sample_mode** specifies the kind of the sampling: Should only a one-time sample event be recorded or should it be sampled continuously? By the object **sample_status** the control system can query, if a sample event has occurred. This will be signalled by a set bit, which can be also shown in the **statusword**, when the object **sample_status_mask** is correspondingly set.

The object **sample_control** is used to control the enabling of the sample events and finally the sampled positions can be read via the objects **sample_position_rising_edge** und **sample_position_falling_edge**.

In the menu Parameters / IOs / Digital Inputs / Sample-Input in the™ can be specified, which digital input will be used.

6.15.2 Description of Objects

6.15.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
204A _h	RECORD	sample_data		ro
204A _h _01 _h	VAR	sample_mode	UINT16	rw
204A _h _02	VAR	sample_status	UINT8	ro
204A _h _03 _h	VAR	sample_status_mask	UINT8	rw
204A _h _04 _h	VAR	sample_control	UINT8	wo
204A _h _05 _h	VAR	sample_position_rising_edge	INT32	ro
204A _h _06 _h	VAR	sample_position_falling_edge	INT32	ro

6.15.2.2 Object 204A_h: sample_data

Index	204A _h
Name	sample_data
Object Code	RECORD
No. of Elements	6

As of Firmware 3.2.0.1.1

The following object determines, if the position is acquired on each sample event (continuous sampling) or if the sampling should be inhibited after a sample event, until the sampling is restarted. Please consider here, that a bouncing could have already activated both edges.

Sub-Index	01 _h
Description	sample_mode
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	-
Value Range	0 ... 1, see table
Default Value	0

As of Firmware 3.2.0.1.1

Value	Meaning
0	continuous sampling
1	auto lock sampling

The following object indicates a new sample event.

Sub-Index	02 _h
Description	sample_status
Data Type	UINT8
Access	ro
PDO Mapping	yes
Units	-
Value Range	0 ... 3, see table
Default Value	0

As of Firmware 3.2.0.1.1

Bit	Value	Name	Description
0	01 _h	falling_edge_occurred	1 = New sample position (falling edge)
1	02 _h	rising_edge_occurred	1 = New sample position (rising edge)

With the following object the bits of the object **sample_status** can be specified, which should cause the setting of bit 15 in the **statusword**. Thereby it is possible to have the information “sample event occurred” in the **statusword**, which may be transmitted cyclically anyhow. Only if this bit is set in the **statusword** it is necessary to read the **sample_status** additionally to find out if the falling or rising edge has occurred.

Sub-Index	03h	
Description	sample_status_mask	
Data Type	UINT8	
Access	rw	
PDO Mapping	yes	
Units	-	
Value Range	0 ... 3, see table	
Default Value	0	

As of Firmware 3.2.0.1.1

Bit	Value	Name	Description
0	01h	falling_edge_visible	If falling_edge_occured = 1 => statusword Bit 15 = 1
1	02h	rising_edge_visible	If rising_edge_occurred = 1 => statusword Bit 15 = 1

The setting of the respective bits in **sample_control** causes the reset of the corresponding status bit in **sample_status** and in the case of “autolock” sampling the sampling is released again.

Sub-Index	04h	
Description	sample_control	
Data Type	UINT8	
Access	WO	
PDO Mapping	yes	
Units	-	
Value Range	0 ... 3, see table	
Default Value	0	

As of Firmware 3.2.0.1.1

Bit	Value	Name	Description
0	01 _h	falling_edge_enable	Allow sampling on falling edge
1	02 _h	rising_edge_enable	Allow sampling on rising edge

The following objects contain the sampled positions.

Sub-Index	05h
Description	sample_position_rising_edge
Data Type	INT32
Access	ro
PDO Mapping	yes
Units	position units
Value Range	-
Default Value	-

As of Firmware 3.2.0.1.1

Sub-Index	06h
Description	sample_position_falling_edge
Data Type	INT32
Access	ro
PDO Mapping	yes
Units	position units
Value Range	-
Default Value	-

As of Firmware 3.2.0.1.1

6.16 Brake control

6.16.1 Survey

Using the following objects it can be determined how a possibly existing motor brake will be controlled by the servo controller. The brake will always be released if the controller is enabled, i.e. if the external and internal enable is present. For the use of brakes with a high inertia a delay time can be determined to ensure the brake is locked before the power stage switches off (Dropping of vertical axis). This delay time can be set via the object **brake_delay_time**. As can be seen in the following figure the velocity demand value will be delayed for the **brake_delay_time** after enabling the servo controller. Equally the deactivation of the power stage will be delayed when disabling the servo controller.




Figure 6.10: Function of brake delay (in Operating Mode Profile Velocity Mode and Operating Mode »Profile Position Mode«)

6.16.2 Description of Objects

Index	Object	Name	Type	Attr.
6510 _h	RECORD	drive_data		rw

6.16.2.1 Object 6510_h_18_h: brake_delay_time

With the object **brake_delay_time** the delay of the brake can be configured.

Index	6510 _h
Name	drive_data
Object Code	RECORD
No. of Elements	51

Sub-Index	18 _h
Description	brake_delay_time
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	ms
Value Range	0...32000
Default Value	0

6.17 Device informations

Index	Object	Name	Type	Attr.
1018h	RECORD	identity_object		rw
6510h	RECORD	drive_data		rw

A huge number of CAN objects have been implemented to read out several device informations like type of servo controller, firmware revision and so on.

6.17.1 Description of Objects

6.17.1.1 Object 1018_h: identity_object

To identify the servo controller uniquely in a CANopen-network the **identity_object** according to the DS301 can be used.

A unique manufacturer code (**vendor_id**), a unique product code (**product_code**), the revision number of the CANopen implementation (**revision_number**) and the device serial number (**serial_number**) can be read.

Index	1018 _h
Name	identity_object
Object Code	RECORD
No. of Elements	4

Sub-Index	01 _h
Description	vendor_id
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	-
Value Range	000000E4
Default Value	000000E4

Sub-Index	02_h
Description	product_code
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	-
Value Range	S.U.
Default Value	S.U.

Value	Description
2045 _h	C 1-02
2046 _h	C 1-05
2050 _h	
204A _h	C 3-05
204B _h	C 3-10

Sub-Index	03_h
Description	revision_number
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	MMMMSSSS _h (M: main version, S: sub version)
Value Range	-
Default Value	-

Sub-Index	04_h
Description	serial_number
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	-
Value Range	-
Default Value	-

6.17.1.2 Object 6510_h_A0_h: drive_serial_number

With the object **drive_serial_number** the serial number of the servo controller can be read. This object is implemented because of terms of compatibility to older versions.

Index	6510 _h
Name	drive_data
Object Code	RECORD
No. of Elements	51

Sub-Index	A0 _h
Description	drive_serial_number
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	-
Value Range	-
Default Value	-

6.17.1.3 Object 6510_h_A1_h: drive_type

The object **drive_type** returns the type of servo controller. This object is implemented because of terms of compatibility to older versions.

Sub-Index	A1 _h
Description	drive_type
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	
Value Range	see 1018 _h _02 _h , product_code
Default Value	see 1018 _h _02 _h , product_code

6.17.1.4 Object 6510_h_A9_h: firmware_main_version

The object **firmware_main_version** returns the main revision index of the firmware (product step).

Sub-Index	A9 _h
Description	firmware_main_version
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	MMMMSSSS _h (M: main version, S: sub version)
Value Range	-
Default Value	-

6.17.1.5 Object 6510_h_AA_h: firmware_custom_version

The object **firmware_custom_version** returns the version number of the customer-specific variant of the firmware.

Sub-Index	AA _h
Description	firmware_custom_version
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	MMMMSSSS _h (M: main version, S: sub version)
Value Range	-
Default Value	-

6.17.1.6 Object 6510_h_AD_h: km_release

The version information **km_release** allows differentiating firmware versions of the same product step (**firmware_main_version**).

Sub-Index	AD_h
Description	km_release
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	--
Value Range	MMMMSSSS _h (M: main version, S: sub version)
Default Value	--

As of Firmware 3.5.x.1.1

6.17.1.7 Object 6510_h_AC_h: firmware_type

With the object **firmware_type** it can be determined for what type of device and encoder module the firmware is suitable. For the the encoder interface can not be plugged anymore. Consequently the parameter G will always return F_h.

Sub-Index	AC _h
Description	firmware_type
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	000000GX _h
Value Range	00000F2 _h
Default Value	00000F2 _h

Value (X)	Description
0 _h	IMD-F
1 _h	ARS
2 _h	ARS 2000

6.17.1.8 Object 6510_h_B0_h: cycletime_current_controller

The object **cycletime_current_controller** returns the period of the current control loop in microseconds.

Sub-Index	B0 _h
Description	cycletime_current_controller
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	μs
Value Range	-
Default Value	00000068 _h

6.17.1.9 Object 6510_h_B1_h: cycletime_velocity_controller

The object **cycletime_velocity_controller** returns the period of the velocity control loop in microseconds.

Sub-Index	B1 _h
Description	cycletime_velocity_controller
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	μs
Value Range	-
Default Value	000000D0 _h

6.17.1.10 Object 6510_h_B2_h: cycletime_position_controller

The object **cycletime_position_controller** returns the period of the position control loop in microseconds.

Sub-Index	B2 _h
Description	cycletime_position_controller
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	μs
Value Range	-
Default Value	000001A0 _h

6.17.1.11 Object 6510_h_B3_h: cycletime_trajectory_generator

The object **cycletime_trajectory_generator** returns the period of the positioning unit in microseconds.

Sub-Index	B3 _h
Description	cycletime_trajectory_generator
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	μs
Value Range	-
Default Value	00000341 _h

6.17.1.12 Object 6510h_C0h: commissioning_state

The parametrization program™ uses the object **commissioning_state** to mark what kinds of parameters have already been adjusted. The default state of this object when delivered and after **restore_default_parameter** is zero. In this case the display of the servo controller shows an "A", to indicate that no suitable parametrization has been done. For a complete set-up via CANopen it is necessary to set at least one bit of this object to suppress the "A". Of course it is possible to use this object for own applications. In this case it has to be kept in mind that™ uses this object, too.

Sub-Index	C0h
Description	commissioning_state
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	-
Value Range	-
Default Value	0

Bit	Description	Bit	Description
0	motor rated current valid	8	Current controller gain valid
1	max_current valid	9	Reserved
2	Number of poles valid	10	Conversion factors valid
3	encoder offset / direction valid	11	velocity controller valid
4	Reserved	12	position controller valid
5	hall encoder offset / direction valid	13	Safety parameter valid
6	Reserved	14	Reserved
7	Absolute position encoder valid	15	Polarity of home switch valid
		16...31	Reserved



Caution!

The object **commissioning_state** does not contain any information if the servo controller has been parametrised correctly according to the specific application. It will only be used to mark if the corresponding item has been parametrised at all.



"A" on 7 segment display

Note that at least one bit in the object `commissioning_state` has to be set, to suppress the "A" on the display of the servo controller.

6.18 Error management

6.18.1 Survey

The offer the possibility to change the error reaction of individual events, e.g. the occurrence of a following error. Thus the controller reacts different, when a certain event occurs. Depending on the settings, the drive can be decelerated, the power stage will be disabled immediately or a warning is shown on the display.

For each event a manufacturer-specific minimum error reaction, which cannot be fallen below. In that way “critical” errors like 06 0 short circuit cannot be parametrised, because an immediate deactivation is necessary, in order to protect the servo controller from damages.

If an error reaction is set to a reaction, which is lower than the minimum allowed reaction for this error, then it is set to the minimum allowed error reaction automatically. A list with all error codes is available in the manual “”.

6.18.2 Description of Objects

6.18.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
2100 _h	RECORD	error_management		ro
2100 _h _01 _h	VAR	error_number	UINT8	rw
2100 _h _02 _h	VAR	error_reaction_code	UINT8	rw

6.18.2.2 Object 2100_h: error_management

Index	2100 _h
Name	error_management
Object Code	RECORD
No. of Elements	2

As of Firmware 3.2.0.1.1

The object **error_number** contains the main error code, which reaction must be changed. The main error code is normally displayed before the hyphen, (e.g. error 08-2, main error code 8). For possible error codes see hereunto chapter 5.5.

Sub-Index	01_h
Description	error_number
Data Type	UINT8
Access	rw
PDO Mapping	no
Units	-
Value Range	1 ... 96
Default Value	1

As of Firmware 3.2.0.1.1

In the object **error_reaction_code** the reaction to the error can be changed. If the manufacturer's minimum reaction is fallen below, then the reaction will be restricted to the minimum reaction. The actual adjusted reaction can be aquired via reading the object.

Sub-Index	02_h
Description	error_reaction_code
Data Type	UINT8
Access	rw
PDO Mapping	no
Units	-
Value Range	0, 1, 3, 5, 7, 8
Default Value	depends on error_number

As of Firmware 3.2.0.1.1

Value	Meaning
0	No action
1	Entry in the buffer
3	Warning on the 7 segment display
5	Disable controller
7	Brake with maximum current
8	Disable power stage

6.18.2.3 Objekt 200F_h: last_warning_code

Warnings are mentionable events that will not stop the movement of the drive (e.g. following error). Warnings will be displayed on the 7- segment display of the servo controller and will disappear automatically.

The last occurred warning can be read by this object. Bit 15 shows if the warning is still active.

Index	200F _h
Name	last_warning_code
Object Code	VAR
Data Type	UINT16

As of Firmware 3.5.x.1.1

Access	r0
PDO Mapping	yes
Units	-
Value Range	-
Default Value	-

Bit	Wert	Beschreibung
0... 3	000F _h	Sub code of warning
4... 11	OFF0 _h	Main code of warning
15	8000 _h	Warning is active

7 Device Control

7.1 State diagram (State machine)

7.1.1 Survey

The following chapter describes how to control the servo controller using CANopen, i.e. how to switch on the power stage or to reset an error.

Using CANopen the complete control of the servo is done by two objects. Via the **controlword** the host is able to control the servo, as the status of the servo can be read out of the **statusword**. The following items will be used in this chapter:

State: The servo controller is in different states dependent on for instance if the power stage is alive or if an error has occurred. States defined under CANopen will be explained in this chapter.

Example: **SWITCH_ON_DISABLED**

State Transition: Just as the states it is defined as well how to move from one state to another (e.g. to reset an error). These state transitions will be either executed by the host by setting bits in the **controlword** or by the servo controller itself, if an error occurs for instance.

Command: To initiate a state transition defined bit combinations have to be set in the **controlword**. Such bit combinations are called command.

Example: **Enable Operation**

State diagram: All the states and all state transitions together form the so called state diagram: A survey of all states and the possible transitions between two states.

7.1.2 The state diagram of the servo controller




Figure 7.11: State diagram of the servo controller

The state diagram can be divided into three main parts: "Power Disabled" means the power stage is switched off and "Power Enabled" the power stage is live. The area "Fault" contains all states necessary to handle errors of the controller.

The most important states have been highlighted in the Figure: After switching on the servo controller initialises itself and reaches the state **SWITCH_ON_DISABLED** after all. In this state CAN communication is possible and the servo controller can be configured (e.g. the mode of operation can be set to "velocity control"). The power stage remains switched off and the motor shaft is freely rotatable. Through the state transitions **2**, **3** and **4** – principally like the controller enable under CANopen – the state **OPERATION_ENABLE** will be reached. In this state the power stage is live and the servo controller controls the motor according to the configured mode of operation. Therefore previously ensure that the servo controller has been configured correctly and the according demand value is zero.

The state transition **9** complies with disabling the power stage, i.e. the motor is freely rotatable.

In case of a fault the servo controller branches independent of the current state lately to the state FAULT. Dependent on the seriousness of the fault several actions can be executed before, for instance an emergency stop (FAULTREACTIONACTIVE).

To execute the mentioned state transitions defined bit combinations have to be set in the controlword. To that the lower 4 bits of the controlword will be evaluated commonly. At first only the important transitions 2, 3, 4, 9 and 15 will be explained. A table of all possible transitions can be found at the end of this chapter.

The following chart contains the desired state transition in the 1st column. The 2nd column contains the condition for the transition (mostly a command by the host, here marked with a frame). How the command has to be built, i.e. what bits have to be set in the controlword, will be shown in the 3rd column (x = not relevant).

No.	Executed if	Bit combination (controlword)						Action
		Bit	3	2	1	0		
2	"Enable controller" + "Enable power stage" applying + Command Shutdown	Shutdown	=	x	1	1	0	None
3	Command Switch On	Switch On	=	x	1	1	1	Power stage will be switched on
4	Command Enable Operation	Enable Operation	=	1	1	1	1	Motor is controlled according to modes_of_operation
9	Command Disable Voltage	Disable Voltage	=	x	x	0	x	Power stage is disabled. The motor is freely rotatable
15	Cause of fault remedied + Command Fault Reset	Fault Reset	=	Bit 7 = 				Reset fault

Figure 7.12: Most important state transitions

EXAMPLE



After the servo controller has been configured it should be enabled, i.e. the power stage should be switched on:

- 1.) The servo is in the state SWITCH_ON_DISABLED.
- 2.) The state OPERATION_ENABLE should be reached.
- 3.) In accordance to the state diagram (Figure 7.11) the state transitions 2, 3 and 4 have to be executed.
- 4.) From
- 5.) Figure 7.12 follows:

Transition 2:	controlword = 0006 _h	New state: READY_TO_SWITCH_ON * ¹⁾
Transition 3:	controlword = 0007 _h	New state: SWITCHED_ON * ¹⁾
Transition 4:	controlword = 000F _h	New state: OPERATION_ENABLE * ¹⁾

Hints:

- 1.) The example implies that no more bits in the **controlword** are set. (For the state transitions only the bits 0..3 are necessary).
- 2.) The state transitions 3 and 4 can be combined by setting the **controlword** to 000F_h directly. For the state transition 3 the set bit 3 is irrelevant.

*¹⁾ The host has to wait until the requested state can be read in the **statusword**. This will be explained more exact in the following chapter.

7.1.2.1 State diagram: States

In the following table all states and their meaning are listed:


Name	Meaning
NOT_READY_TO_SWITCH_ON	The servo controller executes its selftest. The CAN communication is not working
SWITCH_ON_DISABLED	The selftest has been completed. The CAN communication is activated..
READY_TO_SWITCH_ON	The servo controller waits until the digital inputs "Enable controller" + "Enable power stage" are connected to 24V. (controller enable logic is set to "digital inputs and CAN")
SWITCHED_ON * ¹⁾	The power stage is alive.
OPERATION_ENABLE * ¹⁾	The motor is under voltage and is controlled according to operational mode
QUICKSTOP_ACTIVE * ¹⁾	The Quick Stop Function will be executed (see: quick_stop_option_code). The motor is under voltage and is controlled according to the Quick Stop Function .
FAULTREACTION_ACTIVE * ¹⁾	An error has occurred. On critical errors switching to state Fault . Otherwise the action according to the fault_reaction_option_code will be executed. The motor is under voltage and is controlled according to the Fault Reaction Function .
FAULT	An error has occurred. The power stage has been switched off.

*¹⁾ The power stage is alive

7.1.2.2 State diagram: State transitions

The following table lists all state transitions and their meaning:

No.	Executed if	Bit combination (controlword)					Action	
		Bit	3	2	1	0		
0	"Power on" or Reset	internal transition					Execute selftest	
1	Self test successful	internal transition					Activation of the CAN communication	
2	"Enable controller" + "Enable power stage" applying + Command Shutdown	Shutdown	=	x	1	1	0	None

No.	Executed if	Bit combination (controlword)						Action
		Bit	3	2	1	0		
3	Command Switch On	Switch On	=	x	1	1	1	Power stage will be switched on
4	Command Enable Operation	Enable Operation	=	1	1	1	1	Motor is controlled according to operation mode
5	Command Disable Operation	Disable Operation	=	0	1	1	1	Power stage is disabled. Motor is freely rotatable
6	Command Shutdown	Shutdown	=	x	1	1	0	Power stage is disabled. Motor is freely rotatable
7	Command Quick Stop	Quick Stop	=	x	0	1	x	
8	Command Shutdown	Shutdown	=	x	1	1	0	Power stage is disabled. Motor is freely rotatable
9	Command Disable Voltage	Disable Voltage	=	x	x	0	x	Power stage is disabled. Motor is freely rotatable
10	Command Disable Voltage	Disable Voltage	=	x	x	0	x	Power stage is disabled. Motor is freely rotatable
11	Command Quick Stop	Quick Stop	=	x	0	1	x	A braking according to quick_stop_option_code is started.
12	Braking has ended or Command Disable Voltage	Disable Voltage	=	x	x	0	x	Power stage is disabled. Motor is freely rotatable
13	Error occurred	internal transition						On non-critical errors reaction according to fault_reaction_option_code . On critical error executing transition 14.
14	Error treating has ended	internal transition						Power stage is disabled. Motor is freely rotatable
15	Cause of fault remedied + Command Fault Reset	Fault Reset	=	Bit 7 = 				Reset fault (Rising edge)

Power stage disabled



This means the transistors are not driven anymore. **If this state is reached on a rotating motor, the motor coasts down without being braked**. If a mechanical motor brake is available it will be locked.

Caution: This does not ensure that the motor is not under voltage.

**Power stage enabled**

This means the motor will be controlled according to the chosen mode of operation. If a mechanical motor brake is available it will be released. A defect or an incorrect parameter set-up (Motor current, number of poles, resolver offset angle, etc.) may cause an uncontrolled behaviour of the motor.

7.1.3 controlword

7.1.3.1 Object 6040_h: controlword

Via the **controlword** the state of the servo controller can be changed or a designated action (e.g. starting homing operation) can be executed directly. The meaning of the bits 4, 5, 6 and 8 depends on the actual operation mode (**modes_of_operation**), which will be explained in the chapter hereafter.

Index	6040 _h
Name	controlword
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	-
Value Range	-
Default Value	0

Bit	Value	Function	
0	0001 _h		
1	0002 _h	Initiating state transitions. (Bits will be evaluated commonly)	
2	0004 _h		
3	0008 _h		
4	0010 _h	new_set_point / start_homing_operation / enable_ip_mode	
5	0020 _h	change_set_immediately	
6	0040 _h	absolute / relative	
7	0080 _h	reset_fault	
8	0100 _h	halt	
9	0200 _h	reserved	set to 0
10	0400 _h	reserved	set to 0
11	0800 _h	reserved	set to 0
12	1000 _h	reserved	set to 0
13	2000 _h	reserved	set to 0
14	4000 _h	reserved	set to 0
15	8000 _h	reserved	set to 0

Table 7.1: Bit assignment of the controlword

As described detailed in the previous chapter the bits 0..3 are used to execute state transitions. The necessary commands are summarised in the following chart. The command **Fault Reset** will be executed on a rising edge of bit 7 (from 0 to 1).

command:	Bit 7	Bit 3	Bit 2	Bit 1	Bit 0
	0080 _h	0008 _h	0004 _h	0002 _h	0001 _h
Shutdown	×	×	1	1	0
Switch On	×	×	1	1	1
Disable Voltage	×	×	×	0	×
Quick Stop	×	×	0	1	×
Disable Operation	×	0	1	1	1
Enable Operation	×	1	1	1	1
Fault Reset	↑	×	×	×	×

Table 7.2: Survey of all commands (x = not relevant)



As some state transitions take time for processing, all changes written into the **controlword** have to read back from the **statusword**. Only when the requested status can be read in the **statusword**, one may write in further commands using the **controlword**.

Following the remaining bits of the **controlword** will be explained. The meaning of some bits depends on the actual operation mode (object **modes_of_operation**), i.e. if the controller will be torque or velocity controlled.

Bit 4

Depending on: **modes_of_operation**:

new_set_point

On **Profile Position Mode**:

A rising edge signals that a new position parameter set should be taken over. In any case see chapter 8.3 as well.

start_homing_operation

On **Homing Mode**:

A rising edge starts the configured search for reference. A falling edge stops the search immediately.

enable_ip_mode

On **Interpolated Position Mode**:

This bit has to be set to evaluate the interpolation data. It will be acknowledged by the bit **ip_mode_active** in the **statusword**. In any case see chapter 8.4 as well.

Bit 5	<code>change_set_immediately</code>	Only on Profile Position Mode :
		If this bit is cleared a current positioning order will be processed before starting a new one. If this bit is set a current positioning order will be interrupted by the new one. See also chapter 8.3.
Bit 6	<code>relative</code>	Only on Profile Position Mode :
		If this bit is set, the target_position of the current positioning job will be added to the position_demand_value of the position controller.
Bit 7	<code>reset_fault</code>	
		On a rising edge the servo controller tries to reset the present errors. This will only succeed if the cause of error has been remedied.
Bit 8		Depending on modes_of_operation :
	<code>halt</code>	On Profile Position Mode :
		If this bit is set the current positioning will be cancelled according to the object profile_deceleration . After stopping the bit target_reached (statusword) will be set. Resetting this bit has no effect.
	<code>halt</code>	On Profile Velocity Mode :
		If this bit is set the velocity will be reduced to zero according to the profile_deceleration . Resetting this bit will accelerate the motor again.
	<code>halt</code>	On Profile Torque Mode :
		If this bit is set the torque will be reduced to zero according to the torque_slope . Resetting this bit will accelerate the motor again
	<code>halt</code>	On Homing mode :
		If this bit is set the current homing operation will be cancelled and a homing error will be generated. Resetting this bit has no effect.

7.1.4 Reading the status of the servo controller

Similar to initiating several commands by setting bits of the **controlword**, the state of the servo controller can be read by specific bit combinations in the **statusword**.

The following chart lists all states of the state diagram and their respective bit combination occurring in the **statusword**.

State	Bit 6	Bit 5	Bit 3 0008 _h	Bit 2 0004 _h	Bit 1 0002 _h	Bit 0 0001 _h	Mask	Value
	0040 _h	0020 _h						
NOT_READY_TO_SWITCH_ON	0	×	0	0	0	0	004F _h	0000 _h
SWITCH_ON_DISABLED	1	×	0	0	0	0	004F _h	0040 _h
READY_TO_SWITCH_ON	0	1	0	0	0	1	006F _h	0021 _h
SWITCHED_ON	0	1	0	0	1	1	006F _h	0023 _h
OPERATION_ENABLE	0	1	0	1	1	1	006F _h	0027 _h
QUICK_STOP_ACTIVE	0	0	0	1	1	1	006F _h	0007 _h
FAULTREACTION_ACTIVE	0	×	1	1	1	1	004F _h	000F _h
FAULT	0	×	1	1	1	1	004F _h	000F _h
FAULT (accord. DS402) ¹⁾	0	×	1	0	0	0	004F _h	0008 _h

Table 7.3: States of device (× = not relevant)

¹⁾:



In previous CANopen implementations the state FAULT has not been displayed according to DS 402.

Therefore it is possible to change this behaviour by setting Bit 7 of the object **compatibility_control** (see Chapter 6.2):

For compatibility to previous versions no changes have to be done and the numbers up to now can still be used.



EXAMPLE

The above mentioned example shows, what bits in the **controlword** have to be set to enable the servo controller. Now the requested state should be read out of the **statusword**:

Transition from **SWITCH_ON_DISABLED** to **OPERATION_ENABLE**:

- 1.) Write state transition 2 into the **controlword**.
- 2.) Wait until state **READY_TO_SWITCH_ON** occurs in the **statusword**.

Transition 2: controlword = 0006_h Wait until (statusword & 006F_h) = 0021_h ^{*1)}

- 3.) The state transitions 3 and 4 can be written combined into the **controlword**.
- 4.) Wait, until the state **OPERATION_ENABLE** occurs in the **statusword**.

Transition 3+4: controlword = 000F_h Wait until (statusword & 006F_h) = 0027_h ^{*1)}

Hint:

- 3.) The example implies, that no more bits in the **controlword** are set. (For the state transitions only the bits 0..3 are necessary).

^{*1)}To identify a state also cleared bits have to be evaluated (see table). Therefore the **statusword** has to be masked properly.

7.1.5 statusword

7.1.5.1 Object 6041_h: statusword

Index	6041 _h
Name	statusword
Object Code	VAR
Data Type	UINT16

Access	ro
PDO Mapping	yes
Units	-
Value Range	-
Default Value	-

Bit	Value	Name
0	0001 _h	
1	0002 _h	State of the servo controller (see Table 7.3)
2	0004 _h	(These bits have to be evaluated commonly)
3	0008 _h	
4	0010h	voltage_enabled
5	0020 _h	
6	0040 _h	State of the servo controller (see Table 7.3)
7	0080 _h	warning
8	0100 _h	drive_is_moving
9	0200 _h	remote
10	0400 _h	target_reached
11	0800 _h	internal_limit_active
12	1000 _h	set_point_acknowledge / speed_0 / homing_attained / ip_mode_active
13	2000 _h	following_error / homing_error
14	4000 _h	manufacturer_statusbit
15	8000 _h	trigger_result

Table 7.4: Bit assignment of the statusword



All bits of the **statusword** are not buffered and therefore representing the actual state of the device.

In addition to the state of the device several informations can be read out directly of the **statusword**, i.e. every bit is assigned a specific event like a following error. The meaning of the bits is as follows:

Bit 4 voltage_enabled

This bit is set if the transistors of the power stage switched OFF.

If Bit 7 of object **6510h_F0h (compatibility_control)** is set (see Chapter 6.2) ¹⁾:

This bit is set if the transistors of the power stage switched ON.

**CAUTION:**

On a defect the motor may still be under voltage.

Bit 5 quick_stop

If this bit is cleared a Quick Stop will be executed according to the **quick_stop_option_code**.

Bit 7 warning

This bit is set if there is an inhibited rotating direction, because a limit switch has been activated. The setpoint inhibition is cleared, when the faults are reset. (see **controlword**, **fault_reset**)

Bit 8 drive_is_moving

manufacturer specific

This bit is – independent of **modes_of_operation** – set, if the **velocity_actual_value** is outside the window determined by the object **velocity_threshold**.

Bit 9 remote

This bit indicates that the power stage can be enabled via the can bus. It is set if the object **enable_logic** is set accordingly.

1).



In previous CANopen implementations Bit 4 (**voltage_enabled**) has not been displayed according to DS 402. Therefore it is possible to changes this behaviour by setting Bit 7 of the object **compatibility_control** (see Chapter 6.2):
For compatibility to previous versions no changes have to be done and the numbers up to now can still be used.

Bit 10

Depends on **modes_of_operation**:

target_reached

On **Profile Position Mode**:

This bit will be set if the actual position (**position_actual_value**) is within the configured position window (**position_window**).

It will also be set if the motor stops after setting the bit **halt** in the **controlword**.

It will be cleared if a new positioning is started.

`target_reached`

On **Profile Velocity Mode**:

The bit will be set if the actual velocity (`velocity_actual_value`) is within the configured velocity window (`velocity_window`, `velocity_window_time`).

Bit 11 `internal_limit_active`

This bit indicates that the iit limitation is active.

Bit 12

Depends on `modes_of_operation`:

`set_point_acknowledge`

On **Profile Position Mode**:

This bit will be set to acknowledge the bit `new_set_point` in the `controlword`. It will be cleared if the bit `new_set_point` will be cleared. See chapter 8.3 as well.

`speed_0`

On **Profile Velocity Mode**:

This bit will be set if the `velocity_actual_value` is within the window determined by the object `velocity_threshold`.

`homing_attained`

On **Homing mode**:

This bit will be set if the homing operation has been finished without an error.

`ip_mode_active`

On **Interpolated Position Mode**:

This bit signals an active interpolation, i.e. interpolation data is evaluated. It will be set if requested by the bit `enable_ip_mode` in the `controlword`. In any case see chapter 8.4 as well.

Bit 13	Depends on modes_of_operation :
following_error	<p>On Profile Position Mode:</p> <p>This bit will be set if the position_actual_value differs from the position_demand_value so much that the difference is out of the tolerance window determined by the objects following_error_window and following_error_time_out.</p>
homing_error	<p>On Homing Mode:</p> <p>This bit will be set if a homing operation was cancelled by setting the bit halt in the controlword, if both limit switches are closed or the search for the switch exceeds the predefined positioning limits (min_position_limit, max_position_limit).</p>
Bit 14 manufacturer_statusbit	<i>manufacturer specific</i>
	<p>The meaning of this bit can be configured:</p> <p>It can be set if one or more user-defined bits of the manufacturer_statusword_1 will be set or reset.</p> <p>See Chapter 7.1.5.2 for details.</p>
Bit 15 trigger_result	<i>manufacturer specific</i>
	<p>The meaning of this bit can be configured:</p> <p>It is set, when a sample event has occurred and the sample mask is set correspondingly. See herewith chapter 6.15.</p>

7.1.5.2 Object 2000_h: manufacturer_statuswords

The record **manufacturer_statuswords** was introduced in order to represent controller states, which must not be contained in the cyclic polled **statusword**.

Index	2000 _h
Name	manufacturer_statuswords
Object Code	RECORD
No. of Elements	1

As of Firmware 3.3.x.1.1

Sub-Index	01 _h
Description	manufacturer_statusword_1
Data Type	UINT32
Access	ro
PDO Mapping	yes
Units	–
Value Range	–
Default Value	–

As of Firmware 3.3.x.1.1

Bit	Value	Name	
0	00000001 _h	is_referenced	As of Firmware 3.3.x.1.1
1	00000002 _h	commutation_valid	As of Firmware 3.5.x.1.1
2	00000004 _h	ready_for_enable	As of Firmware 3.5.x.1.1
...			
31	80000000 _h	–	

Table 7.5: Bit assignment of manufacturer_statusword_1

Bit 0 is_referenced

This bit indicates, if the drive is referenced. The drive is referenced if a homing has been finished successfully or if there is no need of homing due to the connected encoder system (e.g. if an absolute angle encoder is used).

Bit 1 commutation_valid

This bit is set if the commutation information is valid. It is helpful if an encoder without commutation information is used (e.g. linearmotor), as the process for detection of commutation position may take several time. To avoid a timeout within a plc, this bit can be monitored.

Bit 2 ready_for_enab


This bit will be set if all other conditions for enabling the servo controller are available, except the *controller enable* itself.

The following conditions are fulfilled if this bit is set:

- The servo is error-free
- The dc bus is charged completely
- The encoder evaluation is ready. No process inhibiting enabling (e.g. serial communication) is active
- No locking process is active (e.g. the process for detecting the motor parameter)

By means of `manufacturer_status_masks` and `manufacturer_status_invert` one or more bit of the `manufacturer_statuswords` can be mapped into bit 14 (`manufacturer_statusbit`) of the `statusword` (`6041h`). All bits of the `manufacturer_statusword_1` can be previously inverted by the corresponding bit of the object `manufacturer_status_invert_1`. Thereby it is possible to check if a bit is reset. After inverting the bits, the bits are masked, i.e. only if the corresponding bit of the `manufacturer_status_mask_1` is set, this bit will furthermore take effect. If after masking at least one bit is set, bit 14 of the `statusword` will be set as well.

The following illustration exemplifies these objects:



EXAMPLE



- A) Bit 14 of the **statusword** should be set, if the drive is referenced. *is_referenced* is Bit 0 of the **manufacturer_statusword_1**
- manufacturer_status_invert** = 0x00000000
manufacturer_status_mask = 0x00000001 (bit 0)
- B) Bit 14 of the **statusword** should be set, if the drive has no valid commutation information. *commutation_valid* is Bit 1 of the **manufacturer_statusword_1**. This bit has to be inverted, to be set, if the commutation information is invalid:
- manufacturer_status_invert** = 0x00000002 (bit 1)
manufacturer_status_mask = 0x00000002 (bit 1)
- C) Bit 14 of the **statusword** should be set, if the drive is not ready for enabling OR the drive is referenced: *commutation_valid* is Bit 2 of the **manufacturer_statusword_1**. *is_referenced* is Bit 0. Bit 2 has to be inverted, to be set, if the drive is not ready for enabling:
- manufacturer_status_invert** = 0x00000004 (bit 2)
manufacturer_status_mask = 0x00000005 (bit 2, bit 0)

7.1.5.3 Objekt 2005_h: manufacturer_status_masks

This object record defines all bits of the **manufacturer_statuswords** that should be mapped into the **statusword**. See also chapter 7.1.5.2

Index	2005 _h
Name	manufacturer_status_masks
Object Code	RECORD
No. of Elements	1

As of Firmware 3.5.x.1.1

Sub-Index	01 _h
Description	manufacturer_status_mask_1
Data Type	UINT32
Access	rw
PDO Mapping	yes
Units	--
Value Range	--
Default Value	0x00000000

As of Firmware 3.5.x.1.1

7.1.5.4 Objekt 200A_h: manufacturer_status_invert

This object record defines all bits of the **manufacturer_statuswords** that should be mapped inverted into the statusword. See also chapter 7.1.5.2

Index	200A _h
Name	manufacturer_status_invert
Object Code	RECORD
No. of Elements	1

As of Firmware 3.5.x.1.1

Sub-Index	01 _h
Description	manufacturer_status_invert_1
Data Type	UINT32
Access	rw
PDO Mapping	yes
Units	-
Value Range	-
Default Value	0x00000000

As of Firmware 3.5.x.1.1

7.1.6 Description of Objects

7.1.6.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
605B _h	VAR	shutdown_option_code	INT16	rw
605C _h	VAR	disable_operation_option_code	INT16	rw
605A _h	VAR	quick_stop_option_code	INT16	rw
605E _h	VAR	fault_reaction_option_code	INT16	rw

7.1.6.2 Object 605B_h: shutdown_option_code

The object `shutdown_option_code` determines the behaviour if the state transition 8 (from **OPERATION ENABLE** to **READY TO SWITCH ON**) will be executed. The object indicates the implemented behaviour of the controller and cannot be configured.

Index	605B _h
Name	shutdown_option_code
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	no
Units	-
Value Range	0
Default Value	0

Value	Name
0	Power stage will be switched off. Motor is freely rotatable.

7.1.6.3 Object 605C_h: disable_operation_option_code

The object **disable_operation_option_code** determines the behaviour if the state transition 5 (from **OPERATION ENABLE** to **SWITCHED ON**) will be executed. The object indicates the implemented behaviour of the controller and cannot be configured.

Index	605C _h
Name	disable_operation_option_code
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	no
Units	-
Value Range	-1
Default Value	-1

Value	Name
-1	Slow down motor with quickstop_deceleration.

7.1.6.4 Object 605A_h: quick_stop_option_code

The object **quick_stop_option_code** determines the behaviour if a **Quick Stop** will be executed. The object indicates the implemented behaviour of the controller and cannot be configured.

Index	605A _h
Name	quick_stop_option_code
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	no
Units	-
Value Range	2
Default Value	2

Value	Description
2	Slow down motor with quickstop_deceleration.

7.1.6.5 Object 605E_h: fault_reaction_option_code

The object **fault_reaction_option_code** determines the behaviour on a fault. Because the reaction on errors depends on the type of error in the , this object can not be configured. It always returns the value zero. The fault reaction can be separately configured for each fault group as described in chapter 6.18, Error management.

Index	605E _h
Name	fault_reaction_option_code
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	no
Units	-
Value Range	0
Default Value	0

8 Operating Modes

8.1 Adjustment of the Operating Mode

8.1.1 Survey

The are able to work in a lot of different operation modes. Only some of them are specified in detail in the CANopen specification:

- torque controlled operation
- speed controlled operation
- homing operation (search for reference)
- positioning operation
- interpolated position mode

8.1.2 Description of Objects

8.1.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
6060 _h	VAR	modes_of_operation	INT8	wo
6061 _h	VAR	modes_of_operation_display	INT8	ro

8.1.2.2 Object 6060_h: modes_of_operation

The operating mode of the servo controller is determined by the object **modes_of_operation**.

Index	6060 _h
Name	modes_of_operation
Object Code	VAR
Data Type	INT8

Access	rw
PDO Mapping	yes
Units	-
Value Range	1, 3, 4, 6, 7
Default Value	-

Value	Operation mode
1	Profile Positioning Mode (position controller with positioning operation)
3	Profile Velocity Mode (speed controller with setpoint ramp)
4	Torque Profile Mode (torque controller with setpoint ramp)
6	Homing mode (homing operation)
7	Interpolated Position Mode



The current operating mode can only be read in the object **modes_of_operation_display**. As a change of the operating mode might require some time to process, one will have to wait until the new selected mode appears in the object **modes_of_operation_display**.

8.1.2.3 Object 6061_h: modes_of_operation_display

The current operating mode of the servo controller can be read in the object **modes_of_operation_display**. If an operating mode is set up via the object **6060h**, in addition to the operating mode the setpoint selectors, which are necessary for the operation of the controller via CANopen, are changed too. These are:

	Profile Velocity Mode	Profile Torque Mode
Selector A	Speed setpoint (Fieldbus 1)	Torque setpoint (Fieldbus 1)
Selector B	If necessary: Torque limitation	Inactive
Selector C	Speed setpoint (Synchronous speed)	Inactive

Furthermore the setpoint ramp is activated principally. Only if the selection is set up in the mentioned manner, one of the CANopen operating modes will be returned. If these settings are changed, e.g. via the TM, a particular “user” operating mode will be returned, in order to indicate, that the selectors have been changed.

Index	6061 _h
Name	modes_of_operation_display
Object Code	VAR
Data Type	INT8

Access	ro
PDO Mapping	yes
Units	-
Value Range	-1, 1, 3, 4, 6, 7
Default Value	3

Value	Operation mode
-1	Unknown operating mode under CANopen
-11	User Position Mode
-13	User Velocity Mode
-14	User Torque Mode
1	Profile Positioning Mode (position controller with positioning operation)
3	Profile Velocity Mode (speed controller with setpoint ramp)
4	Torque Profile Mode (torque controller with setpoint ramp)
6	Homing mode (homing operation)
7	Interpolated Position Mode



The operating mode can only be set via the object `modes_of_operation`. As a change of the operating mode might require some time, it has to be wait until the new selected mode appears in the object `modes_of_operation_display`. During this period of time it could happen that invalid operating modes (-1) are displayed for a short time.

8.2 Operating Mode »Homing mode«

8.2.1 Survey

This chapter describes how the servo controller searches the start position (also called reference point or zero point). There are various methods to determine this position. Either the limit switches at the end of the positioning range can be used or a reference switch (zero point switch) within the possible range of motion. Among some methods the zero impulse of the used encoder (resolver, incremental encoder, etc.) can be included to achieve a state that can be reproduced as good as possible.




Figure 8.1: Homing Mode

The user can determine the velocity, acceleration, and the kind of homing operation. After the servo controller has found its reference the zero position can be moved to the desired point via the object `home_offset`. There are two kinds of speed for the homing operation.

The higher search speed (`speed_during_search_for_switch`) is used to find the limit switch respectively the reference switch. To determine the reference slope exactly a lower speed is used (`speed_during_search_for_zero`).

If just the position should be moved instead of finding a reference point, object `2030h` (`set_absolute_position`) can be used. For this purposes see chapter 6.7.2.15.



The movement to the zero position is in most cases not part of the homing operation. If all required values are known (i.e. if the zero position is already known by the servo controller), no physical motion will be executed. This behaviour can be changed by object `6510h_F0h` (`compatibility_control`, see chapter 6.2.2.2), that the drive always moves to zero after completing the homing procedure successfully.

8.2.2 Description of Objects

8.2.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attribute
607C _h	VAR	home_offset	INT32	rw
6098 _h	VAR	homming_method	INT8	rw
6099 _h	ARRAY	homming_speeds	UINT32	rw
609A _h	VAR	homming_acceleration	UINT32	rw
2045 _h	VAR	homming_timeout	UINT16	rw

8.2.2.2 Affected objects from other chapters

Index	Object	Name	Type	Chapter
6040 _h	VAR	controlword	UINT16	6.18 Device control
6041 _h	VAR	statusword	UINT16	6.18 Device control

8.2.2.3 Object 607C_h: home_offset

The object `home_offset` determines the displacement of the zero position to the limit resp. reference switch position.




Figure 8.2: Home Offset

Index	607Ch
Name	home_offset
Object Code	VAR
Data Type	INT32

Access	rw
PDO Mapping	yes
Units	position units
Value Range	-
Default Value	0

8.2.2.4 Object 6098_h: homing_method

A number of different methods are available for a homing operation. The method that is necessary for the application can be selected via the object **homing_method**. There are four possible signals for the homing operation: The negative and positive limit switch, the reference switch and the (periodic) zero impulse of the angle encoder. Besides this the controller can refer to the negative or positive endstop without additional signal. If a method has been determined via the object **homing_method** the following parameters are fixed by that:

- The signal for reference (neg./pos. limit switch, reference switch, neg. / pos. endstop)
- The direction and process of the homing operation
- The kind of evaluation of the zero impulse of the used angle encoder.

Index	6098 _h
Name	homing_method
Object Code	VAR
Data Type	INT8

Access	rw
PDO Mapping	yes
Units	-
Value Range	-18, -17, -2, -1, 1, 2, 7, 11, 17, 18, 23, 27, 32, 33, 34, 35
Default Value	17

Value	Direction	Target	Reference point for Home position	DS402
-18	Positive	Endstop	Endstop	-18
-17	Negative	Endstop	Endstop	-17

-2	Positive	Endstop	Zero impulse	-2
-1	Negative	Endstop	Zero impulse	-1
1	Negative	Limit switch	Zero impulse	1
2	Positive	Limit switch	Zero impulse	2
7	Positive	Reference switch	Zero impulse	7
11	Negative	Reference switch	Zero impulse	11
17	Negative	Limit switch	Limit switch	17
18	Positive	Limit switch	Limit switch	18
23	Positive	Reference switch	Reference switch	23
27	Negative	Reference switch	Reference switch	27
32	Negative	Zero impulse	Zero impulse	33
33	Positive	Zero impulse	Zero impulse	34
34		No run	Actual position	35



In previous CANopen implementations the homing methods 32, 33, 34 and 35 are not assigned according to DS402. Therefore there is the possibility to choose the assignment according to DS402 via the object **compatibility_control** (see 6.2). In this case the methods' numbers, printed in italic, should be used.
For compatibility to previous versions no changes have to be done and the numbers up to now can still be used.

The **homing_method** can only be changed, when the homing is not active. Otherwise the error message Data cannot be transferred or stored to the application because of the present device state is returned.
The homing sequence of the respective methods is explained more detailed in chapter 8.2.3.

8.2.2.5 Object 6099_h: homing_speeds

This object determines the speeds which are used during the homing operation.

Index	6099 _h
Name	homing_speeds
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01 _h
Description	speed_during_search_for_switch
Access	rw
PDO Mapping	yes
Units	speed units
Value Range	-
Default Value	100 min ⁻¹

Sub-Index	02 _h
Description	speed_during_search_for_zero
Access	rw
PDO Mapping	yes
Units	speed units
Value Range	-
Default Value	10 min ⁻¹



The drive moves to zero after completing the homing procedure successfully, if bit 6 of the object **compatibility_control** (see chapter 6.2.2.2) is set.
If this bit is set, writing to object **speed_during_search_for_switch** will set the velocity for searching the switch as well as the velocity for moving to the zero position.

8.2.2.6 Object 609Ah: homing_acceleration

The objects **homing_acceleration** determine the acceleration which is used for all acceleration and deceleration operations during the search for reference.

Index	609Ah
Name	homing_acceleration
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	acceleration units
Value Range	-
Default Value	1000 min ⁻¹ / s

8.2.2.7 Object 2045h: homing_timeout

The homing's maximum execution time can be monitored. For that purpose the maximum execution time is specified by the object **homing_timeout**. If this time is exceeded and the homing has not been finished yet, error 11-3 will occur.

Index	2045h
Name	homing_timeout
Object Code	VAR
Data Type	UINT16

As of Firmware 3.2.0.1.1

Access	rw
PDO Mapping	no
Units	ms
Value Range	0 (off), 1 ... 65535
Default Value	60000

8.2.3 Homing sequences

The various homing sequences are pictured in the following figures. The encircled numbers correspond to the number of the object homing_method.

8.2.3.1 Method 1: Negative limit switch using zero impulse evaluation

If this method is used the drive first moves relatively quick into the negative direction until it reaches the negative limit switch. This is displayed in the diagram by the rising edge. Afterwards the drive slowly returns and searches for the exact position of the limit switch. The zero position refers to the first zero impulse of the angle encoder in positive direction from the limit switch.




Figure 8.3: Homing operation to the negative limit switch including evaluation of the zero impulse

8.2.3.2 Method 2: Positive limit switch using zero impulse evaluation

If this method is used the drive first moves relatively quick into the positive direction until it reaches the positive limit switch. This is displayed in the diagram by the rising edge. Afterwards the drive slowly returns and searches for the exact position of the limit switch. The zero position refers to the first zero impulse of the angle encoder in negative direction from the limit switch.




Figure 8.4: Homing operation to the positive limit switch including evaluation of the zero impulse

8.2.3.3 Methods 7 and 11: Reference switch and zero impulse evaluation

These two methods use the reference switch which is only active over parts of the distance. These reference methods are particularly useful for round-axis applications where the reference switch is activated once per revolution.

In case of method 7 the drive first moves into positive and in case of method 11 into negative direction. Depending on the direction of the motion the zero position refers to the first zero impulse in negative or positive direction from the reference switch. This can be seen in the two following diagrams.




Figure 8.5: Homing operation to the reference switch evaluating the zero impulse for a positive start motion



On homing to the reference switch the first reached limit switch is used to reverse the search direction. If therupon the opposite limit switch is reached an error occurs.




Figure 8.6: Homing operation to the reference switch evaluating the zero impulse for a negative start motion

8.2.3.4 Method 17: Homing operation to the negative limit switch

If this method is used the drive first moves relatively quick into the negative direction until it reaches the negative limit switch. This is displayed in the diagram by the rising edge. Afterwards the drive slowly returns and searches for the exact position of the limit switch. The zero position refers to the descending edge from the negative limit switch.




Figure 8.7: Homing operation to the negative limit switch

8.2.3.5 Method 18: Homing operation to the positive limit switch

If this method is used the drive first moves relatively quick into the positive direction until it reaches the positive limit switch. This is displayed in the diagram by the rising edge. Afterwards the drive slowly returns and searches for the exact position of the limit switch. The zero position refers to the descending edge from the positive limit switch.




Figure 8.8: Homing operation to the positive limit switch

8.2.3.6 Methods 23 and 27: Homing operation to the reference switch

These two methods use the reference switch which only is active over part of the distance. These reference methods are particularly useful for round-axis applications where the reference switch is activated once per revolution.

In case of method 23 the drive first moves into positive and in case of method 27 into negative direction. The zero position refers to the edge from the reference switch. This can be seen in the two following diagrams.




Figure 8.9: Homing operation to the reference switch for a positive start motion



On homing to the reference switch the first reached limit switch is used to reverse the search direction. If therupon the opposite limit switch is reached an error occurs.




Figure 8.10: Homing operation to the reference switch for a negative start motion

8.2.3.7 Method -1: Negative stop evaluating the zero impulse

If this method is used the drive moves into negative direction until it reaches the stop. The I^2t integral of the motor reaches a maximum value of 90%. The stop has to be mechanically dimensioned so that it is not damaged in case of the configured maximum current. The zero position refers to the first zero impulse of the angle encoder in positive direction from the stop.




Figure 8.11: Homing operation to the negative stop evaluating the zero impulse

8.2.3.8 Method -2: Positive stop evaluating the zero impulse

If this method is used the drive moves into positive direction until it reaches the stop. The I^2t integral of the motor reaches a maximum value of 90%. The stop has to be mechanically dimensioned so that it is not damaged in case of the configured maximum current. The zero position refers to the first zero impulse of the angle encoder in negative direction from the stop.




Figure 8.12: Homing operation to the positive stop evaluating the zero impulse

8.2.3.9 Method -17: Homing operation to the negative stop

If this method is used the drive moves into negative direction until it reaches the stop. The I^2t integral of the motor reaches a maximum value of 90%. The stop has to be mechanically dimensioned so that it is not damaged in case of the configured maximum current. The zero position refers directly to the endstop.




Figure 8.13: Homing operation to the negative stop

8.2.3.10 Method -18: Homing operation to the positive stop

If this method is used the drive moves into positive direction until it reaches the stop. The I^2t integral of the motor reaches a maximum value of 90%. The stop has to be mechanically dimensioned so that it is not damaged in case of the configured maximum current. The zero position refers directly to the endstop.




Figure 8.14: Homing operation to the positive stop

8.2.3.11 Methods 32 and 33: Homing operation to the zero impulse

For the methods 32 (*33 according to DS402*) and 33 (*34 according to DS402*) the direction of the homing operation is negative and positive, respectively. The zero position refers to the first zero impulse from the angle encoder in search direction.




Figure 8.15: Homing operation only referring to the zero impulse

8.2.3.12 Method 34: Homing operation to the current position

On method 34 (*35 according to DS402*) the zero position is referred to the current position.

If just the position should be moved instead of finding a reference point, object 2030_h (`set_absolute_position`) can be used. For this purposes see chapter 6.7.2.15.

8.2.4 Control of the homing operation

The homing operation is started by setting bit 4 in the **controlword**. The successful end of a homing operation is indicated by a set bit 12 in the object **statusword**. A set bit 13 in the object **statusword** indicates that an error has occurred during the homing operation. The error reason can be identified by the objects **error_register** and **predefined_error_field**.

Bit 4	Description
0	Homing operation is not active
0 → 1	Start homing operation
1	Homing operation is active
1 → 0	Interrupt homing operation

Table 8.1: Description of the bits in the controlword

Bit 13	Bit 12	Description
0	0	Homing operation has not yet finished
0	1	Homing operation executed successfully
1	0	Homing operation not executed successfully
1	1	Illegal state

Table 8.2: Description of the bits in the statusword

8.3 Operating Mode »Profile Position Mode«

8.3.1 Survey

The structure of this operating mode is shown in Figure 8.16:

The target position (**target_position**) is passed to the trajectory generator. This generator generates a desired position value (**position_demand_value**) for the position controller that is described in the chapter **Position Controller** (position control function, chapter 0). These two function blocks can be adjusted independently from each other.




Figure 8.16: Trajectory generator and position controller

All input quantities of the trajectory generator are converted into internal quantities of the controller by means of the quantities of the **Factor group** (see chapter 6.3: Conversion factors (Factor Group)). The internal quantities are marked by an asterisk and are not imperatively needed by the user.

8.3.2 Description of Objects

8.3.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
607A _h	VAR	target_position	INT32	rw
6081 _h	VAR	profile_velocity	UINT32	rw
6082 _h	VAR	end_velocity	UINT32	rw
6083 _h	VAR	profile_acceleration	UINT32	rw
6084 _h	VAR	profile_deceleration	UINT32	rw
6085 _h	VAR	quick_stop_deceleration	UINT32	rw
6086 _h	VAR	motion_profile_type	INT16	rw

8.3.2.2 Affected objects from other chapters

Index	Object	Name	Type	Chapter
6040 _h	VAR	controlword	INT16	6.16 Device control
6041 _h	VAR	statusword	UINT16	6.16 Device control
605A _h	VAR	quick_stop_option_code	INT16	6.16 Device control
607E _h	VAR	polarity	UINT8	6.3 Conversion factors (Factor Group)
6093 _h	ARRAY	position_factor	UINT32	6.3 Conversion factors (Factor Group)
6094 _h	ARRAY	velocity_encoder_factor	UINT32	6.3 Conversion factors (Factor Group)
6097 _h	ARRAY	acceleration_factor	UINT32	6.3 Conversion factors (Factor Group)

8.3.2.3 Object 607A_h: target_position

Das Object **target_position** (Zielposition) bestimmt, an welche Position der Antrieb bewegt wird. The object **target_position** determines the destination the servo controller moves to. For this purpose the current adjustments of the velocity, of the acceleration, of the deceleration and the kind of motion profile (**motion_profile_type**) have to be considered. The target position (**target_position**) is interpreted either as an absolute or relative position. This depends on bit 6 (**relative**) of the object **controlword**.

Index	607A _h
Name	target_position
Object Code	VAR
Data Type	INT32

Access	rw
PDO Mapping	yes
Units	position units
Value Range	-
Default Value	0

8.3.2.4 Object 6081_h: profile_velocity

The object **profile_velocity** specifies the speed that usually is reached during a positioning motion at the end of the acceleration ramp. The object **profile_velocity** is specified in **speed_units**.

Index	6081 _h
Name	profile_velocity
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	speed_units
Value Range	-
Default Value	1000

8.3.2.5 Object 6082_h: end_velocity

The object **end_velocity** defines the speed at the target position (**target_position**). Usually this object has to be set to zero so that the controller stops when it reaches the target position. For gapless sequences of positionings a value unequal zero can be set. The object **end_velocity** is specified in **speed_units** like the object **profile_velocity**.

Index	6082 _h
Name	end_velocity
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	speed units
Value Range	-
Default Value	0

8.3.2.6 Object 6083_h: profile_acceleration

The object **profile_acceleration** determines the maximum acceleration used during a positioning motion. It is specified in user specific acceleration units (**acceleration_units**). (See 6.3 Conversion factors (Factor Group)).

Index	6083 _h
Name	profile_acceleration
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	acceleration units
Value Range	-
Default Value	10000 min ⁻¹ /s

8.3.2.7 Object 6084_h: profile_deceleration

The object **profile_deceleration** specifies the maximum deceleration used during a positioning motion. This object is specified in the same units as the object **profile_acceleration**. (See chapter 6.3 Conversion factors (Factor Group)).

Index	6084 _h
Name	profile_deceleration
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	acceleration units
Value Range	-
Default Value	10000 min ⁻¹ /s

8.3.2.8 Object 6085_h: quick_stop_deceleration

The object **quick_stop_deceleration** determines the deceleration if a Quick Stop will be executed (see chapter 7.1.2.2). The object **quick_stop_deceleration** is specified in the units as the object **profile_deceleration**.

Index	6085 _h
Name	quick_stop_deceleration
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	acceleration units
Value Range	-
Default Value	14100 min ⁻¹ /s

8.3.2.9 Object 6086_h: motion_profile_type

The object **motion_profile_type** is used to select the kind of positioning profile. At present only a linear profile is available.

Index	6086 _h
Name	motion_profile_type
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	yes
Units	-
Value Range	0; 2
Default Value	0

Value	Profile
0	Linear ramp
2	Jerkfree ramp

As of Firmware 3.1.0.1.1

8.3.3 Functional Description

Two different ways to apply target positions to the servo controller are supported.

Single setpoints

After reaching the **target_position** the servo controller signals this status to the host by the bit **target_reached** (Bit 10 of **controlword**) and then receives a new setpoint. The servo controller stops at the **target_position** before starting a move to the next setpoint.

Set of setpoints

After reaching the **target_position** the servo controller immediately processes the next **target_position** which results in a move where the velocity of the drive normally is not reduced to zero after reaching a setpoint.

These two methods are controlled by the bits **new_set_point** and **change_set_immediately** in the object **controlword** and **set_point_acknowledge** in the object **statusword**. These bits are in a request-response relationship. So it is possible to prepare one positioning job while another job is still running.




Figure 8.17: Positioning job transfer from a host

Figure 8.17 shows the communication between the host and the servo controller via the CAN bus:

At first the positioning data (**target_position**, **profile_velocity**, **end_velocity** and **profile_acceleration**) are transferred to the servo controller. After the positioning data set has been transferred completely (1) the host can start the positioning motion by setting the bit **new_set_point** in the **controlword** (2).

This will be acknowledged by the servo controller by setting the bit **set_point_acknowledge** in the **statusword** (3), when the positioning data has been copied into the internal buffer.

Afterwards the host can start to transfer a new positioning data set into the servo controller (4) and clear the bit **new_set_point** (5). The servo controller signals by a cleared **set_point_acknowledge** bit that it can accept a new drive job (6). The host has to wait for the falling edge of the bit **set_point_acknowledge** before a new positioning motion can be started (7).

In Figure 8.18 a new positioning motion is started after the previous one has been finished completely. For that purpose the host evaluates the bit **target_reached** in the object **statusword**.




Figure 8.18: Simple positioning job

In Figure 8.19 a new positioning motion has already been started while the previous motion was still running. The host already transfers the subsequent target to the servo controller if it signals by a cleared **set_point_acknowledge** bit that it has read the buffer and started the corresponding positioning motion. In this way the positioning motions are joined together gaplessly. For this operating mode the object **end_velocity** of the first job should be configured to the same value as the object **profile_velocity** of the following job so that the servo controller does not decelerate to zero amongst the single positioning motions.




Figure 8.19: Gapless sequence of positioning jobs

If beside the bit `new_setpoint` the bit `change_set_immediately` is set in the `controlword`, too, the new positioning job will interrupt the actual job immediately and will be started instead. The actual positioning job is canceled in this case.

8.4 Interpolated Position Mode

8.4.1 Survey

The interpolated position mode (IP) allows cyclic sending of position demand values to the servo in a multi-axle system. Therefore the host sends synchronisation telegrams (SNYC) and position demand values in a fixed interval (synchronisation interval). The servo controller itself interpolates between two setpoints, if the synchronisation interval is larger than the position control interval as shown in the following figure:




Figure 8.20: Linear interpolation between two positions

In the following the objects of the **interpolated position mode** will be described first. After it a functional description will explain the activation and the order of parameterisation detailed.

8.4.2 Description of Objects

8.4.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
60C0 _h	VAR	interpolation_submode_select	INT16	rw
60C1 _h	REC	interpolation_data_record		rw
60C2 _h	REC	interpolation_time_period		rw
60C3 _h	VAR	interpolation_sync_definition	UINT8	rw
60C4 _h	REC	interpolation_data_configuration		rw

8.4.2.2 Affected objects of other chapters

Index	Object	Name	Type	Chapter
6040 _h	VAR	controlword	INT16	6.18 Device control
6041 _h	VAR	statusword	UINT16	6.18 Device control
6093 _h	ARRAY	position_factor	UINT32	6.3 Conversion factors (Factor Group)
6094 _h	ARRAY	velocity_encoder_factor	UINT32	6.3 Conversion factors (Factor Group)
6097 _h	ARRAY	acceleration_factor	UINT32	6.3 Conversion factors (Factor Group)

8.4.2.3 Object 60C0_h: interpolation_submode_select

The object **interpolation_submode_select** determines the type of interpolation. At present only the manufacturer specific type „Linear interpolation without buffer“ is available.

Index	60C0 _h
Name	interpolation_submode_select
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	yes
Units	-
Value Range	-2
Default Value	-2

Value	Type of interpolation
-2	Linear interpolation without buffer

8.4.2.4 Object 60C1_h: interpolation_data_record

The object record **interpolation_data_record** represents the interpolation data itself. It contains the position demand value (**ip_data_position**) and a controlword (**ip_data_controlword**) that determines whether the position value is relative or absolute. The use of the controlword is optional. If it should be used it is necessary to write subindex 2 first (**ip_data_controlword**) followed by subindex 1 (**ip_data_position**) to achieve data consistence, because the position will be copied by a write access to **ip_data_position**.

Index	60C1 _h
Name	interpolation_data_record
Object Code	RECORD
No. of Elements	2

Sub-Index	01 _h
Description	ip_data_position
Data Type	INT32
Access	rW
PDO Mapping	yes
Units	position units
Value Range	-
Default Value	-

Sub-Index	02 _h
Description	ip_data_controlword
Data Type	UINT8
Access	rW
PDO Mapping	yes
Units	-
Value Range	0, 1
Default Value	0

Value	ip_data_position is
0	Absolute position
1	Relative distance



The data will be copied on a write access to subindex 1. If also subindex 2 should be used it is necessary to write subindex 2 first followed by subindex 1 .

8.4.2.5 Object 60C2_h: interpolation_time_period

Using the object record **interpolation_time_period** the synchronisation interval can be determined. First the unit (ms or 1/10 ms) can be set by the object **ip_time_index**. After that the interval can be written to **ip_time_units**.

For the synchronisation the complete controller loops (Current-, velocity- and position controller) will be synchronised to the external clock. Therefore the change of the interval will only take effect after a reset. If the synchronisation interval should be changed via CAN bus, it is necessary to save the parameter set first (see chapter 0), and reset the device after that (see chapter 5.6). The external clock has to have a high precision.

Index	60C2 _h
Name	interpolation_time_period
Object Code	RECORD
No. of Elements	2

Sub-Index	01 _h
Description	ip_time_units
Data Type	UINT8
Access	rw
PDO Mapping	yes
Units	according to ip_time_index
Value Range	ip_time_index = -3: 1, 2,..., 9, 10 ip_time_index = -4: 10, 20,..., 90, 100
Default Value	-

Sub-Index	02 _h
Description	ip_time_index
Data Type	INT8
Access	rw
PDO Mapping	yes
Units	-
Value Range	-3, -4
Default Value	-3

Value	ip_time_units will be written in
-3	10^{-3} seconds (ms)
-4	10^{-4} seconds (0.1 ms)



The change of the synchronisation interval will only take effect after a reset. If the interval should be changed via CAN bus, it is necessary to save the parameter set first and reset the device after that.

8.4.2.6 Object 60C3_h: interpolation_sync_definition

The object **interpolation_sync_definition** determines the kind of synchronisation (**synchronize_on_group**) and the number (**ip_sync_every_n_event**) of synchronisations messages (SYNC) per synchronisation interval. For the only the standard SYNC telegram and 1 SYNC per interval can be set.

Index	60C3 _h
Name	interpolation_sync_definition
Object Code	ARRAY
No. of Elements	2
Data Type	UINT8

Sub-Index	01 _h
Description	synchronize_on_group
Access	rw
PDO Mapping	yes
Units	–
Value Range	0
Default Value	0

Value	Description
0	Use standard SYNC teleogramm

Sub-Index	02h
Description	ip_sync_every_n_event
Access	rw
PDO Mapping	yes
Units	-
Value Range	1
Default Value	1

8.4.2.7 Object 60C4_h: interpolation_data_configuration

By the object record `interpolation_data_configuration` the kind (`buffer_organisation`) and size (`max_buffer_size`, `actual_buffer_size`) of a possibly available buffer can be set. Additionally the access can be controlled by the objects `buffer_position` and `buffer_clear`. The object `size_of_data_record` returns the size of one buffer item. Even though no buffer is available for the interpolation type „linear interpolation without buffer“, the access has to be enabled using the object `buffer_clear`.

Index	60C4 _h
Name	interpolation_data_configuration
Object Code	RECORD
No. of Elements	6

Sub-Index	01h
Description	max_buffer_size
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	-
Value Range	0
Default Value	0

Sub-Index	02h
Description	actual_size
Data Type	UINT32
Access	rw
PDO Mapping	yes
Units	-
Value Range	0...max_buffer_size
Default Value	0

Sub-Index	03h
Description	buffer_organisation
Data Type	UINT8
Access	rw
PDO Mapping	yes
Units	-
Value Range	0
Default Value	0

Value	Description
0	FIFO

Sub-Index	04h
Description	buffer_position
Data Type	UINT16
Access	rw
PDO Mapping	yes
Units	-
Value Range	0
Default Value	0

Sub-Index	05h
Description	size_of_data_record
Data Type	UINT8
Access	wo
PDO Mapping	yes
Units	-
Value Range	2
Default Value	2

Sub-Index	06h
Description	buffer_clear
Data Type	UINT8
Access	wo
PDO Mapping	yes
Units	-
Value Range	0, 1
Default Value	0

Value	Description
0	Clear buffer / Access to 60C1h disabled
1	Access to 60C1h enabled

8.4.3 Functional Description

8.4.3.1 Preliminary parameterisation

Before the interpolated position mode can be entered, several settings have to be done: The interpolation interval (**interpolation_time_period**), i.e the time between two SYNC messages, the kind of interpolation (**interpolation_submode_select**) and the kind of synchronisation (**interpolation_sync_definition**) have to be set. Additionally the access to the position buffer has to be enabled by the object **buffer_clear**.

EXAMPLE



Task	CAN object / COB	
Interpolation type	-2	60C0h, interpolation_submode_select = -2
Time unit	0.1 ms	60C2h_02h, interpolation_time_index = -04
Time interval	4 ms	60C2h_01h, interpolation_time_units = 40
Save parameter set	1010h_01h, save_all_parameters	
Execute reset	NMT reset node	
Wait for bootup	Bootup message	
Enable buffer	1	60C4h_06h, buffer_clear = 1
Create SYNCs	SYNC (every 4 ms)	

8.4.3.2 Activation of the Interpolated Position Mode and first synchronisation

The IP will be activated by the object **modes_of_operation** (6060_h). From this point in time the controller tries to synchronise to the external clock given by the SYNC telegrams. On success the **interpolated position mode** will be displayed in the object **modes_of_operation_display** (6061_h). During the first synchronisation period “**unknown mode**” (-1) will be returned as well as if the synchronisation is lost because of an invalid interval for example.

If the **interpolated position mode** is reached the transmission of position data can be started. For logical reasons the host first reads the position actual value of the servo controller and transmits it cyclically as demand value (**interpolation_data_record**). After that the acceptance of the data can be enabled by handshake bits of the **controlword** and the **statusword**. By setting the bit **enable_ip_mode** in the **controlword**

the host signals that the position data should be evaluated. The position data will not be processed until the servo controller acknowledges that with setting bit **ip_mode_selected** in the **statusword**.

This results in the following sequence:




Figure 8.21: First synchronisation und data processing

No.	Event	CAN object
1	Create SYNC messages	
2	Request the operation mode „IP“	6060 _h , modes_of_operation = 07
3	Wait for the operation mode	6061 _h , modes_of_operation_display = 07
4	Read actual position	6064 _h , position_actual_value
5	Rewrite it as demand value	60C1 _h _01 _h , ip_data_position
6	Start interpolation	6040 _h , controlword, enable_ip_mode
7	Wait for acknowledge	6041 _h , statusword, ip_mode_active
8	Change position setpoints according to the desired trajectory	60C1 _h _01 _h , ip_data_position

To prevent the further evaluation of position data the bit `enable_ip_mode` can be cleared and the operation mode can be changed after that.

8.4.3.3 Interruption of interpolation in case of an error

If a currently running interpolation (`ip_mode_active` set) will be interrupted by the occurrence of an error, the servo controller reacts as specified for the certain error (i.e. disabling the controller and changing to the state `SWITCH_ON_DISABLED`).

The interpolation can only be restarted by a re-synchronisation, because the state `OPERATION_ENABLE` has to be entered again, whereby the bit `ip_mode_active` will be cleared.


8.5 Profile Velocity Mode

8.5.1 Survey

The profile velocity mode includes the following subfunctions:

- Setpoint generation by the ramp generator
- Speed recording via the angle encoder by differentiation
- Speed control with suitable input and output signals
- Limitation of the desired torque value (`torque_demand_value`)
- Control of the actual speed (`velocity_actual_value`) with the window-function/threshold

The meaning of the following parameters is described in the chapter Profile Position Mode:
`profile_acceleration`, `profile_deceleration`, `quick_stop`






Figure 8.22: Structure of the Profile Velocity Mode

8.5.2 Description of Objects

8.5.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
6069 _h	VAR	velocity_sensor_actual_value	INT32	ro
606A _h	VAR	sensor_selection_code	INT16	rw
606B _h	VAR	velocity_demand_value	INT32	ro
202E _h	VAR	velocity_demand_sync_value	INT32	ro
606C _h	VAR	velocity_actual_value	INT32	ro
606D _h	VAR	velocity_window	UINT16	rw
606E _h	VAR	velocity_window_time	UINT16	rw
606F _h	VAR	velocity_threshold	UINT16	rw
6080 _h	VAR	max_motor_speed	UINT32	rw
60FF _h	VAR	target_velocity	INT32	rw

8.5.2.2 Affected objects from other chapters

Index	Object	Name	Type	Chapter
6040 _h	VAR	controlword	INT16	6.18. Device control
6041 _h	VAR	statusword	UINT16	6.18. Device control
6063 _h	VAR	position_actual_value*	INT32	6.7 Position Control Function
6071 _h	VAR	target_torque	INT16	8.7 Profile Torque Mode
6072 _h	VAR	max_torque_value	UINT16	8.7 Profile Torque Mode
607E _h	VAR	polarity	UINT8	6.3 Conversion factors (Factor Group)
6083 _h	VAR	profile_acceleration	UINT32	8.3 Operating Mode »Profile Position Mode«
6084 _h	VAR	profile_deceleration	UINT32	8.3 Operating Mode »Profile Position Mode«
6085 _h	VAR	quick_stop_deceleration	UINT32	8.3 Operating Mode »Profile Position Mode«
6086 _h	VAR	motion_profile_type	INT16	8.3 Operating Mode »Profile Position Mode«
6094 _h	ARRAY	velocity_encoder_factor	UINT32	6.3 Conversion factors (Factor Group)

8.5.2.3 Object 6069_h: velocity_sensor_actual_value

The speed encoder is read via the object **velocity_sensor_actual_value**. The value is normalised in internal units. As no external speed encoder can be connected to servo controllers of the , the actual velocity value always has to be read via the object 606C_h.

Index	6069 _h
Name	velocity_sensor_actual_value
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	R / 4096 min
Value Range	--
Default Value	--

8.5.2.4 Object 606A_h: sensor_selection_code

The speed sensor can be selected by this object. Currently no separate speed sensor will be provided by the servo controller. Therefore only the default angle encoder can be selected.

Index	606A _h
Name	sensor_selection_code
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	yes
Units	-
Value Range	0
Default Value	0

8.5.2.5 Object 606B_h: velocity_demand_value

The velocity demand value can be read via this object. It will be influenced by the ramp generator and the trajectory generator respectively. Besides this the correction speed of the position controller is added if it is activated

Index	606B _h
Name	velocity_demand_value
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	speed units
Value Range	-
Default Value	-

8.5.2.6 Object 202E_h: velocity_demand_sync_value

The speed setpoint of the synchronisation encoder can be read from this object in user-defined units. This setpoint is specified with the object 2022_h synchronization_encoder_select (chapter 6.11).

Index	202E _h
Name	velocity_demand_sync_value
Object Code	VAR
Data Type	INT32

As of Firmware 3.2.0.1.1

Access	ro
PDO Mapping	no
Units	velocity units
Value Range	-
Default Value	-

8.5.2.7 Object 606C_h: velocity_actual_value

The actual velocity value can be read via the object velocity_actual_value.

Index	606C _h
Name	velocity_actual_value
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	speed units
Value Range	-
Default Value	-

8.5.2.8 Objekt 2074_h: velocity_actual_value_filtered

The object **velocity_actual_value_filtered** provides a highly filtered velocity actual value that should only be used for display purposes. In contrast to **velocity_actual_value** the **velocity_actual_value_filtered** is not used for motor control but for overspeed protection. The filter time can be configured by object 2073_h (**velocity_display_filter_time**). See chapter 6.6.2.2

Index	2074 _h
Name	velocity_actual_value_filtered
Object Code	VAR
Data Type	INT32

As of Firmware 3.5.x.1.1

Access	ro
PDO Mapping	yes
Units	speed units
Value Range	-
Default Value	-




Figure 8.23: Evaluation of velocity_actual_value and velocity_actual_value_filtered

8.5.2.9 Object 606D_h: velocity_window

With the object **velocity_window** a tolerance window for the velocity actual value will be defined for comparing the **velocity_actual_value** with the target velocity (target_velocity object 60FF_h). If the difference is smaller than the velocity window for a longer time than specified by the object **velocity_window_time** bit 10 (**target_reached**) will be set in the object **statusword**.

See also: Object 606E_h (**velocity_window_time**).

Index	606D _h
Name	velocity_window
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	speed units
Value Range	0...65536 min ⁻¹
Default Value	4 min ⁻¹

8.5.2.10 Object 606E_h: velocity_window_time

The object **velocity_window_time** serves besides the object 606D_h: **velocity_window** to adjust the window comparator. It compares the **velocity_actual_value** with the **target_velocity** (object 60FF_h). If the difference is smaller than specified by **velocity_window** for a longer time than specified by the object **velocity_window_time** bit 10 (**target_reached**) will be set in the object **statusword**.

Index	606E _h
Name	velocity_window_time
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	ms
Value Range	0...4999
Default Value	0

8.5.2.11 Object 606F_h: velocity_threshold

The object **velocity_threshold** determines the velocity underneath the axis is regarded as stationary. As soon as the **velocity_actual_value** exceeds the **velocity_threshold** longer than the **velocity_threshold_time** bit 12 is cleared in the **statusword**.

Index	606F _h
Name	velocity_threshold
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	speed units
Value Range	0...65536 min ⁻¹
Default Value	10

8.5.2.12 Object 6070_h: velocity_threshold_time

The object **velocity_threshold** determines the velocity below the axis is regarded as stationary. As soon as the **velocity_actual_value** exceeds the **velocity_threshold** longer than the **velocity_threshold_time** bit 12 is cleared in the **statusword**.

Index	6070 _h
Name	velocity_threshold_time
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	ms
Value Range	0...4999
Default Value	0

8.5.2.13 Object 6080_h: max_motor_speed

The object **max_motor_speed** specifies the maximum permissible speed for the motor in rpm. The object is used to protect the motor and can be taken from the motor specifications. The velocity set point value is limited to the value of the object **max_motor_speed**.

Index	6080 _h
Name	max_motor_speed
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	min ⁻¹
Value Range	0... 32768 min ⁻¹
Default Value	32768 min ⁻¹

8.5.2.14 Object 60FF_h: target_velocity

The object **target_velocity** is the setpoint for the ramp generator.

Index	60FF _h
Name	target_velocity
Object Code	VAR
Data Type	INT32

Access	rw
PDO Mapping	yes
Units	speed units
Value Range	-
Default Value	-

8.6 Speed ramps

When the object **modes_of_operation** is set to **profile_velocity_mode**, the setpoint ramp is always activated. By the objects **profile_acceleration** and **profile_deceleration** it is possible to smooth the change of velocity.

The controller allows not only the entering of accelerations and decelerations, but also to differentiate between negative and positive speed. The following figure makes this behaviour clear:




Figure 8.24: Speed ramps

The record **velocity_ramps** allows the parameterisation of the 4 accelerations. Please consider, that the objects **profile_acceleration** and **profile_deceleration** change the same internal accelerations as the record **velocity_ramps**. When the object **profile_acceleration** is changed, the objects **velocity_acceleration_pos** and **velocity_acceleration_neg** are changed too. When the object **profile_deceleration** is changed, the objects **velocity_deceleration_pos** and **velocity_deceleration_neg** are changed too. The speed ramps can be enabled resp. disabled via the object **velocity_ramps_enable**.

Index	2090_h
Name	velocity_ramps
Object Code	RECORD
No. of Elements	5

As of Firmware 3.0.x.1.1

Sub-Index	01_h
Description	velocity_ramps_enable
Data Type	UINT8
Access	rw
PDO Mapping	no
Units	-
Value Range	0: Speed ramps off 1: Speed ramps on
Default Value	1

As of Firmware 3.0.x.1.1

Sub-Index	02_h
Description	velocity_acceleration_pos
Data Type	INT32
Access	rw
PDO Mapping	no
Units	acceleration units
Value Range	-
Default Value	14 100 min ⁻¹ /s

Sub-Index	03_h
Description	velocity_deceleration_pos
Data Type	INT32
Access	rw
PDO Mapping	no
Units	acceleration units
Value Range	-
Default Value	14 100 min ⁻¹ /s

Sub-Index	04_h
Description	velocity_acceleration_neg
Data Type	INT32
Access	rw
PDO Mapping	no
Units	acceleration units
Value Range	-
Default Value	14 100 min ⁻¹ /s

Sub-Index	05_h
Description	velocity_deceleration_neg
Data Type	INT32
Access	rw
PDO Mapping	no
Units	acceleration units
Value Range	-
Default Value	14 100 min ⁻¹ /s

8.7 Profile Torque Mode

8.7.1 Survey

This chapter describes the torque controlled operation. This operating mode offers the chance to demand an external torque value (`target_torque`) which can be smoothed by the integrated ramp generator. So it is also possible to use this servo controller for trajectory control functions where both position controller and speed controller are dislocated to an external computer.




Figure 8.25: Structure of the Profile Torque Mode

The parameters **torque_slope** and **torque_profile_type** (ramp form) have to be specified for the ramp generator. If bit 8 **halt** is set in the **controlword** the ramp generator reduces the torque down to zero. Correspondingly it raises it again to the **target_torque** if bit 8 is cleared. In both cases this will be done under consideration of the ramp generator. All definitions within this document refer to rotatable motors. If linear motors are used all "torque"-objects correspond to "force" instead. For reasons of simplicity the objects do not exist twice and their names should not be modified.

The operating modes Profile Position Mode and Profile Velocity Mode need the torque controller to work properly. Therefore it is always necessary to parametrize the torque controller.

8.7.2 Description of Objects

8.7.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
6071 _h	VAR	target_torque	INT16	rw
6072 _h	VAR	max_torque	UINT16	rw
6074 _h	VAR	torque_demand_value	INT16	ro
6076 _h	VAR	motor_rated_torque	UINT32	rw
6077 _h	VAR	torque_actual_value	INT16	ro
6078 _h	VAR	current_actual_value	INT16	ro
6079 _h	VAR	DC_link_circuit_voltage	UINT32	ro
6087 _h	VAR	torque_slope	UINT32	rw
6088 _h	VAR	torque_profile_type	INT16	rw
60F7 _h	RECORD	power_stage_parameters		rw
60F6 _h	RECORD	torque_control_parameters		rw

8.7.2.2 Affected objects from other chapters

Index	Object	Name	Type	Chapter
6040 _h	VAR	controlword	INT16	6.16 Device control
60F9 _h	RECORD	motor_parameters		6.5 Current control and motor adaptation
6075 _h	VAR	motor_rated_current	UINT32	6.5 Current control and motor adaptation
6073 _h	VAR	max_current	UINT16	6.5 Current control and motor adaptation

8.7.2.3 Object 6071_h: target_torque

This parameter is the input value for the torque controller in Profile Torque Mode. It is specified as thousandths of the nominal torque (object 6076_h).

Index	6071 _h
Name	target_torque
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	yes
Units	motor_rated_torque / 1000
Value Range	-32768...32768
Default Value	0

8.7.2.4 Object 6072_h: max_torque

This value is the maximum permissible value of the motor. It is specified as thousandths of **motor_rated_torque** (object 6076_h). If for example a double overload of the motor is permissible for a short while the value 2000 has to be entered.



The Object 6072_h: max_torque corresponds with object 6073_h: max_current. You are only allowed to write to one of these objects, once the object 6075_h: motor_rated_current has been configured with a valid value.

Index	6072 _h
Name	max_torque
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	motor_rated_torque / 1000
Value Range	1000...65536
Default Value	2023

8.7.2.5 Object 6074_h: torque_demand_value

The current demand torque can be read in thousandths of **motor_rated_torque** (6076_h) via this object. The internal limitations of the servo controller will be considered (current limit values and I²t control).

Index	6074 _h
Name	torque_demand_value
Object Code	VAR
Data Type	INT16

Access	ro
PDO Mapping	yes
Units	motor_rated_torque / 1000
Value Range	--
Default Value	--

8.7.2.6 Object 6076_h: motor_rated_torque

This object specifies the nominal torque of the motor. This value can be taken from the motor plate. It has to be entered by the unit 0.001 Nm.

Index	6076 _h
Name	motor_rated_torque
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	0.001 Nm
Value Range	--
Default Value	296

8.7.2.7 Object 6077_h: torque_actual_value

The actual torque value of the motor can be read via this object in thousandths of the nominal torque (object 6076_h).

Index	6077 _h
Name	torque_actual_value
Object Code	VAR
Data Type	INT16

Access	ro
PDO Mapping	yes
Units	motor_rated_torque / 1000
Value Range	--
Default Value	--

8.7.2.8 Object 6078_h: current_actual_value

The actual current value of the motor can be read via this object in thousandths of the nominal current (object 6075_h).

Index	6078 _h
Name	current_actual_value
Object Code	VAR
Data Type	INT16

Access	ro
PDO Mapping	yes
Units	motor_rated_current / 1000
Value Range	--
Default Value	--

8.7.2.9 Object 6079_h: dc_link_circuit_voltage

The voltage in the intermediate circuit of the regulator can be read via this object. The voltage is specified in millivolt.

Index	6079 _h
Name	dc_link_circuit_voltage
Object Code	VAR
Data Type	UINT32

Access	ro
PDO Mapping	yes
Units	mV
Value Range	-
Default Value	-

8.7.2.10 Object 6087_h: torque_slope

This parameter describes the modification speed of the setpoint ramp. This speed is to be specified as thousandths of the nominal torque per second. For example the desired torque value **target_torque** is raised from 0 Nm to the value **motor_rated_torque**. If the output value of the interconnected torque ramp is to reach this value within a second the value 1000 is to be entered into this object.

Index	6087 _h
Name	torque_slope
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	motor_rated_torque / 1000 s
Value Range	-
Default Value	E310F94 _h

8.7.2.11 Object 6088_h: torque_profile_type

The object **torque_profile_type** defines by which shape of curve a setpoint step is executed. Instantaneous only the linear ramp is implemented in the servo controller so only 0 can be written to this object.

Index	6088 _h
Name	torque_profile_type
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	yes
Units	-
Value Range	0
Default Value	0

Value	Description
0	Linear Ramp

9 Appendix

9.1 Characteristics of the CAN interface

The CAN interface has the following features:

- CAN specification V2.0 part A (part B passive, e. g. messages of this kind will be tolerated but not processed)
- physical layer: ISO 11898

9.2 Header File

```
*****  
*          OBJEKTE.H          *  
*          *  
* Definition of CANopen -Objects          *  
*          *  
* Author:    Ulf Matthiesen          *  
* Date:     05.09.2007          *  
* Update:          *  
* Tests:    —          *  
* Release:   —          *  
* Version:   4.00          *  
*          *  
*          *  
*          *  
* Format:   (0xHHHHSULL mit HHHH = Main index          *  
*          SU  = Sub index          *  
*          LL  = Length in Bits + 0, if unsigned          *  
*          + 1, if signed          *  
*          *  
*          *  
*          *  
*          *  
*****/  
  
#define cUINT8 0x08  
#define cUINT16 0x10  
#define cUINT32 0x20  
#define cINT8 0x09  
#define cINT16 0x11  
#define cINT32 0x21  
#define cPDO 0x00 /* Appropriate bit constants can be entered here */  
#define cWR 0x00 /* Appropriate bit constants can be entered here */
```

```

#define cRD 0x00 /* Appropriate bit constants can be entered here */

#define cUINT8 0x08
#define cUINT16 0x10
#define cUINT32 0x20
#define cINT8 0x09
#define cINT16 0x11
#define cINT32 0x21
#define cPDO 0x00 /* Hier geeignete Bitkonstanten einfügbare */
#define cWR 0x00 /* Hier geeignete Bitkonstanten einfügbare */
#define cRD 0x00 /* Hier geeignete Bitkonstanten einfügbare */

#define device_type (0x100000 + cUINT32 + cRD)
#define error_register (0x100100 + cUINT8 + cRD + cPDO)
#define manufacturer_status_register (0x100200 + cUINT32 + cRD)
#define pre_defined_error_field (0x100300 + cUINT8 + cRD + cWR)
#define standard_error_field_0 (0x100301 + cUINT32 + cRD)
#define standard_error_field_1 (0x100302 + cUINT32 + cRD)
#define standard_error_field_2 (0x100303 + cUINT32 + cRD)
#define standard_error_field_3 (0x100304 + cUINT32 + cRD)
#define cob_id_sync (0x100500 + cUINT32 + cRD + cWR)
#define communication_cycle_period (0x100600 + cUINT32 + cRD + cWR)
#define synchronous_window_length (0x100700 + cUINT32 + cRD + cWR)
#define guard_time (0x100C00 + cUINT16 + cRD + cWR)
#define life_time_factor (0x100D00 + cUINT8 + cRD + cWR)
#define store_parameters (0x101000 + cUINT8 + cRD)
#define save_all_parameters (0x101001 + cUINT32 + cRD + cWR)
#define restore_parameters (0x101100 + cUINT8 + cRD)
#define restore_all_default_parameters (0x101101 + cUINT32 + cRD + cWR)
#define cob_id_time_stamp_message (0x101200 + cUINT32 + cRD + cWR)
#define cob_id_emergency_message (0x101400 + cUINT32 + cRD + cWR)
#define consumer_heartbeat_time (0x101600 + cUINT8 + cRD)
#define consumer_heartbeat_time_1 (0x101601 + cUINT32 + cRD + cWR)
#define producer_heartbeat_time (0x101700 + cUINT16 + cRD + cWR)
#define identity_object (0x101800 + cUINT8 + cRD)
#define vendor_id (0x101801 + cUINT32 + cRD)
#define product_code (0x101802 + cUINT32 + cRD)
#define revision_number (0x101803 + cUINT32 + cRD)
#define serial_number (0x101804 + cUINT32 + cRD)
#define server_sdo_parameter (0x120000 + cUINT8 + cRD)
#define cob_id_client_server (0x120001 + cUINT32 + cRD)
#define cob_id_server_client (0x120002 + cUINT32 + cRD)
#define receive_pdo_parameter_rpdo1 (0x140000 + cUINT8 + cRD)
#define cob_id_used_by_pdo_rpdo1 (0x140001 + cUINT32 + cRD + cWR)
#define transmission_type_rpdo1 (0x140002 + cUINT8 + cRD + cWR)
#define receive_pdo_parameter_rpdo2 (0x140100 + cUINT8 + cRD)
#define cob_id_used_by_pdo_rpdo2 (0x140101 + cUINT32 + cRD + cWR)
#define transmission_type_rpdo2 (0x140102 + cUINT8 + cRD + cWR)
#define receive_pdo_parameter_rpdo3 (0x140200 + cUINT8 + cRD)
#define cob_id_used_by_pdo_rpdo3 (0x140201 + cUINT32 + cRD + cWR)
#define transmission_type_rpdo3 (0x140202 + cUINT8 + cRD + cWR)
#define receive_pdo_parameter_rpdo4 (0x140300 + cUINT8 + cRD)
#define cob_id_used_by_pdo_rpdo4 (0x140301 + cUINT32 + cRD + cWR)
#define transmission_type_rpdo4 (0x140302 + cUINT8 + cRD + cWR)
#define receive_pdo_mapping_rpdo1 (0x160000 + cUINT8 + cRD + cWR)
#define first_mapped_object_rpdo1 (0x160001 + cUINT32 + cRD + cWR)
#define second_mapped_object_rpdo1 (0x160002 + cUINT32 + cRD + cWR)

```

```

#define third_mapped_object_rpdo1      (0x160003 + cRD + cWR    )
#define fourth_mapped_object_rpdo1     (0x160004 + cRD + cWR    )
#define receive_pdo_mapping_rpdo2     (0x160100 + cRD + cWR    )
#define first_mapped_object_rpdo2      (0x160101 + cRD + cWR    )
#define second_mapped_object_rpdo2     (0x160102 + cRD + cWR    )
#define third_mapped_object_rpdo2      (0x160103 + cRD + cWR    )
#define fourth_mapped_object_rpdo2     (0x160104 + cRD + cWR    )
#define receive_pdo_mapping_rpdo3     (0x160200 + cRD + cWR    )
#define first_mapped_object_rpdo3      (0x160201 + cRD + cWR    )
#define second_mapped_object_rpdo3     (0x160202 + cRD + cWR    )
#define third_mapped_object_rpdo3      (0x160203 + cRD + cWR    )
#define fourth_mapped_object_rpdo3     (0x160204 + cRD + cWR    )
#define receive_pdo_mapping_rpdo4     (0x160300 + cRD + cWR    )
#define first_mapped_object_rpdo4      (0x160301 + cRD + cWR    )
#define second_mapped_object_rpdo4     (0x160302 + cRD + cWR    )
#define third_mapped_object_rpdo4      (0x160303 + cRD + cWR    )
#define fourth_mapped_object_rpdo4     (0x160304 + cRD + cWR    )
#define transmit_pdo_parameter_tpdo1   (0x180000 + cRD      )
#define cob_id_used_by_pdo_tpdo1      (0x180001 + cRD + cWR    )
#define transmission_type_tpdo1        (0x180002 + cRD + cWR    )
#define inhibit_time_tpdo1            (0x180003 + cRD + cWR    )
#define transmit_pdo_parameter_tpdo2   (0x180100 + cRD      )
#define cob_id_used_by_pdo_tpdo2      (0x180101 + cRD + cWR    )
#define transmission_type_tpdo2        (0x180102 + cRD + cWR    )
#define inhibit_time_tpdo2            (0x180103 + cRD + cWR    )
#define transmit_pdo_parameter_tpdo3   (0x180200 + cRD      )
#define cob_id_used_by_pdo_tpdo3      (0x180201 + cRD + cWR    )
#define transmission_type_tpdo3        (0x180202 + cRD + cWR    )
#define inhibit_time_tpdo3            (0x180203 + cRD + cWR    )
#define transmit_pdo_parameter_tpdo4   (0x180300 + cRD      )
#define cob_id_used_by_pdo_tpdo4      (0x180301 + cRD + cWR    )
#define transmission_type_tpdo4        (0x180302 + cRD + cWR    )
#define inhibit_time_tpdo4            (0x180303 + cRD + cWR    )
#define transmit_pdo_mapping_tpdo1     (0x1A0000 + cRD + cWR    )
#define first_mapped_object_tpdo1       (0x1A0001 + cRD + cWR    )
#define second_mapped_object_tpdo1     (0x1A0002 + cRD + cWR    )
#define third_mapped_object_tpdo1      (0x1A0003 + cRD + cWR    )
#define fourth_mapped_object_tpdo1     (0x1A0004 + cRD + cWR    )
#define transmit_pdo_mapping_tpdo2     (0x1A0100 + cRD + cWR    )
#define first_mapped_object_tpdo2       (0x1A0101 + cRD + cWR    )
#define second_mapped_object_tpdo2     (0x1A0102 + cRD + cWR    )
#define third_mapped_object_tpdo2      (0x1A0103 + cRD + cWR    )
#define fourth_mapped_object_tpdo2     (0x1A0104 + cRD + cWR    )
#define transmit_pdo_mapping_tpdo3     (0x1A0200 + cRD + cWR    )
#define first_mapped_object_tpdo3       (0x1A0201 + cRD + cWR    )
#define second_mapped_object_tpdo3     (0x1A0202 + cRD + cWR    )
#define third_mapped_object_tpdo3      (0x1A0203 + cRD + cWR    )
#define fourth_mapped_object_tpdo3     (0x1A0204 + cRD + cWR    )
#define transmit_pdo_mapping_tpdo4     (0x1A0300 + cRD + cWR    )
#define first_mapped_object_tpdo4       (0x1A0301 + cRD + cWR    )
#define second_mapped_object_tpdo4     (0x1A0302 + cRD + cWR    )
#define third_mapped_object_tpdo4      (0x1A0303 + cRD + cWR    )
#define fourth_mapped_object_tpdo4     (0x1A0304 + cRD + cWR    )
#define manufacturer_statuswords      (0x200000 + cRD      )
#define manufacturer_statusword_1      (0x200001 + cRD + cWR + cPDO)
#define manufacturer_status_masks      (0x200500 + cRD      )
#define manufacturer_status_mask_1     (0x200501 + cRD + cWR + cPDO)

```

```

#define manufacturer_status_invert      (0x200A00 + UINT8 + cRD      )
#define manufacturer_status_invert_1    (0x200A01 + UINT32 + cRD + cWR + cPDO)
#define last_warning_code              (0x200F00 + UINT16 + cRD + cPDO )
#define tpdo1_transmit_mask           (0x201400 + UINT8 + cRD      )
#define tpdo1_transmit_mask_low       (0x201401 + UINT32 + cRD + cWR  )
#define tpdo1_transmit_mask_high      (0x201402 + UINT32 + cRD + cWR  )
#define tpdo2_transmit_mask           (0x201500 + UINT8 + cRD      )
#define tpdo2_transmit_mask_low       (0x201501 + UINT32 + cRD + cWR  )
#define tpdo2_transmit_mask_high      (0x201502 + UINT32 + cRD + cWR  )
#define tpdo3_transmit_mask           (0x201600 + UINT8 + cRD      )
#define tpdo3_transmit_mask_low       (0x201601 + UINT32 + cRD + cWR  )
#define tpdo3_transmit_mask_high      (0x201602 + UINT32 + cRD + cWR  )
#define tpdo4_transmit_mask           (0x201700 + UINT8 + cRD      )
#define tpdo4_transmit_mask_low       (0x201701 + UINT32 + cRD + cWR  )
#define tpdo4_transmit_mask_high      (0x201702 + UINT32 + cRD + cWR  )
#define encoder_emulation_data        (0x201A00 + UINT8 + cRD      )
#define encoder_emulation_resolution  (0x201A01 + INT32 + cRD + cWR )
#define encoder_emulation_offset      (0x201A02 + INT16 + cRD + cWR )
#define commutation_encoder_select   (0x201F00 + INT16 + cRD + cWR )
#define position_controller_resolution(0x202000 + UINT32 + cRD + cWR )
#define position_encoder_selection    (0x202100 + INT16 + cRD + cWR )
#define synchronisation_encoder_selection(0x202200 + INT16 + cRD + cWR )
#define synchronisation_filter_time  (0x202300 + UINT32 + cRD + cWR )
#define encoder_x2a_data_field       (0x202400 + UINT8 + cRD      )
#define encoder_x2a_resolution        (0x202401 + UINT32 + cRD      )
#define encoder_x2a_numerator         (0x202402 + INT16 + cRD + cWR )
#define encoder_x2a_divisor          (0x202403 + INT16 + cRD + cWR )
#define encoder_x10_data_field       (0x202500 + UINT8 + cRD      )
#define encoder_x10_resolution        (0x202501 + UINT32 + cRD + cWR )
#define encoder_x10_numerator         (0x202502 + INT16 + cRD + cWR )
#define encoder_x10_divisor          (0x202503 + INT16 + cRD + cWR )
#define encoder_x10_counter          (0x202504 + UINT32 + cRD + cPDO)
#define encoder_x2b_data_field       (0x202600 + UINT8 + cRD      )
#define encoder_x2b_resolution        (0x202601 + UINT32 + cRD + cWR )
#define encoder_x2b_numerator         (0x202602 + INT16 + cRD + cWR )
#define encoder_x2b_divisor          (0x202603 + INT16 + cRD + cWR )
#define encoder_x2b_counter          (0x202604 + UINT32 + cRD + cPDO)
#define encoder_emulation_resolution  (0x202800 + INT32 + cRD + cWR )
#define position_demand_sync_value   (0x202D00 + INT32 + cRD      )
#define velocity_demand_sync_value   (0x202E00 + INT32 + cRD      )
#define synchronisation_selector_data(0x202F00 + UINT8 + cRD      )
#define synchronisation_main          (0x202F07 + UINT16 + cRD + cWR )
#define set_position_absolute         (0x203000 + INT32 + cWR      )
#define torque_feed_forward          (0x203A00 + UINT32 + cRD + cWR )
#define homing_timeout                (0x204500 + UINT16 + cRD + cWR )
#define sample_data                   (0x204A00 + UINT8 + cRD      )
#define sample_mode                   (0x204A01 + UINT16 + cRD + cWR )
#define sample_status                 (0x204A02 + UINT8 + cRD + cPDO)
#define sample_status_mask            (0x204A03 + UINT8 + cRD + cWR + cPDO)
#define sample_control                (0x204A04 + UINT8 + cWR + cPDO)
#define sample_position_rising_edge   (0x204A05 + INT32 + cRD + cPDO)
#define sample_position_falling_edge  (0x204A06 + INT32 + cRD + cPDO)
#define velocity_display_filter_time (0x207300 + UINT32 + cRD + cWR )
#define velocity_actual_value_filtered(0x207400 + INT32 + cRD + cPDO)
#define velocity_message              (0x207800 + UINT8 + cRD      )
#define message_target_velocity       (0x207801 + INT32 + cRD + cWR )
#define message_velocity_window       (0x207802 + INT16 + cRD + cWR )

```

```

#define velocity_ramps          (0x209000 + UINT8 + cRD      )
#define velocity_rampe_enable    (0x209001 + UINT8 + cRD + cWR   )
#define velocity_acceleration_pos (0x209002 + INT32 + cRD + cWR   )
#define velocity_deceleration_pos (0x209003 + INT32 + cRD + cWR   )
#define velocity_acceleration_neg (0x209004 + INT32 + cRD + cWR   )
#define velocity_deceleration_neg (0x209005 + INT32 + cRD + cWR   )
#define error_management         (0x210000 + UINT8 + cRD      )
#define error_number              (0x210001 + UINT8 + cRD + cWR   )
#define error_reaction_code      (0x210002 + UINT8 + cRD + cWR   )
#define read_write_ko_nr         (0x220000 + UINT32 + cRD + cWR   )
#define read_ko                  (0x220400 + UINT32 + cRD      )
#define write_ko                 (0x221400 + UINT32 + cWR      )
#define read_ko_record            (0x221500 + UINT8 + cRD      )
#define read_ko_demand_value     (0x221501 + UINT32 + cRD      )
#define read_ko_actual_value      (0x221502 + UINT32 + cRD      )
#define read_ko_minimum           (0x221503 + UINT32 + cRD      )
#define read_ko_maximum           (0x221504 + UINT32 + cRD      )
#define analog_input_voltage      (0x240000 + UINT8 + cRD      )
#define analog_input_voltage_ch_0 (0x240001 + INT16 + cRD      )
#define analog_input_voltage_ch_1 (0x240002 + INT16 + cRD      )
#define analog_input_voltage_ch_2 (0x240003 + INT16 + cRD      )
#define analog_input_offset       (0x240100 + UINT8 + cRD      )
#define analog_input_offset_ch_0  (0x240101 + INT32 + cRD + cWR   )
#define analog_input_offset_ch_1  (0x240102 + INT32 + cRD + cWR   )
#define analog_input_offset_ch_2  (0x240103 + INT32 + cRD + cWR   )
#define current_limitation       (0x241500 + UINT8 + cRD      )
#define limit_current_input_channel (0x241501 + INT8 + cRD + cWR   )
#define limit_current             (0x241502 + INT32 + cRD + cWR   )
#define speed_limitation          (0x241600 + UINT8 + cRD      )
#define limit_speed_input_channel (0x241601 + INT8 + cRD + cWR   )
#define limit_speed               (0x241602 + INT32 + cRD + cWR   )
#define digital_outputs_state_mapping (0x242000 + UINT8 + cRD      )
#define dig_out_state_mapp_dout_1 (0x242001 + UINT8 + cRD + cWR   )
#define dig_out_state_mapp_dout_2 (0x242002 + UINT8 + cRD + cWR   )
#define dig_out_state_mapp_dout_3 (0x242003 + UINT8 + cRD + cWR   )
#define dig_out_state_mapp_ea88_0_low (0x242011 + INT32 + cRD + cWR   )
#define dig_out_state_mapp_ea88_0_high (0x242012 + INT32 + cRD + cWR   )
#define digital_inputs_low_byte   (0x2C0A00 + UINT8 + cRD + cPDO )
#define error_code                (0x603F00 + UINT16 + cRD + cPDO )
#define controlword               (0x604000 + UINT16 + cRD + cWR + cPDO )
#define statusword                (0x604100 + UINT16 + cRD + cPDO )
#define pole_number                (0x604D00 + UINT8 + cRD + cWR + cPDO )
#define quick_stop_option_code    (0x605A00 + INT16 + cRD + cWR   )
#define shutdown_option_code       (0x605B00 + INT16 + cRD + cWR   )
#define disable_operation_option_code (0x605C00 + INT16 + cRD + cWR   )
#define stop_option_code           (0x605D00 + INT16 + cRD + cWR   )
#define fault_reaction_option_code (0x605E00 + INT16 + cRD + cWR   )
#define modes_of_operation          (0x606000 + INT8 + cRD + cWR + cPDO )
#define modes_of_operation_display (0x606100 + INT8 + cRD + cPDO )
#define position_demand_value     (0x606200 + INT32 + cRD + cPDO )
#define position_actual_value_star (0x606300 + INT32 + cRD + cPDO )
#define position_actual_value     (0x606400 + INT32 + cRD + cPDO )
#define following_error_window    (0x606500 + UINT32 + cRD + cWR + cPDO )
#define following_error_time_out  (0x606600 + UINT16 + cRD + cWR + cPDO )
#define position_window            (0x606700 + UINT32 + cRD + cWR + cPDO )
#define position_window_time      (0x606800 + UINT16 + cRD + cWR + cPDO )
#define velocity_sensor_actual_value (0x606900 + INT32 + cRD + cPDO )

```

```

#define sensor_selection_code          (0x606A00 + INT16 + cRD + cWR + cPDO )
#define velocity_demand_value         (0x606B00 + INT32 + cRD + cPDO )
#define velocity_actual_value          (0x606C00 + INT32 + cRD + cPDO )
#define velocity_window               (0x606D00 + UINT16 + cRD + cWR + cPDO )
#define velocity_window_time          (0x606E00 + UINT16 + cRD + cWR + cPDO )
#define velocity_threshold             (0x606F00 + UINT16 + cRD + cWR + cPDO )
#define velocity_threshold_time        (0x607000 + UINT16 + cRD + cWR + cPDO )
#define target_torque                 (0x607100 + INT16 + cRD + cWR + cPDO )
#define max_torque                    (0x607200 + UINT16 + cRD + cWR + cPDO )
#define max_current                   (0x607300 + UINT16 + cRD + cWR + cPDO )
#define torque_demand_value           (0x607400 + INT16 + cRD + cPDO )
#define motor_rated_current           (0x607500 + UINT32 + cRD + cWR + cPDO )
#define motor_rated_torque            (0x607600 + UINT32 + cRD + cWR + cPDO )
#define torque_actual_value           (0x607700 + INT16 + cRD + cPDO )
#define current_actual_value          (0x607800 + INT16 + cRD + cPDO )
#define dc_link_circuit_voltage       (0x607900 + UINT32 + cRD + cPDO )
#define target_position                (0x607A00 + INT32 + cRD + cWR + cPDO )
#define position_range_limit           (0x607B00 + UINT8 + cRD      )
#define min_position_range_limit       (0x607B01 + INT32 + cRD + cWR + cPDO )
#define max_position_range_limit       (0x607B02 + INT32 + cRD + cWR + cPDO )
#define home_offset                    (0x607C00 + INT32 + cRD + cWR + cPDO )
#define software_position_limit        (0x607D00 + UINT8 + cRD      )
#define min_position_limit             (0x607D01 + INT32 + cRD + cWR + cPDO )
#define max_position_limit             (0x607D02 + INT32 + cRD + cWR + cPDO )
#define polarity                       (0x607E00 + UINT8 + cRD + cWR + cPDO )
#define max_motor_speed                (0x608000 + UINT16 + cRD + cWR + cPDO )
#define profile_velocity                (0x608100 + INT32 + cRD + cWR + cPDO )
#define end_velocity                   (0x608200 + INT32 + cRD + cWR + cPDO )
#define profile_acceleration           (0x608300 + INT32 + cRD + cWR + cPDO )
#define profile_deceleration           (0x608400 + INT32 + cRD + cWR + cPDO )
#define quick_stop_deceleration        (0x608500 + INT32 + cRD + cWR + cPDO )
#define motion_profile_type            (0x608600 + INT16 + cRD + cWR + cPDO )
#define torque_slope                   (0x608700 + INT32 + cRD + cWR + cPDO )
#define torque_profile_type            (0x608800 + INT16 + cRD + cWR + cPDO )
#define position_notation_index        (0x608900 + INT8 + cRD + cWR + cPDO )
#define position_dimension_index       (0x608A00 + UINT8 + cRD + cWR + cPDO )
#define velocity_notation_index        (0x608B00 + INT8 + cRD + cWR + cPDO )
#define velocity_dimension_index       (0x608C00 + INT8 + cRD + cWR + cPDO )
#define acceleration_notation_index   (0x608D00 + INT8 + cRD + cWR + cPDO )
#define acceleration_dimension_index   (0x608E00 + INT8 + cRD + cWR + cPDO )
#define position_encoder_resolution    (0x608F00 + UINT8 + cRD      )
#define encoder_increments              (0x608F01 + INT32 + cRD + cWR + cPDO )
#define motor_revolutions               (0x608F02 + INT32 + cRD + cWR + cPDO )
#define velocity_encoder_resolution     (0x609000 + UINT8 + cRD      )
#define encoder_increments_per_second  (0x609001 + INT32 + cRD + cWR + cPDO )
#define motor_revolutions_per_second   (0x609002 + INT32 + cRD + cWR + cPDO )
#define gear_ratio                      (0x609100 + INT8 + cRD      )
#define motor_revolutions               (0x609101 + INT32 + cRD + cWR + cPDO )
#define shaft_revolutions               (0x609102 + INT32 + cRD + cWR + cPDO )
#define feed_constant                  (0x609200 + INT8 + cRD      )
#define feed                            (0x609201 + INT32 + cRD + cWR + cPDO )
#define shaft_revolutions               (0x609202 + INT32 + cRD + cWR + cPDO )
#define position_factor                 (0x609300 + INT8 + cRD      )
#define numerator                       (0x609301 + INT32 + cRD + cWR + cPDO )
#define divisor                         (0x609302 + INT32 + cRD + cWR + cPDO )
#define velocity_encoder_factor         (0x609400 + INT8 + cRD      )
#define numerator                       (0x609401 + INT32 + cRD + cWR + cPDO )

```

```

#define divisor (0x609402 + UINT32 + cRD + cWR + cPDO )
#define velocity_factor_1 (0x609500 + UINT8 + cRD      )
#define numerator (0x609501 + UINT32 + cRD + cWR + cPDO )
#define divisor (0x609502 + UINT32 + cRD + cWR + cPDO )
#define velocity_factor_2 (0x609600 + UINT8 + cRD      )
#define numerator (0x609601 + UINT32 + cRD + cWR + cPDO )
#define divisor (0x609602 + UINT32 + cRD + cWR + cPDO )
#define acceleration_factor (0x609700 + UINT8 + cRD      )
#define numerator (0x609701 + UINT32 + cRD + cWR + cPDO )
#define divisor (0x609702 + UINT32 + cRD + cWR + cPDO )
#define homing_method (0x609800 + INT8 + cRD + cWR + cPDO )
#define homing_speeds (0x609900 + UINT8 + cRD      )
#define speed_during_search_for_switch (0x609901 + UINT32 + cRD + cWR + cPDO )
#define speed_during_search_for_zero (0x609902 + UINT32 + cRD + cWR + cPDO )
#define homing_acceleration (0x609A00 + UINT32 + cRD + cWR + cPDO )
#define interpolation_submode_select (0x60C000 + INT16 + cRD + cWR + cPDO )
#define interpolation_data_record (0x60C100 + UINT8 + cRD      )
#define ip_data_position (0x60C101 + INT32 + cRD + cWR + cPDO )
#define ip_data_controlword (0x60C102 + UINT8 + cRD + cWR + cPDO )
#define interpolation_time_period (0x60C200 + UINT8 + cRD      )
#define ip_time_units (0x60C201 + UINT8 + cRD + cWR + cPDO )
#define ip_time_index (0x60C202 + INT8 + cRD + cWR + cPDO )
#define interpolation_sync_definition (0x60C300 + UINT8 + cRD      )
#define synchronize_on_group (0x60C301 + UINT8 + cRD + cWR + cPDO )
#define ip_sync_every_n_event (0x60C302 + UINT8 + cRD + cWR + cPDO )
#define interpolation_data_configuration (0x60C400 + UINT8 + cRD      + cPDO )
#define max_buffer_size (0x60C401 + UINT32 + cRD      )
#define actual_size (0x60C402 + UINT32 + cRD + cWR + cPDO )
#define buffer_organisation (0x60C403 + UINT8 + cRD + cWR + cPDO )
#define buffer_position (0x60C404 + INT16 + cRD + cWR + cPDO )
#define size_of_data_record (0x60C405 + UINT8      + cWR + cPDO )
#define buffer_clear (0x60C406 + UINT8      + cWR + cPDO )
#define torque_control_parameters (0x60F600 + UINT8 + cRD      )
#define torque_control_gain (0x60F601 + INT16 + cRD + cWR      )
#define torque_control_time (0x60F602 + INT16 + cRD + cWR      )
#define velocity_control_parameter_set (0x60F900 + UINT8 + cRD      )
#define velocity_control_gain (0x60F901 + INT16 + cRD + cWR      )
#define velocity_control_time (0x60F902 + INT16 + cRD + cWR      )
#define velocity_control_filter_time (0x60F904 + INT16 + cRD + cWR      )
#define control_effort (0x60FA00 + INT32 + cRD      + cPDO )
#define position_control_parameter_set (0x60FB00 + UINT8 + cRD      )
#define position_control_gain (0x60FB01 + INT16 + cRD + cWR      )
#define position_control_time (0x60FB02 + INT16 + cRD + cWR      )
#define position_control_v_max (0x60FB04 + UINT32 + cRD + cWR      )
#define position_error_tolerance_window (0x60FB05 + UINT32 + cRD + cWR      )
#define digital_inputs (0x60FD00 + UINT32 + cRD      + cPDO )
#define digital_outputs (0x60FE00 + UINT8 + cRD      )
#define digital_outputs_data (0x60FE01 + UINT32 + cRD + cWR + cPDO )
#define digital_outputs_mask (0x60FE02 + UINT32 + cRD + cWR + cPDO )
#define target_velocity (0x60FF00 + INT32 + cRD + cWR + cPDO )
#define motor_type (0x640200 + INT16 + cRD      + cPDO )
#define motor_data (0x641000 + UINT8 + cRD      )
#define iit_time_motor (0x641003 + INT16 + cRD + cWR      )
#define iit_ratio_motor (0x641004 + INT16 + cRD      )
#define phase_order (0x641010 + INT16 + cRD + cWR      )
#define encoder_offset_angle (0x641011 + INT16 + cRD + cWR + cPDO )
#define motor_temperature_sensor_polarity (0x641014 + INT16 + cRD + cWR + cPDO )

```

```

#define supported_drive_modes      (0x650200 + UINT32 + cRD + cPDO )
#define drive_data                (0x651000 + UINT8 + cRD      )
#define serial_number              (0x651001 + UINT32 + cRD      )
#define drive_code                 (0x651002 + UINT32 + cRD      )
#define user_variable_not_saved    (0x651003 + INT16 + cRD + cWR   )
#define user_variable_saved        (0x651004 + INT16 + cRD + cWR   )
#define enable_logic               (0x651010 + UINT16 + cRD + cWR   )
#define limit_switch_polarity     (0x651011 + INT16 + cRD + cWR   )
#define limit_switch_selector      (0x651012 + INT16 + cRD + cWR   )
#define homing_switch_selector    (0x651013 + INT16 + cRD + cWR   )
#define homing_switch_polarity    (0x651014 + INT16 + cRD + cWR   )
#define limit_switch_deceleration (0x651015 + INT32 + cRD + cWR   )
#define brake_delay_time          (0x651018 + UINT16 + cRD + cWR   )
#define automatic_brake_delay     (0x651019 + UINT16 + cRD + cWR   )
#define position_range_limit_enable(0x651020 + UINT16 + cRD + cWR   )
#define position_error_switch_off_limit (0x651022 + UINT32 + cRD + cWR   )
#define motor_temperature         (0x65102E + INT16 + cRD + cPDO )
#define max_motor_temperature     (0x65102F + INT16 + cRD + cWR   )
#define pwm_frequency              (0x651030 + UINT16 + cRD + cWR   )
#define power_stage_temperature   (0x651031 + INT16 + cRD + cPDO )
#define max_power_stage_temperature(0x651032 + INT16 + cRD      )
#define nominal_dc_link_circuit_voltage (0x651033 + UINT32 + cRD      )
#define actual_dc_link_circuit_voltage (0x651034 + UINT32 + cRD + cPDO )
#define max_dc_link_circuit_voltage (0x651035 + UINT32 + cRD      )
#define min_dc_link_circuit_voltage (0x651036 + UINT32 + cRD + cWR   )
#define enable_dc_link_undervoltage_error (0x651037 + UINT16 + cRD + cWR   )
#define iit_error_enable           (0x651038 + UINT16 + cRD + cWR   )
#define enable_enhanced_modulation (0x65103A + UINT16 + cRD + cWR   )
#define iit_ratio_servo            (0x65103D + UINT16 + cRD + cPDO )
#define nominal_current            (0x651040 + UINT32 + cRD      )
#define peak_current                (0x651041 + UINT32 + cRD      )
#define drive_serial_number          (0x6510A0 + UINT32 + cRD      )
#define drive_type                  (0x6510A1 + UINT32 + cRD      )
#define drive_revision              (0x6510A2 + UINT32 + cRD      )
#define encoder_serial_number       (0x6510A3 + UINT32 + cRD      )
#define encoder_type                (0x6510A4 + UINT32 + cRD      )
#define encoder_revision            (0x6510A5 + UINT32 + cRD      )
#define module_serial_number        (0x6510A6 + UINT32 + cRD      )
#define module_type                  (0x6510A7 + UINT32 + cRD      )
#define module_revision              (0x6510A8 + UINT32 + cRD      )
#define firmware_main_version       (0x6510A9 + UINT32 + cRD      )
#define firmware_custom_version     (0x6510AA + UINT32 + cRD      )
#define mdc_version                 (0x6510AB + UINT32 + cRD      )
#define firmware_type                (0x6510AC + UINT32 + cRD      )
#define km_release                  (0x6510AD + UINT32 + cRD      )
#define cycletime_current_controller (0x6510B0 + UINT32 + cRD      )
#define cycletime_velocity_controller (0x6510B1 + UINT32 + cRD      )
#define cycletime_position_controller (0x6510B2 + UINT32 + cRD      )
#define cycletime_trajectory_generator (0x6510B3 + UINT32 + cRD      )
#define device_current                (0x6510B8 + UINT32 + cRD      )
#define commissioning_state         (0x6510C0 + UINT32 + cRD + cWR   )
#define compatibility_control        (0x6510F0 + UINT16 + cRD + cWR   )

/*****************************************/
/* 'magic' word for loading parameter */
/*****************************************/
#define cLOAD 0x64616F6C

```

```

#define cSAVE 0x65766173

/*****************************************/
/* modes of operation */
/*****************************************/
#define cPositionMode 0x01
#define cVelocityMode 0x03
#define cTorqueMode 0x04
#define cHomingMode 0x06
#define cInterpolatedMode 0x07
#define cUnknownMode 0xFF

/*****************************************/
/* digital inputs */
/*****************************************/
#define cEND0 0x00000001 /* negative limit switch */
#define cEND1 0x00000002 /* positive limit switch */
#define cHOME_SAMPLE 0x00000004 /* Home / Sample */
#define cLOCK 0x00000008 /* controller or power stage disabled */
#define cPOS0 0x01000000 /* Digital Input Target selector */
#define cPOS1 0x02000000 /* Digital Input Target selector */
#define cPOS2 0x04000000 /* Digital Input Target selector */
#define cPOS3 0x08000000 /* Digital Input Target selector */
#define cSTART 0x10000000
#define cSAMPLE 0x20000000

/* ----- Definition according to the connectors name----- */
#define cDINO cPOS0
#define cDIN1 cPOS1
#define cDIN2 cPOS2
#define cDIN3 cPOS3
#define cDIN5 cLOCK
#define cDIN6 cEND0
#define cDIN7 cEND1
#define cDIN8 cSTART
#define cDIN9 cSAMPLE

/*****************************************/
/* controlword */
/*****************************************/
#define cwSHUT_DOWN 0x0006
#define cwSWITCH_ON 0x0007
#define cwDISABLE_VOLTAGE 0x0000
#define cwQUICK_STOP 0x0002
#define cwDISABLE_OPERATION 0x0007
#define cwENABLE_OPERATION 0x000F
#define cwFAULT_RESET 0x0080 /* Fault Reset with rising edge */

#define cwNEW_SET_POINT 0x0010
#define cwSTART_HOMING_OPERATION 0x0010
#define cwENABLE_IP_MODE 0x0010
#define cwCHANGE_SET_IMMEDIATELY 0x0020
#define cwABSOLUTE_RELATIV 0x0040
#define cwHOLD 0x0100

/*****************************************/
/* statusword */
/*****************************************/
/* state definition */

```

```
#define cdNOT_READY_TO_SWITCH_ON    0x0000
#define cdSWITCHED_ON_DISABLED      0x0040
#define cdREADY_TO_SWITCH_ON        0x0021
#define cdSWITCHED_ON               0x0023
#define cdOPERATION_ENABLED         0x0027
#define cdFAULT                      0x000F
#define cdFAULT_REACTION_ACTIVE     0x000F
#define cdQUICK_STOP_ACTIVE          0x0007

/* Bits of status word */
#define swVOLTAGE_DISABLED          0x0010
#define swSWITCH_ON_DISABLED         0x0040
#define swWARNING                     0x0080
#define swREMOTE                      0x0200
#define swTARGET_REACHED              0x0400
#define swINTERNAL_LIMIT_ACTIVE      0x0800
#define swSET_POINT_ACKNOWLEDGE     0x1000
#define swSPEED0                      0x1000
#define swHOMING_ATAINED              0x1000
#define swIP_MODE_ACTIVE              0x1000
#define swFOLLOWING_ERROR             0x2000
#define swHOMING_ERROR                0x2000

/* position modes */
#define pCONTINUOUS                 0x0000
#define pIMMEDIATE                   0x0020
#define pABSOLUTE                     0x0000
#define pRELATIVE                     0x0040

/* motion profile types */
#define mpLINEAR                      0
```

10 Keyword index

7

7 segment display

'A' on..... 172

A

A on 7 segment display	172
acceleration_factor	78
Action on command 'disable operation'	199
Action on command 'quick stop'	199
actual_dc_link_circuit_voltage.....	88
actual_size	235
analog_input_offset.....	144
analog_input_offset_ch_0.....	144
analog_input_offset_ch_1.....	145
analog_input_offset_ch_2.....	145
analog_input_voltage.....	143
analog_input_voltage_ch_0.....	143
analog_input_voltage_ch_1.....	144
analog_input_voltage_ch_2.....	144
Analogue inputs.....	143

B

Bootup	57
brake_delay_time.....	163
buffer_clear	236
buffer_organisation.....	235
buffer_position.....	236

C

Cabling	24
cabling hints	25
CAN interface	
Characteristics of the.....	260
cob_id_sync	48
cob_id_used_by_pdo	40
commissioning_state	172
commutation_encoder_select.....	137
commutation_valid.....	193
compatibility_control.....	67
Control of the device.....	177
control_effort.....	118
controlword	183
Bits of the	184
Commands	185
Description.....	183
Conversion factors	70
Sign.....	81
Current controller.....	93
Parameters	103
Current DC link voltage	88
Current limitation	124
current_actual_value	257
current_limitation	124
cycletime_current_controller	169
cycletime_position_controller	170
cycletime_tracectory_generator	171
cycletime_velocity_controller.....	170

D

DC link voltage	
current.....	88

maximum	88
dc_link_circuit_voltage	258
Demand value	
Position (position_units).....	114
Device Control.....	177
dig_out_state_mapp_dout_1.....	150
dig_out_state_mapp_dout_2.....	150
dig_out_state_mapp_dout_3.....	150
Digital outputs	
Mapping of DOUT1	150
Mapping of DOUT2	150
Mapping of DOUT3	150
Digital outputs	
Mapping	150
digital_inputs	147
digital_outputs	148
digital_outputs_data.....	148
digital_outputs_mask.....	148
digital_outputs_state_mapping.....	150
disable_operation_option_code.....	199
Display, 7 segment	
'A' on.....	172
divisor	
acceleration_factor	78
position_factor.....	72
velocity_encoder_factor.....	75
drive_data	83, 101, 120, 122, 152, 163, 166
drive_serial_number.....	166
drive_type.....	166
encoder_x10_counter	133
encoder_x10_data_field	132
encoder_x10_divisor	132
encoder_x10_numerator	132
encoder_x10_resolution	132
encoder_x2a_data_field	128
encoder_x2a_divisor	128
encoder_x2a_numerator.....	128
encoder_x2a_resolution.....	128
encoder_x2b_counter	130
encoder_x2b_data_field	129
encoder_x2b_divisor	130
encoder_x2b_numerator.....	129
encoder_x2b_resolution.....	129
end_velocity.....	221
Error	
'A' on 7 segment display	172
Error of servo controller.....	49
pre_defined_error_field	53
SDO-Error messages	32
Error codes	175
Error Control Protocol	
Bootup.....	57
Heartbeat	58
Node guarding	60
Error management	174
Error message	49
Error reaction	175
error_management.....	174
error_number	175
error_reaction_code	175
Exceedance limit value following error.....	120

E

EMERGENCY.....	48, 49
EMERGENCY message	48
Structure of an.....	49
enable_dc_link_undervoltage_error	89
enable_enhanced_modulation.....	84
enable_logic	83
Enabling the device.....	177
encoder_emulation_data.....	135
encoder_emulation_offset.....	135
encoder_emulation_resolution	135, 136
encoder_offset_angle	100
encoder_x10_counter	133

F

Factor Group	70
acceleration_factor.....	78
polarity	81
position_factor	72
velocity_encoder_factor	75
Fault	180
Fault Reaction Active	180
fault_reaction_option_code	200
Faults	48
Filter time constant synchronous speed	142

firmware_custom_version	167
firmware_main_version	167
firmware_type	169
first_mapped_object	41
Following error	107
Limit value exceedance	120
following_error_time_out	118
following_error_window	117
fourth_mapped_object	42
 G	
guard_time	61
 H	
Heartbeat	58
home_offset	207
Homing	
Timeout	210
Homing methods	211
Homing mode	205
home_offset	207
homing_acceleration	210
homing_method	207
homing_speeds	208
Speed during search for switch	208
Speed during search for zero	209
Homing operation	205
Control of the	217
Homing switches	152
homing_acceleration	210
homing_method	207
homing_speeds	208
homing_switch_polarity	154
homing_switch_selector	155
homing_timeout	210
 I	
Identifier	
NMT service	54
identity_object	164
iit_error	98
iit_error_enable	98
iit_ratio_motor	97
iit_time_motor	97
Incremental encoder emulation	
Offset	135
Resolution	135, 136
inhibit_time	40
Inputs	
Analogue	143
interpolation_data_configuration	234
interpolation_data_record	230
interpolation_submode_select	229
interpolation_sync_definition	232
interpolation_time_period	231
Interpolation-Type	229
ip_data_controlword	230
ip_data_position	230
ip_sync every n event	233
ip_time_index	231
ip_time_units	231
is_referenced	193
 K	
km_release	168
 L	
last_warning_code	176
Limit stop	215, 216
Limit switch	211, 213
Limit switches	152
Limit value	
Following error	120
limit_current	124, 125
limit_current_input_channel	124
limit_speed_input_channel	125
limit_switch_deceleration	155
limit_switch_polarity	152
limit_switch_selector	153
Load and save parameter sets	63

M

manufacturer_status_invert.....	197
manufacturer_status_invert_1.....	197
manufacturer_status_mask_1.....	196
manufacturer_status_masks.....	196
manufacturer_statusword_1.....	193
Bit assignment.....	193
manufacturer_statuswords.....	193
Max. current.....	95
Max. DC link voltage.....	88
max_buffer_size.....	235
max_current.....	95
max_dc_link_circuit_voltage.....	88
max_motor_speed.....	250
max_motor_temperature.....	102
max_position_range_limit.....	121
max_power_stage_temperature.....	86
max_torque.....	255
Maximum current.....	92
Maximum power stage temperature.....	86
min_dc_link_circuit_voltage.....	89
min_position_range_limit.....	121
Mode of operation	
Profile Position Mode	218
Profile Torque Mode.....	253
Profile Velocity Mode.....	241
modes_of_operation.....	202
modes_of_operation_display.....	203
motion_profile_type.....	223
Motor adaptation.....	93
Motor parameter	
iit time	97
Max. current.....	95
Number of poles.....	96
Phase order.....	99
Rated current.....	94
Resolver offset angle.....	100
motor_data.....	100
motor_rated_current.....	94
motor_rated_torque.....	256
motor_temperatur_sensor_polarity	101
motor_temperature.....	101

N

NMT service.....	54
Nodeguarding	60
guard_time.....	61
life_time_factor	62
nominal_voltage	86
nominal_current	91
nominal_dc_link_circuit_voltage	86
Not Ready to Switch On	180
Number of poles.....	96
number_of_mapped_objects	41
numerator	
acceleration_factor.....	78
position_factor	72
velocity_encoder_factor	75

O

Objects

Object 1000 _h	63
Object 1001 _h	63
Object 1002 _h	63
Object 1003 _h	53
Object 1003 _h _01 _h	53
Object 1003 _h _02 _h	53
Object 1003 _h _03 _h	53
Object 1003 _h _04 _h	53
Object 1005 _h	48
Object 1006 _h	63
Object 1007 _h	63
Object 100C _h	61
Object 100D _h	62
Object 1010 _h	66
Object 1010 _h _01 _h	66
Object 1011 _h	65
Object 1011 _h	65
Object 1011 _h _01 _h	65
Object 1017 _h	58
Object 1018 _h	164
Object 1018 _h _01 _h	164
Object 1018 _h _02 _h	164
Object 1018 _h _03 _h	165

Object 1018_h_04_h.....	165
Object 1400h.....	45
Object 1401_h.....	45
Object 1402_h.....	45
Object 1403_h.....	45
Object 1600h.....	45
Object 1601_h.....	45
Object 1602_h.....	45
Object 1603_h.....	45
Object 1800h.....	40, 42
Object 1800_h_01_h.....	40
Object 1800_h_02_h.....	40
Object 1800_h_03_h.....	40
Object 1801h.....	42
Object 1802_h.....	43
Object 1803_h.....	43
Object 1A00h.....	41, 42
Object 1A00_h_00_h.....	41
Object 1A00_h_01_h.....	41
Object 1A00_h_02_h.....	41
Object 1A00_h_03_h.....	41
Object 1A00_h_04_h.....	42
Object 1A01h.....	42
Object 1A02_h.....	43
Object 1A03_h.....	43
Object 2000h.....	193
Object 2000_h_01_h.....	193
Object 2005h.....	196
Object 2005_h_01_h.....	196
Object 200Ah.....	197
Object 200Ah_01_h.....	197
Object 200F_h.....	176
Object 2014_h.....	43
Object 2015_h.....	43
Object 2016_h.....	44
Object 2017_h.....	44
Object 201Ah.....	135
Object 201Ah_01_h.....	135
Object 201Ah_02_h.....	135
Object 201F_h.....	137
Object 2021_h.....	139
Object 2022_h.....	140
Object 2023_h.....	142
Object 2024_h.....	128
Object 2024_h_01_h.....	128
Object 2024h_02_h.....	128
Object 2024h_03_h.....	128
Object 2025_h.....	132
Object 2025_h_01_h.....	132
Object 2025_h_02_h.....	132
Object 2025_h_03_h.....	132
Object 2025_h_04_h.....	133
Object 2026h.....	129
Object 2026_h_01_h.....	129
Object 2026_h_02_h.....	129
Object 2026_h_03_h.....	130
Object 2026_h_04_h.....	130
Object 2028_h.....	136
Object 202D_h.....	115
Object 202E_h.....	246
Object 202F_h.....	141
Object 202F_h_07_h.....	141
Object 2030_h.....	123
Object 2045h.....	210
Object 204Ah.....	157
Object 204Ah_01_h.....	157
Object 204Ah_02_h.....	158
Object 204Ah_03_h.....	159
Object 204Ah_04_h.....	159
Object 204Ah_05_h.....	161
Object 204Ah_06_h.....	161
Object 2073_h.....	106
Object 2074_h.....	247
Object 2090h.....	251
Object 2090_h_01_h.....	251
Object 2090_h_02_h.....	252
Object 2090_h_03_h.....	252
Object 2090_h_04_h.....	252
Object 2090_h_05_h.....	252
Object 2100h.....	174
Object 2100_h_01_h.....	175
Object 2100_h_02_h.....	175
Object 2400h.....	143
Object 2400h_01h.....	143
Object 2400h_02h.....	144
Object 2400h_03h.....	144
Object 2401h.....	144
Object 2401_h_01h.....	144
Object 2401_h_02h.....	145
Object 2401_h_03h.....	145

Object 2415 _h	124	Object 607B _h	121
Object 2415 _{h_01}	124	Object 607B _{h_01}	121
Object 2415 _{h_02}	124	Object 607B _{h_02}	121
Object 2416 _h	125	Object 607C _h	207
Object 2416 _{h_01}	125	Object 607E _h	81
Object 2416 _{h_02}	125	Object 6080 _h	250
Object 2420 _h	150	Object 6081 _h	221
Object 2420 _{h_01}	150	Object 6082 _h	221
Object 2420 _{h_02}	150	Object 6083 _h	222
Object 2420 _{h_03}	150	Object 6084 _h	222
Object 6040 _h	183	Object 6085 _h	223
Object 6040 _h	183	Object 6086 _h	223
Object 6041 _h	188	Object 6087 _h	258
Object 604D _h	96	Object 6088 _h	259
Object 605A _h	199	Object 6093 _h	72
Object 605B _h	198	Object 6093 _{h_01}	72
Object 605C _h	199	Object 6093 _{h_02}	72
Object 605E _h	200	Object 6094 _h	75
Object 6060 _h	202	Object 6094 _{h_01}	75
Object 6061 _h	203	Object 6094 _{h_02}	75
Object 6062 _h	114	Object 6097 _h	78
Object 6062 _h	114	Object 6097 _{h_01}	78
Object 6064 _h	116	Object 6097 _{h_02}	78
Object 6065 _h	117	Object 6098 _h	207
Object 6066 _h	118	Object 6099 _h	208
Object 6067 _h	119	Object 6099 _{h_01}	208
Object 6068 _h	119	Object 6099 _{h_02}	209
Object 6069 _h	244	Object 609A _h	210
Object 606A _h	245	Object 60C0 _h	229
Object 606B _h	245	Object 60C1 _h	230
Object 606C _h	246	Object 60C1 _{h_01}	230
Object 606D _h	248	Object 60C1 _{h_02}	230
Object 606E _h	248	Object 60C2 _h	231
Object 606F _h	249	Object 60C2 _{h_01}	231
Object 6070 _h	249	Object 60C2 _{h_02}	231
Object 6071 _h	255	Object 60C3 _h	232
Object 6072 _h	255	Object 60C3 _{h_01}	232
Object 6073 _h	95	Object 60C3 _{h_02}	233
Object 6074 _h	256	Object 60C4 _h	234
Object 6075 _h	94	Object 60C4 _{h_01}	235
Object 6076 _h	256	Object 60C4 _{h_02}	235
Object 6077 _h	257	Object 60C4 _{h_03}	235
Object 6078 _h	257	Object 60C4 _{h_04}	236
Object 6079 _h	258	Object 60C4 _{h_05}	236
Object 607A _h	220	Object 60C4 _{h_06}	236

Object 60F6 _h	103	Object 6510 _h _35 _h	88
Object 60F6 _h _02 _h	103	Object 6510 _h _36 _h	89
Object 60F9 _h	105	Object 6510 _h _37 _h	89
Object 60F9 _h _01 _h	105	Object 6510 _h _38 _h	98
Object 60F9 _h _02 _h	105	Object 6510 _h _38 _h	98
Object 60F9 _h _04 _h	105	Object 6510 _h _3A _h	84
Object 60FA _h	118	Object 6510 _h _40 _h	91
Object 60FB _h	113	Object 6510 _h _41 _h	92
Object 60FB _h _01 _h	113	Object 6510 _h _A0 _h	166
Object 60FB _h _02 _h	113	Object 6510 _h _A1 _h	166
Object 60FB _h _04 _h	113	Object 6510 _h _A9 _h	167
Object 60FBh_05h.....	114	Object 6510 _h _AA _h	167
Object 60FD _h	147	Object 6510 _h _AC _h	169
Object 60FE _h	148	Object 6510 _h _AD _h	168
Object 60FE _h _01 _h	148	Object 6510 _h _B0 _h	169
Object 60FE _h _02 _h	148	Object 6510 _h _B1 _h	170
Object 60FF _h	250	Object 6510 _h _B2 _h	170
Object 6410 _h	100	Object 6510 _h _B3 _h	171
Object 6410 _h _03 _h	97	Object 6510 _h _C0 _h	172
Object 6410 _h _03 _h	97	Object 6510 _h _F0 _h	67
Object 6410 _h _04 _h	97		
Object 6410 _h _10 _h	99	Operating Mode	
Object 6410 _h _10 _h	99	Homing mode	205
Object 6410 _h _11 _h	100	Parameterisation of the.....	201
Object 6410 _h _11 _h	100	Position control.....	218
Object 6410 _h _14 _h	101	Torque control.....	253
Object 6510 _h	83, 101, 120, 122, 152, 163, 166	Velocity control.....	241
Object 6510 _h _10 _h	83	Operation enable.....	180
Object 6510 _h _10 _h	83	Overspeed protection.....	104
Object 6510 _h _11 _h	152		
Object 6510 _h _11 _h	152		
Object 6510 _h _12 _h	153		
Object 6510 _h _13 _h	155		
Object 6510 _h _14 _h	154		
Object 6510 _h _15 _h	155		
Object 6510 _h _18 _h	163		
Object 6510 _h _20 _h	122		
Object 6510 _h _22 _h	120		
Object 6510 _h _2E _h	101		
Object 6510 _h _2F _h	102		
Object 6510 _h _30 _h	84		
Object 6510 _h _31 _h	85		
Object 6510 _h _32 _h	86		
Object 6510 _h _33 _h	86		
Object 6510 _h _34 _h	88		

P

Parameter

Load default parameter	65
Parameter adjustment.....	63
PDO.....	28, 35
RPD01	
COB-ID used by PDO.....	45
first mapped object	45
fourth mapped object.....	45
Identifier	45
number of mapped objects.....	45
second mapped object	45
third mapped object.....	45
transmission type	45

RPD02	
COB-ID used by PDO	45
first mapped object.....	45
fourth mapped object.....	45
Identifier	45
number of mapped objects	45
second mapped object.....	45
third mapped object.....	45
transmission type.....	45
RPD03	
COB-ID used by PDO	45
first mapped object.....	45
fourth mapped object.....	45
Identifier	45
number of mapped objects	45
second mapped object.....	45
third mapped object.....	45
transmission type.....	45
RPD04	
COB-ID used by PDO	45
first mapped object.....	45
fourth mapped object.....	45
Identifier	45
number of mapped objects	45
second mapped object.....	45
third mapped object.....	45
transmission type.....	45
TPD01	
COB-ID used by PDO	42
first mapped object.....	42
fourth mapped object.....	42
Identifier	42
inhibit time.....	42
number of mapped objects	42
second mapped object.....	42
third mapped object.....	42
transmission type.....	42
TPD02	
COB-ID used by PDO	42
first mapped object.....	42
fourth mapped object.....	42
Identifier	42
inhibit time.....	42
number of mapped objects	42
second mapped object.....	42
third mapped object.....	42
transmission type	42
TPD03	
COB-ID used by PDO.....	43
first mapped object.....	43
fourth mapped object.....	43
Identifier	43
inhibit time	43
number of mapped objects.....	43
second mapped object	43
third mapped object.....	43
transmission type	43
TPD04	
COB-ID used by PDO.....	43
first mapped object	43
fourth mapped object	43
Identifier	43
inhibit time	43
number of mapped objects	43
second mapped object	43
third mapped object	43
transmission type	43
PDO message	28, 35
peak_current	92
phase_order	99
polarity	81
Polarity Motor temperature sensor.....	101
pole_number.....	96
Position control	218
position control function	107
Position controller	107
Gain.....	113
Max. correction speed.....	113
Output of.....	118
Time constant	113
Tolerance window	114
Position reached	108
position_actual_value.....	116
position_control_gain	113
position_control_parameter_set	113
position_control_time	113
position_control_v_max	113
position_demand_sync_value	115
position_demand_value	114
position_encoder_selection	139

position_error_switch_off_limit.....	120	target_velocity.....	250
position_error_tolerance_window.....	113, 114	velocity_actual_value.....	246
position_factor.....	72	velocity_actual_value_filtered.....	247
position_range_limit.....	121	velocity_demand_value.....	245
position_range_limit_enable.....	122	velocity_display_filter_time.....	106
position_window.....	119	velocity_sensor.....	244
position_window_time.....	119	velocity_threshold.....	249
Positioning.....	218	velocity_threshold_time.....	249
Power stage parameter		velocity_window.....	248
DC link voltage	88	velocity_window_time.....	248
Max. current.....	92	profile_acceleration.....	222
Max. DC link voltage.....	88	profile_deceleration.....	222
Max. Temperature.....	86	profile_velocity.....	221
Min. DC link voltage.....	89	pwm_frequency.....	84
Nominal current.....	91		
Nominal voltage.....	86		
Temperature.....	85		
Power stage parameters.....	82		
power stage protection.....	89	Quick Stop Active.....	180
Power stage protection.....	88	quick_stop_deceleration.....	223
power_stage_temperature.....	85	quick_stop_option_code.....	199
pre_defined_error_field.....	53		
producer_heartbeat_time.....	58		
product_code.....	164		
Profile Position Mode.....	218		
end_velocity.....	221		
motion_profile_type.....	223		
profile_acceleration.....	222		
profile_deceleration.....	222		
profile_velocity.....	221		
quick_stop_deceleration.....	223		
target_position.....	220		
Profile Torque Mode.....	253		
current_actual_value.....	257	Rated current	94
dc_link_circuit_voltage.....	258	Ready to Switch On.....	180
max_torque.....	255	ready_for_enab.....	193
motor_rated_torque.....	256	Receive PDO 1	45
target_torque	255	Receive PDO 2	45
torque_actual_value.....	257	Receive PDO 3	45
torque_demand_value.....	256	Receive PDO 4	45
torque_profile_type	259	Reference switch	152
torque_slope	258	resolver_offset_angle.....	100
Profile Velocity Mode.....	241	restore_all_default_parameters.....	65
max_motor_speed.....	250	restore_default_parameters.....	65
sensor_selection_code.....	245	restore_parameters.....	65

Q

Quick Stop Active.....	180
quick_stop_deceleration.....	223
quick_stop_option_code.....	199

R

Rated current	94
Ready to Switch On.....	180
ready_for_enab.....	193
Receive PDO 1	45
Receive PDO 2	45
Receive PDO 3	45
Receive PDO 4	45
Reference switch	152
resolver_offset_angle.....	100
restore_all_default_parameters.....	65
restore_default_parameters.....	65
restore_parameters.....	65
revision_number.....	165
R-PDO 1	45
R-PDO 2	45
R-PDO 3	45
R-PDO 4	45

S

Sample	
Control	159
Mode	157
Status	158
Status mask	159
sample_control	159
sample_data	157
sample_mode	157
sample_position_falling_edge	161
sample_position_rising_edge	161
sample_status	158
sample_status_mask	159
Sampling position	
Falling edge	161
Rising edge	161
save_all_parameters	66
Scaling factors	70
Sign	81
SDO	28, 29
Error messages	32
SDO message	28
SDO-Message	29
second_mapped_object	41
Selection of the commutating encoder	137
Selection of the position encoder	139
Selection of the synchronisation encoder	140
sensor_selection_code	245
serial_number	165
set_position_absolute	123
Setpoint	
Position (position_units)	114
Synchronous speed (velocity units)	246
Velocity (speed_units)	245
shutdown_option_code	198
Sinus modulation	84
size_of_data_record	236
Synchronous speed setpoint	246
Speed controller	104
Speed limitation	125
Scaling	125
Setpoint	125
Source	125

Speed limited torque control	125
speed_limitation	125
standard_error_field_0	53
standard_error_field_1	53
standard_error_field_2	53
standard_error_field_3	53
State	
Fault	180
Fault Reaction Active	180
Not Ready to Switch On	180
Operation Enable	180
Quick Stop Active	180
Ready to Switch On	180
Switch On Disabled	180
Switched On	180
state diagram	178
statemachine	178
statusword	
Bits of the	189
Description	188
store_parameters	66
Switch On Disabled	180
Switched On	180
SYNC	48
synchronisation_encoder_selection	140
synchronisation_filter_time	142
synchronisation_main	141
synchronisation_selector_data	141
Synchronous speed (velocity units)	246
SYNC-Message	48
syncronize_on_group	232

T

Target position	
Time	119
Target position window	119
target_position	220
target_reached	108
target_torque	255
target_velocity	250
third_mapped_object	41
Torque control	253
Max. torque	255

Torque limitation	124	
Scaling	124	
Setpoint	124	
Source	124	
Torque limites speed control	124	
torque_actual_value	257	
torque_control_parameters	103	
torque_control_time	103	
torque_demand_value	256	
torque_profile_type	259	
torque_slope	258	
T-PDO 1	42	
T-PDO 2	42	
T-PDO 3	43	
T-PDO 4	43	
tpdo_1_transmit_mask	43	
tpdo_2_transmit_mask	43	
tpdo_3_transmit_mask	44	
tpdo_4_transmit_mask	44	
Trailing error	107	
Trajectory generator	218	
transfer_PDO_1	42	
transfer_PDO_2	42	
transfer_PDO_3	43	
transfer_PDO_4	43	
transmission_type	40	
transmit_pdo_mapping	41	
transmit_pdo_parameter	40	
 V		
Velocity control	241	
Velocity controller	104	
Filter time	105	
Gain	105	
Parameter	105	
Time constant	105	
velocity_acceleration_neg	252	
velocity_acceleration_pos	252	
velocity_actual_value	246	
velocity_actual_value_filtered	247	
 Y		
velocity_control_filter_time	105	
velocity_control_gain	105	
velocity_control_parameters	105	
velocity_control_time	105	
velocity_deceleration_neg	252	
velocity_deceleration_pos	252	
velocity_demand_sync_value	246	
velocity_demand_value	245	
velocity_display_filter_time	106	
velocity_encoder_factor	75	
velocity_rampe_enable	251	
velocity_ramps	251	
velocity_sensor_actual_value	244	
velocity_threshold	249	
velocity_threshold_time	249	
velocity_window	248	
velocity_window_time	248	
vendor_id	164	
 X		
X10		
Counter	133	
Ingoing shaft	132	
Outgoing shaft	132	
Resolution	132	
X2A		
Ingoing shaft	128	
Outgoing shaft	128	
Resolution	128	
X2B		
Counter	130	
Ingoing shaft	129	
Outgoing shaft	130	
Resolution	129	
 Z		
Zero impulse		216